




Product Installation Instructions







1x1




2x1




3x2




4x2




5x1




6x1




7x1




8x1




9x1




10x1




11x1




12x1




13x1




14x1




15x1




16x1




17x1




18x1




19x1




20x1




21x1




22x1




23x1




24x1




25x4




1




26x1




27x1




28x1




29x1



30x2




31x1




32x1



33x1



34x1




35x1




36x1




37x1




38x1




39x1




40x2




41x1




42x2




43x2




44x2




45x2




46x2



47x2































48x1




49x1


















2

A		Two In One Screw (6x28mm)	149pcs +6pcs
B		Two In One Nut (10x12mm)	149pcs +6pcs
C		Wood Chipping (6x30mm)	16pcs +2pcs
D		Fixing clip & screw (3x16mm)	18pcs +2pcs
E		Handle & Screw (4x8mm)	2pcs / 4pcs +1pcs
F		Handle & Screw (4x16mm)	1pcs / 2pcs
G		Screw (3x20mm)	2pcs +1pcs
H		Laminate support nail	8pcs
I		Screw & Guide(12 inch) (3x12mm)	20pcs +2pcs / 4pcs
J		Non-slip pads	10pcs +2pcs
K		Iron guide rail	1pcs
L		Iron guide rail hook	2pcs
M		Plastic slide	2pcs
N		Hinge & Screw (3.5x12mm)	2pcs / 8pcs +1pcs
O		Acrylic hair dryer holder & Screw (3.5x25mm)	1pcs / 2pcs
P		Clamp	2pcs
Q		Screw (6x28mm)	3pcs
R		Screw (6x12mm)	4pcs +1pcs
S		Power Socket & Screw (3x10mm)	1pcs / 2pcs
T		Magnetic attraction Screw (3x10mm) Iron sheet	2pcs / 8pcs +2pcs / 2pcs
U		Screw (3.5x12mm)	4pcs +1pcs
V	<div>  x2  x2  x4  x2 </div> <div>  1pcs </div> <div>  </div> <div> Double-head screwdriver, use as required </div> <div>  </div>		

Product structure decomposition




<div>A</div>		75pcs	<div>B</div>		67pcs	<div>C</div>		16pcs
<div>D</div>		2pcs	<div>E</div>	 2pcs	 4pcs	<div>G</div>		2pcs
<div>I</div>	 4pcs	 20pcs	<div>J</div>	 6pcs	<div>S</div>	 1pcs	 2pcs	
<div>T</div>	 2pcs	 4pcs						




Use parts A and B




Step1



Step2





Step3




Use a screwdriver to lock in the direction of the "+" sign Disassemble along the direction of "-" sign

Step 1





Step 2

Ⓑ




x4




Step 3

④




⑥

③




7


Step 4



Step 5





Drawer rail breakdown diagram




Step 1 : Pull the rails apart

Step 2 : Push the nylon buckle outward a



(b)

(c)




(a)

(b)


(c)

Step 6




(I)

x2




x4




(E)




x1





x2



Step 7








Step 8







Fix the internal structure with screws

Step 9




Step 10




Step 11

B




x4




Step 12

I




x2




x4


E





x1





x2



Step 13




Step 14





Step 15

B




x3




Step 16



T





x1






x2







Step 17



Step 18






Step 19




Tear off release paper and stick the black foot pad on the board


Step 20





Step 21

- A

x2
- T


x1


x2



Step 22


- A

x5




Step 23

B




x3




Step 24

C




x2




Step 25



B





x2



Step 26





Step 27



Step 28


B

x3




Step 29


B

x3

J


x2

Tear off release paper and stick the black foot pad on the board




Step 30

I




x2




Step 31

I




x1




This hole is for strengthening fixed hole customers can choose to install according to their needs.

Step 32


- A



x7
- C




x4




Step 33



- B





x5



Step 34




Step 35




Step 36

B




x3




Step 37

B




x3




Step 38

①




x2



Step 39

①




x1

①



x2


Tear off release paper and stick the black foot pad on the board




This hole is for strengthening fixed hole customers can choose to install according to their needs.

Step 40


- A



x6
- C




x2




Step 41

- A




x2




Step 42

B




x4




Step 43

B




x6




Step 44

C




x6




Step 45

1



x2




Note: There are no nut holes on this side


The 10th board should be installed in the direction indicated by the arrow on the label

Step 46

1




x1




This hole is for strengthening fixed hole customers can choose to install according to their needs.

Step 45

I




x2




The 10th board should be installed in the direction indicated by the arrow on the label

Step 46

I




x1




This hole is for strengthening fixed hole customers can choose to install according to their needs.

Step 47



B





x2



Step 49




Step 50




Step 51



B




x9





























Step 52


- S**
-  x1
-  x2






Thread the light wire through the back panel hole






A		32pcs	B		40pcs	D		16pcs
F	 1pcs	 2pcs	H		8pcs	K		1pcs
L		2pcs	M		2pcs	N		8pcs
O	 1pcs	 2pcs	P		2pcs	Q	 3pcs	 3pcs
R		4pcs	T	 2pcs	 4pcs	U		4pcs
V	 2pcs	 4pcs	 2pcs	 2pcs	 2pcs			



Step 53




Step 54




Step 55

B




x2




Step 56

B






x4





39



Step 57





Step 58





Step 59




Step 60




Step 61

K	 1 Pcs
Q	 3 Pcs



The screw is threaded through the iron guide rail, then through the iron pipe, and then installed in place




Step 62




Step 63


Ⓑ		x8
Ⓗ		x8










Step 64



Step 65





F		
	x1	x2
N		
	x2	x4
T		
	x2	x4



Step 66


N

x4




As shown, When installing the drawer,
pull the guide rail out first, Slide beads are also pulled out.

Step 67





If there is a large gap after the installation of the door, please twist the screw of the door hinge back halfway and move the door left and right.


Step 68



If a large gap is found after installing the drawer the slide rail can be moved up and down to adjust the gap

Step 69




M		x2
U		x4



Step 70

L
x2

Hang the guide rail hook horizontally on the guide rail iron bar and make it vertical




Step 71

®



x4


Put the iron plate of the mirror's guide rail into the aluminum groove





First, thread the mirror power cord through the back panel before installing the mirror

Step 72

D



x16


x16




Step 73


P



x2




Step 74




0

x2



x1



x2


18


Attention: When the screws are about to be tightened, be careful not to use too much force to avoid bursting the air duct frame


Step 75


Install as required


V

 x2


 x2

 x2


3.5x14mm 





Install the anti fall hardware on the cabinet as shown in the picture first






Then mark the wall with a pen through the holes in the anti-fall hardware



Step 76




Drill the hole with an electric drill and punch in the colloidal particles




4x45mm

Fix the dressing table to the wall

Step 77




A




40pcs



B




40pcs






Step 78



Step 79




Repeat this step 2 times





Step 80

Repeat this step 2 times

B




x16



Attention: Two in one hole facing outward


Step 81

A





x4

B




x4




Step 82

B




x4

Attention: Two in one hole facing outward




Step 83


A




x4



Step 84




B



x8


J




x4

Tear off release paper and stick the black foot pad on the board

Step 85



B



x8



User's Guide

Thank you for purchasing this product.

To use this product, please plug it into a 12V DC power supply.

Please use if the product works normally after connecting to power.

Introduction

The box is an intelligent controller. It has 1 USB output port 1 Type-c port and can distribute the current output up to 5V DC-2A. With 2 touch buttons, it can turn. ON/OFF the light, change light colors, and adjust the light luminance.

Operation




This touch button is used to turn on/off, change colors, and adjust brightness.

- A. Short touch -> lighting on -> short touch -> change light color -> short touch -> change light color -> short touch -> lighting off.
- B. Long touch -> adjust the luminance.



This touch button is used to turn on/off the induction function.

- A. Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller in 1 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.
- B. Long touch to turn off the induction function.
- C. Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.



ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
2. If you have any questions when installing, please feel free to contact us. Thank you.