




# SKU:BE017101



## BOARD IDENTIFICATION




# Part List



Top Board

Board

Back Board




Left Board

Right Board

Left Board

Right Board




Left Middle Board

Right Middle Board

Front Middle Board

Back Board




Front Middle Batten

Bottom Batten

Back Batten

Back Board




Drawer Front board

Drawer left board

Drawer right board

Drawer Back board


# Hardware List



CAM BOLT

CAM LOCK


WOODEN PEG



SCREW

HANDLE


SCREW



USB

LEFT RAIL

RIGHT RAIL




SCREW

LIGHT STRIP


WASHERS

## STEP 1




Insert (C) into part (1). Attach cam bolt (A) to part (1) with screwdriver.


Attach part (1) to part (8,9,10). Then use attach part (B) to lock them.




## STEP 2




Insert (C) into part (1,11,12). Attach part (6,7) to part (1,11,12) with (D).



## STEP 3




Insert (C) into part (8,9,10). Attach part (2) to part (8,9,10) with (D).



5

## STEP 4




Using screw (J), attach (H) to (4).

Using screw (J), attach (I) to (5).



Notice:

Note the orientation and hole location of (H) and (I).




6



## STEP 5




Insert (C) into part (5). Attach part (5) to part (13,14) with (D).





## STEP 6



Insert (C) into part (13,14). Attach part (4) to part (13,14) with (D).




## STEP 7



Attach part (G) to part (1) with (J) as shown.


Notice:

Note that the plug is placed under the hole as shown in the figure.




9

## STEP 8




Tear off (K) tape stick (K) on parts (8,9,10)






10

## STEP 9

Put part (3) into (4,5) as shown.




## STEP 10



Insert (C) into part (4,5). Attach cam bolt (A) to part (2) with screwdriver.

Attach part (2) to part (4,5). Then use attach part (B) to lock them.




## STEP 11









Attach part (17,18) to part (19) with (K). Then put part (15) into (17,18,19) as shown.

Repeat this step for another drawer assembly.



## STEP 12



Attach cam bolt (A) to part (16) with screwdriver.  
Attach part (16) to part (17,18). Then use attach part (B) to lock them.


Using screw (J), attach (H) to part (18).

Using screw (J), attach (I) to part (17).



Notice:

Note the orientation and hole location of (H) and (I).


Repeat this step for another drawer assembly.



## STEP 13




Using screw (F), attach (E) to the side part (16).  
Repeat this step for another drawer assembly.




15

## STEP 14



Align the 2 slide rails and put drawer into, then put (L) as shown.



16