


Thanaddo® Carport

3m x 6m / 10ft x 20ft

Assembly Guide




Imported by **Thanaddo Industrial Inc.** 10501 Valley Blvd, #1824 El Monte, CA 91731
Manufactured by **Laizhou Beite Machinery Co., Ltd.**


SAFETY


- Read all the safety information and instructions.
- Make sure you have all the parts before the assembling
- Do not assemble the carport on a stormy day. It will be damaged.
- Always wear work gloves, long sleeves, and safety goggles when assembling.
- Keep children and pets away from the assembly site.
- When using a ladder, make sure the ground is stable enough to hold the ladder.
- Remove snow from the roof after each snowfall.
- Do not walk on the roof, even if you can.

TOOLS




PART LIST







Part	Qty
G	8
H	8
I	84
K	4
L	4
O	12

Part	Qty
Front Cover	1
Back Cover	1
Side Cover	2
Top Cover	1




1

Part	Qty
A	4
B	6
D	6




Note

For this product, tubes are connected using button clips. Button clips are already inserted inside tubes. When connecting, press the button clip and insert one tube into another. Forcing the tubes inside each other might also work but you are risking damaging the Clip. Repeat this step.



Part	Qty
A	4
E	6

Note
Repeat this step.






Part	Qty
B	3

Part	Qty
C1	4
C2	4
F	8
G	8


Note

Tubes like C1 and C2 only have one button clip inside. While connecting C1 and C2 to F, make sure to use the end without button clip. Repeat this step till you have used all C1 and C2.







Note
Temporarily lay the frame down and attach C1+F and C2+F created in last step to the frame.
Make sure that C2 are placed at the front and back of the frame with the three holes facing outwards.



7 Optional Step


Part	Qty
M	6
O	12




Note

This is an optional step. It's up to you to decide whether to use M to add the extra stability. You will need a power tool drive O into the tubes. Notice that you will not find predrilled holes on the tubes for O. Do not worry too much about pinpointing the exact location for M. The location contributes little to the stability.

TOP COVER





Part	Qty
Top Cover	1



Note

Find the hooks at the end of Top Cover's feet and place the hook inside the hole at the bottom of C2.



Part	Qty
Side Cover	2
Front Cover	1
Back Cover	1
I	84



Note


Use bungee cord, Part No. I, to fasten the covers onto the tubes.
 On the eaves of the carport, where the grommet of Top Cover overlap with the grommet of Side Cover, use one I with two grommets.

Part	Qty
K	4
L	4



11 Optional Step

Part	Qty
H	8



Note
 If you prefer to secure the carport onto a concrete surface then use the concrete anchor H. Eight H are included. You can use one per F, or four on the front and four at the back. You will need a M12, or 1/2 inch drill bit to drill into the concrete a hole which is 5.1cm, or 2inch deep. Remove the carport when hammering the H_Bolt and H_Sleeve into the concrete. Notice that once the Bolts and Sleeves are in, it is almost impossible to get them out. So plan where you want to use them carefully.

