



Assembly Instructions

Option A



Option B




Before Assembly

Tips Before Your Start:


- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until the assembly is completely assembled.
- Keep all hardware parts out of reach of children.

QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


CAM LOCK



When fitting a cam lock, ensure the starting position is correct before inserting the connecting QUI CKFIT














Quickfit head should be in the centre of the cam lock when the two panels are joined.

Cam lock should be inserted before quickfit.




Turn cam lock clockwise to tighten.


Part List

<p>No. A Quantity:10 Pcs Cam Lock Dowel 8*28mm</p> 	<p>No. B Quantity:10 Pcs Cam φ15</p> 	<p>No. C Quantity:10 Pcs Sticker Ø20</p> 	<p>No. D Quantity:20 Pcs Dowel 8*40mm</p> 
<p>No. E Quantity:1 Sets Stretch hardware</p> 	<p>No. F Quantity:40 Pcs Screw M3.5*14mm</p> 	<p>No. G Quantity:2 Pcs Screw M4*14mm</p> 	<p>No. H Quantity:24 Pcs Screw M6*40mm</p> 
<p>No. I Quantity:8 Pcs Slip Mat Ø20</p> 	<p>No. J Quantity:1 Pcs Allen Key 4#</p> 	<p>No. K Quantity:2 Pcs Hinge 84*30*6mm</p> 	<p>No. L Quantity:1 Pcs Handle 200*20mm</p> 
<p>No. M Quantity:6 Pcs Dowel 8*30mm</p> 			

Product structure



STEP 1




No. A
Quantity: 4 Pcs
8*28 mm



×2

STEP 2




No. B
Quantity: 4 Pcs
Ø15



STEP 3


No. M
Quantity: 6 Pcs
8*30mm



No. H
Quantity: 8 Pcs
M6*40mm




No. J
Quantity: 1 Pcs
4#



STEP 4


No. D
Quantity: 4 Pcs
8*40mm



No. H
Quantity: 4 Pcs
M6*40mm




No. J
Quantity: 1 Pcs
4#



STEP 5


No. D
Quantity: 4 Pcs
8*40mm



No. H
Quantity: 6 Pcs
M6*40mm




No. J
Quantity: 1 Pcs
4#




STEP 6

No. A
Quantity: 6 Pcs
8*28 mm




STEP 7




No. B
Quantity: 6 Pcs
Ø15



No. D
Quantity: 6 Pcs
8*40mm




STEP 8




No. G
Quantity: 2 Pcs
M4*14mm



No. L
Quantity: 1 Pcs
200*20mm




STEP 9



There is wax on the sliding door, and it needs to be pushed and rubbed back and forth before use, so that the wax is evenly attached to the board.

STEP 10


No. D
Quantity: 6 Pcs
8*40mm




No. H
Quantity: 6 Pcs
M6*40mm



No. J
Quantity: 1 Pcs
4#





STEP 11



No. I
Quantity: 8 Pcs
Ø20



STEP 12





No. E
Quantity: 1 Sets



No. F
Quantity: 12 Pcs
M3.5*14mm




STEP 13



No. F
Quantity: 16 Pcs
M3.5*14mm




STEP 14



No. F
Quantity: 12 Pcs
M3.5*14mm







No. K
Quantity: 2 Pcs
84*30*6mm



STEP 15





Option A



After the panel is closed, please lock the slide track to prevent the panel from sliding.

STEP 16

Option B



Please unlock the slide track before using this scheme, so that the panel can be pulled open.

