
30000068/300001068/300003068/300004068 30000099/300001099/300003099/300004099 300000431/300001431/300003431/300004431 300000430/300001430/300003430/300004430





PARTS IDENTIFICATION

(jagged)

Anchor Stake

- Caps x 8


# \*\*NOTE

Stacking

Stake

Anchor stakes should ONLY be use on ground level & middle portion . It CANNOT be used to stack up additional levels.

Stacking stakes can be used on all levels and when creating additional levels. **ONLY** Stacking Stakes can stack!



### FOR INDOOR & HARD SURFACE:

If you plan to assemble raised bed on a hard surface, use hacksaw to remove the spike of each stake. Use these cut down stakes for the base level only of your raised garden.

Customer Service: 1800-914-9835 | support@frameitall.com © Frame It All. All Rights Reserved.

# ASSEMBLY INSTRUCTIONS

#### STEP 1:


Assemble the timbers by sliding one end of timber into channel end of one of the brackets. Use plugs to cover the holes on both sides to lock the bracket in place.



Repeat this process on the opposite end of the timber flipping the bracket in the opposite direction (see image). Repeat for all timbers.

### STEP 2:

Layout the base level of your raised garden in a straight square shape, using 2 timbers on each side. Insert stake through the hole of the bracket and into each of the corners to lock all sides in place. Install anchor stakes on each of the joint locations indicated by the red arrows below. All remaining ground level joints will use stacking stakes.



## **ASSEMBLY INSTRUCTIONS – For Product with Second to Four Levels**

### STEP 3:

For each levels, use  $8 \times 4'$  timbers plus the stacking stakes. Insert one stake through the brackets into the hole on top of the stake beneath it to lock the level below in place.

Lastly, add the caps to each of the top corner joint.

### How the Joints Work

