








Version : 2.0




EN_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.




EN_QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.
























EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.































EN_Turn cam lock clockwise to tighten.





PACKING DELALS


NO.	PARTS	QTY	SPARE
①		x2	
②		x2	
③		x2	
④		x2	
⑤		x1	
⑥		x1	
⑦		x1	
⑧		x1	
⑨		x1	
⑩		x1	
⑪		x1	






NO.	PARTS	QTY	SPARE
⑫		x2	
⑬		x8	
⑭		x2	
⑮		x4	
⑯		x4	
⑰		x8	
⑱		x8	
⑲		x8	
⑳		x8	
			
	Hardware Kit		







 A x60 Ø6x35mm +3(spare)	 B x60 Ø15x10mm +3(spare)	 C x52 Ø6x30mm +3(spare)	 D x52 Ø4x35mm +3(spare)	 E x96 Ø3.5x12mm +5(spare)	 F1	 F2 x8	
 G x2	 H1	 H2	 I1	 I2	 J x2 Ø4x14mm	 K x18 Ø5x35mm +1(spare)	 L x1
 CL x8 L350mm	 CR x8 L350mm	 DL x8 L350mm	 DR x8 L350mm	 M1	 M2 x4	 N x2	
 O x8 Ø4x12mm	 P x4	 Q x8					

 A x20	 B x20	 D x20	 C x16	x4	01
---	--	---	---	-----------	-----------










E x24

DL x4

DR x4

x4



06



A x8





B x8



07




x2

x2







A x3



12




A x2




E x12



CL x4






13





A x1

E x12

CL x4




B x3




For easier installation, please pad two pieces of foam under the product (take it from the packaging box).

B x3





Need Two or More People To Complete





C x6

D x6






Need Two or More People To Complete







D x6





A x6




B x6

C x6








! The backplate slots are rearward





H x10


Q x8









First fix the anti-rewind screw in the reserved hole of the product.




then, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.



Then use a tape drill to make holes in the wall that are suitable for the product screws.



Then, put the expansion bolt into the hole



Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.

