




Assembly Instructions



Part List



Parts List



Please prepare the following tools

A x 80

Ø6 x 35 mm

B x 80

Ø12 x 10 mm

C x 4

Ø4 x 40 mm

D x 4

Ø10 x 9 mm

E x 24

Ø3 x 12 mm

F x 12

G x 4

Ø4 x 16 mm

H x 2

I x 2


J x 2

K x 1


Screwdriver

L x 2

Warm Reminder




A




B

This Cam Lock Fastening System will be used throughout the assembly process


(1)



(2)









(3)




Install

1


<p>A x 6</p>  <p>Ø6 x 35 mm</p>	<p>10 x 1</p>	 
		

Screw the cam bolt(A) into panel(10).




Install

2





1 x 2


2 x 2



Screw the cam bolt (A) into one side of panel (1), then flip the panel 180° and screw the cam bolt into the other side.



Screw the cam bolt (A) into one side of panel (2), then flip the panel 180° and screw the cam bolt into the other side.





Install

3

A x 48  Ø6 x 35 mm	7 x 1 12 x 3 14 x 3
	8 x 1 13 x 3 15 x 3






Screw the cam bolt(A) into panels (8), (7), (14), (13), (15), and (12).






Please note that there are three pieces of each panel (14),(13),(15) and (12), and cam bolts (A) need to be screwed into all of them.



Install

4

B x 30  M12 x 10 mm	⑪ x 3	⑬ x 3	 
	⑫ x 3	⑭ x 3	







Align the screws (A) on panel (12) with the holes in panel (11), then secure them using cam locks (B) on panel (11). Repeat this step three times.




Align the screws (A) on panels (14) and (13) with the holes in panels (11) and (12), then secure them using cam locks (B) on panels (11) and (12). Repeat this step three times.


Install

5

B x 18  M12 x 10 mm	E x 24  Ø3 x 12 mm	F x 12 	(15) x 3 
--	---	---	---







Install the four wheels (F) at the bottom of panel (11) and secure them with screws (E). Repeat this step three times.




Align the screws (A) on panel (15) with the holes in panels (11), (13), and (14), then secure them using cam locks (B) on panels (11), (13), and (14) respectively. Repeat this step three times.

Install

6






<p>B x 4</p>  <p>M12 x 10 mm</p>	<p>2 x 1</p> <p>3 x 2</p>	 
		

Align the screws (A) on panel (2) with the holes in panel (3), then secure them using cam locks (B) on panel (3).




Install

7

<p>B x 4</p>  <p>M12 x 10 mm</p>	<p>1 x 1</p>	<p>4 x 1</p>	
			

Refer to the diagram and slide panel (4) into the assembled parts from Step 6.

Align the screws (A) on panel (1) with the holes in panel (3), then secure them using cam locks (B) on panel (3).




Install

8



After completing Step 7, flip the cabinet 180° .





Install


9

B x 4
M12 x 10 mm

5 x 2








Align the screws (A) on panel (2) with the holes in panel (5), then secure them using cam locks (B) on panel (5).




Install

10

<p>C x 4</p>  <p>Ø4 x 40 mm</p>	<p>D x 4</p>  <p>Ø10 x 9 mm</p>	<p>6 x 1</p>	 
			




Insert part (D) into panel (5). Align the holes of panel (6) with panel (5), then secure panel (6) to panel (5) using screws (C).




Install

11

<p>B x 6</p>  <p>M12 x 10 mm</p>	<p>7 x 1</p>	
---	--------------	---

		
---	---	---




Align the screws (A) on panel (7) with the holes on panels (1), (2), and (6), then secure them with the latch lock (B).


Please note that this step requires the gap on part (7) to be connected with panel (4).

Install

12



<p>B x 6</p>  <p>M12 x 10 mm</p>	<p>8 x 1</p>	
  		

Flip the bookshelf 180° and repeat the same operation as Step 11 for panel (8).
Note that panel (8) must still be connected with the gap on panel (4).




Install

13

<p>B x 2</p>  <p>M12 x 10 mm</p>	<p>9 x 1</p>	 
  		



Align screws (A) on panel (1) with the holes in panels (9), then secure with cam locks (B).




Install

14

4 x 1




Refer to the diagram and slide panel (4) into the assembled parts from Step 13.





Install


15

B x 6

M12 x 10 mm

10 x 1






Align screws (A) on panel (10) with the holes in panels (8), (9), and (7), then secure with cam locks (B).




Install


16

H x2 	G x4  Ø4 x 16 mm	 
---	---	---

		
---	---	---







Install the (H) anti-tip bracket onto the side panels (7) and (8) using (G) screws.



Install


17




Use an impact drill to make holes and insert the expansion screw (J) into the wall, then screw part (L) into the expansion screw (part J). Finally, use the straps (part I) to connect part (H) and secure the bookshelf to the wall.

Install


18




Slide the assembled drawer into the bookshelf.



Install





We' d Love to hear from you!

Thank you for your purchase of our product!

If you encounter any problems, please give us an opportunity to improve your experience right away, our team members are more than happy to help.

We also welcome you to post a product review so that others could benefit from your experience. Thanks again for your support, feedback and time.