


Assembling Instruction

Generating Drawings



ATTENTION

If there is any missing, please kindly send us messages to let us know the name of missing part regarding to the first page of instructions.


We will send replacement to you asap. We are concerned about each customer's experience, if there is any loss or damage, please contact us at any time, we will provide effective solutions.

Please attach your Oder ID so that we can assist you better.




General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product .




- VI. Power tools should not be used to assemble this product .

































- VII. Concealed hinges are three-way adjustable.

Parts List



HARDWARE PACK CONTENT

 Ø6x35mm 45x +2	 Ø15x11mm 41x +2	 Ø6x40mm 4x+1	 1x	 Ø8x5x16mm 8x+1	 Ø3x17mm 12x+2	 12x+2
 3x	 M6*12mm 6x	 4x	 Ø6x12mm 8x	 2x	 Ø4x12mm 4x	 Ø8x30mm 34x+2
 4x	 Ø4x12mm 10x+1	 Ø15x9mm 4x	 Ø30mm 41x+2	 Ø3x12mm 8x+1	 M6*25mm 2x	 5x
 Ø4x32mm 7x	 1x	 2x	 6x	 2x	 2x	 Ø3x26mm 2x
 1x						







Philips head screwdriver required for assembly
(not included)



The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.

CAM LOCK/BOLT FASTENING INTRODUCTION

(You will use it during assembly)

<p>1</p> 	<p>2</p> 	<p>3</p> 	<p>4</p> 
<p>1.Screw cam bolt into the threaded anchor gently. (Attention:don't screw cam bolt too deep or too shallow.)</p>	<p>2.Please connect the 2 boards you want connect by inserting cam bolt.</p>	<p>3.Insert the cam lock into the round hole of the board. (Attention:point the arrow on the top of the cam lock to the outer edge.)</p>	<p>4.Turn the cam lock clockwise until it is firmly tightened.</p>

Please use [B] and [Q] CAM LOCKS as shown in the illustrations.




Step 1

N




X34




Step 2

A



X41



Step 3


Q




X4




NOTE: Be sure to use [Q] 9MM CAM LOCKS for the drawer side panels #21 and #22.




Step 4




Step 5

V

X4





Step 6

R
O
X4




Step 7

S	CC
	
X6	X1





NOTE:

Refer to the images to identify CC-L (left) and CC-R (right). Attach CC-L to #5 panel and CC-R to #6 panel. [S] screws must go in the exact spots shown.



Make sure the rollers on the slides face downward.




Make sure the rollers on the slides face downward.

Step 8

B



X2




Step 9




B




X2





Step 10

D	H	I
		
X1	X3	X3




Step 11

I

X3



Step 12





Step 13

C



X4




Step 14

B



X3




Step 15

B



X1




Step 16


B



X4



Step 17





Step 18


E







X8







Step 19






Step 20

P	O	K	J
			
X8	X4	X8	X4




Step 21

L	M
	
X2	X4



Step 22




Step 23



B




X10



Step 24

X	Y
	
X2	X6



Step 25


B



X4



NOTE: #9 and #10 with the dowel side facing out.




Step 26

B



X4




Step 27

B




X7





Step 28

A



X4




Step 29

B



X4




Step 30

V



X3




Step 31

T




X2






Step 32

R
O
X37







Step 33

F	G
	
X12	X12




Step 34


S	W
	
X2	X1




Step 35



Step 36



Step 37





Step 38

U






X5



Adjustable feet


Step 39

Z	P
	
X2	X2



Step 40

Wall




Make FOUR holes 30MM deep


Step 41

Wall

AA



X2




Step 42

BB



X2

Wall



Step 43

