


# Installation Manual



## Thank you for your purchase.

If you encounter any challenges during installation or if the product dimensions don't align with your designated space, kindly reach out directly for assistance. We are committed to ensuring your satisfaction and offer the option to exchange panels or parts to accommodate your specific needs.

We take pride in delivering quality products and exceptional customer service. Our goal is to guarantee your contentment with your purchase for years to come. With an extensive range of sizes available, we can provide panels/hardware to suit any measurements.

For any inquiries or assistance, please feel free to contact us. We appreciate your choice of products and look forward to serving you. Thank you!

Best Regards,

**Caution: The corners of tempered glass panels are particularly fragile. It is crucial to use the provided cardboard or rubber blocks, ensuring the glass never contacts the tile surface during installation. Always place the glass on cardboard packaging or rubber blocks when outside the packaging. If needed, you can utilize wood, cardboard, or other rubber materials for added protection against breakage. Please exercise care in handling the glass to prevent damage.**

## IMPORTANT: Please read before install

1. **\*\*Inspect Shipment Upon Arrival:** Before proceeding with installation, it is crucial to examine all packages for any visible shipping damage and to compare the quantity of items received with the packing slip. This step ensures that all components are accounted for and in good condition.


2. **\*\*Introduction and Component Verification:** After unpacking, please take a moment to read through the provided introduction. Utilize the "Packing List" to verify the presence of all essential parts, marking each off as you confirm them. Should you discover any damages, finish flaws, or missing components, contact our customer service team within three business days of receiving your shipment. For assistance, provide your order number or any other relevant purchase details to help us locate your original order efficiently.
3. **\*\*Compliance with Local Building Codes:** It is your responsibility to consult local building and plumbing codes to ensure your installation meets all compliance standards.
4. **\*\*Preparation for New Constructions:** For installations in new constructions, ensure all required plumbing and drainage are in place before installing the shower. Engage a qualified and, if necessary by local regulations, licensed plumber for all plumbing work.
5. **\*\*Surface Preparation:** Before starting the installation, confirm that the base surfaces are level, solid, and capable of supporting the total weight of the unit. Walls should be checked for right angles to avoid installation difficulties. Adjustments and drilling may be required during the installation process.

## Cleaning and Maintenance

1. For daily cleaning of the product, you can use common liquid detergent and a soft cloth.
2. For stains, use a clean soft towel or a small amount of neutral soap solution or toothpaste to gently wipe.
3. To keep the glass surface shiny, you can use a polishing agent for polishing treatment.

## Precautions

1. Do not use acidic, alkaline, or sharp tools during cleaning to avoid damaging the glossiness of shower trays, glass, metal materials, and other accessories surfaces.
2. Avoid using strong detergents containing acetone or ammonia ingredients; when disinfecting, avoid using disinfectants containing formic acid and formaldehyde to prevent damage to the product's surface glossiness.
3. Do not allow body or hard objects to come into contact with or impact the glass surface during showering to avoid accidents.



## In the event of breakage please follow the steps below.

1. If someone is inside the shower, move the panel slowly out of the way and exit the bathroom as soon as possible. Do not allow anyone to re-enter bathroom until prepared to remove and dispose of broken panel.
2. Utilize safety precautions such as a hard-hat, safety glasses, leather gloves, proper footwear and moving blankets to minimize risk of injury.
3. It is recommended that two people assist in the removal of the panel. One person to hold panel steady, and the other to un-install the hardware. Then carefully remove glass from shower and lay flat on cardboard or plywood until it can be removed. Once laying flat a razor knife or box cutter can be utilized to cut the film and remove in smaller pieces.

## Tools



Level



Tape Measure



Pencil



Phillips Screwdriver



Silicone



Power Drill



Drill Bit  
Ø1/8"  
(3mm)



Drill Bit  
Ø3/16"  
(4mm)



Drill Bit  
Ø1/4"  
(6mm)




Drill Bit  
Ø5/16"  
(8mm)



Drill Bit  
Ø3/8"  
(10mm)



Soft Head Hammer



Miter saw



Safety Glasses



Work Gloves



Hacksaw



#3 Phillips Driver Bit



Professional-grade Glass suction cup




Painter's Tape




Razor Knife



Extender Driver Bit



Soft Cloth or Blanket



Soft Wood Shim



**INSTRUCTIONS THAT, IF IGNORED COULD RESULT IN SERIOUS INJURY OR DEATH CAUSED BY INCORRECT HANDLING OR INSTALLATION OF THE PRODUCT. THESE INSTRUCTIONS MUST BE OBSERVED FOR SAFE INSTALLATION!**


LICENSED AND INSURED PROFESSIONAL CONTRACTOR IS REQUIRED TO INSTALL THIS PRODUCT INCLUDING ASSISTANCE OF A SECOND PERSON DURING INSTALLATION

No modifications to the product are allowed. Modifications of any types to the product will result in serious injuries or may cause death.


















**IMPORTANT:** Do not install the handle on to the glass door until the instruction tells you to do so. Never lift the glass using the handle. Failure to do so will result in serious personal injury and could cause damages to the glass.

Professional graded glass suction cups are highly recommended while handling extremely heavy glass. This product must be installed on a finished threshold and against finished walls only. This product is intended for residential use only.


# Exploded Diagram





## Parts List

①  x2	②  x1	③  x2	④  x2	⑤  x2	⑥  x1
⑦  x1	⑧  x2	⑨  x1	⑩  x1	⑪  x1	⑫  x2 ST4x16
⑬  x2	⑭  x1	⑮  4x30 x4	⑯  x1	⑰  x1	

# Product Size




 If the total height of the shower room changes, the wall holes should also change accordingly. The above dimensions are for reference only,




## Model Specific Preparation

No Out-of-Plumb Adjustment; Verify threshold and walls with a level



Threshold must be level

**3" minimum threshold**





**NOTE**

This model is reversible for right or left-hand door installation. The right-hand door installation is shown as an example throughout this manual. For the left-hand door installation, simply begin on the opposite wall and reverse the orientation of the steps shown.

# Step 1

a. Depending on the layout of your bathroom, determine which side the sliding door will be installed on. For the convenience of installation, first place the sliding door inside the shower room, and cover the bottom of the glass with paper to protect it.

b. Install the sealing strip ⑯ on the wall side of the fixed glass panel ⑰ .








# Step 2



a. Measure the height and mark the holes on the wall. Use a spirit level to ensure that the hole positions on both walls remain horizontal and aligned at the same height.

b. Drill holes and use expansion anchor screws to secure the wall components in the header fixing part ① to the wall.

c. Insert the locator ③ into both ends of the header ⑭ . Lock the fixing parts at both ends to fix the header onto the wall, and use a spirit level to recheck the level of the header.




If the total height of the shower room changes, the wall holes should also change accordingly.




## Step 3

Install the glass panel onto the header using the fixing parts 13 and lock it securely.



# Step 4


- a. Place the Guide Block ⑪ to the bottom edge of the Glass panel ⑥, mark down the predrilled position of the guide block. Now drill the hole with 3.2mm (Ø 1/8") drill bit to the threshold. Put the silicone to the hole and then put the Wall Anchor into the hole. Now secure the Guide Block to the threshold with ST4x16 screws



The guide slider should be installed in the center and not skewed

# Step 5

a. Put silicone sealant to the bottom of the Anti-Splash Threshold ⑩, secure the threshold in front of the Glass Door, and install water blocking strip decorative cover ⑨







# Step 6

a. Attach the rollers ④ to the glass door ⑥

Hang the Glass Door ⑥ back to the Upper Guide Rail ⑭ ,  
slide the bottom of the glass door into the slot of the Guide Block ⑪ .

Be careful that the glass door should not touch the metal part of the guide block.



# Step 7

a. Attach the Bumper Strip ② to the Glass Door ⑥ .

Attach the Side Anti-Water Strip ⑧ to the edge of the Stationary Glass ⑰ and the door ⑥ Use a razor knife to trim the Side Anti-Water Strip at the top to avoid interfering with the Upper Guide Rail ⑭.

b. Install the handle ⑦ to the Glass Door, make sure that clear gasket and busher will be between the glass and the metal parts of the handle.









Fig 5



# Step 8


## Horizontal adjustment of the door

- a: Use a 3/16" shim beneath the Glass Door when adjusting the level of the door so that the glass does not make contact with the guide block or threshold. The adjustment disks in the wheels are the same as the disks in the Glass-to-Rail Brackets and can be rotated to adjust the Glass Door to create a seal with the wall. The Safety Set Screw on both Roller Assembly MUST be re-tightened after installation to prevent the wheel bolt from becoming loose.
- b: To prevent the glass door from jumping off the track when closing too hard, After adjust panels level install the anti-jump blocks (5) .



## Step 9

### DO NOT USE THE ENCLOSURE FOR 24 HOURS AFTER SEALING



After testing the functionality of the shower door without any issues, caulk the fixed glass panel and the bottom square water barrier with silicone caulk to get better stability and waterproofing.

## Warning

1. We take no responsibility for any damages or injury occurred when attempting installation. Do so at your own risk.
2. This manual is just for information purposes only. Read this manual thoroughly or with the help of a professional before attempting installation. Due to its weight and fragility this may require more than one person to perform the installation safely. Time frame it should take: 1-2 hours.
3. Check whether the glass is intact and the accessories are complete at the first time after receiving the product. If you encounter any problems please feel free to contact us through Amazon, we will try our best to serve you.