


| U-BOLTS | | |
|---|---|--------------------------------|
| 1.5 inch legs | 1.75 inch legs | |
| UBHWD-UB-12 (Set of 12) UBHWD-UB-16 (Set of 16) Fits for Poles 1" and 1.5" Fits for Legs up to 1.5" diameter | UBHWD-1.75-UB-8 UBHWD-1.75-UB-12 UBHWD-1.75-16 Fits for Poles 1" and 1.5" Fits for Legs up to 1.75" | UBHWD-U-UB-12 UBHWD-U-UB-16 |

MEASURING TIP FOR U BOLT:

Measure the diameter of your trampoline leg and make sure that you have the right size u-bolt. Example: the trampoline legs measures 1.5", you need a U-bolt for 1.5". Our U-bolts fit for connecting poles which measures 1" or 1.5". (If you have 1.75" connector, these U-bolts won't fit.)




STEPS FOR CONNECTING POLES USING U BOLT


- Take the clamp and clasp the trampoline pole into the rounded end of the clamp. Make sure that the black rubber cap of the lower pole faces down.

This step is optional for the 1.5" U-bolts
(This is NOT an option for the bigger size U-bolts)


- If the pole fits too loosely, insert the green rounded piece before clamping the pole so clamp will tightly clasp the pole. If the pole is too thick and does not fit into the hole, remove the green rounded piece to create more space for the pole. You should then be able to clasp the trampoline pole into the clamp.




- Once the pole is securely inserted into the clamp, you should now insert the plastic bracket until you reach the pole.



- Be aware that the mark on the lower pole needs to align with the trampoline frame. If there is no line on the pole then please have it attached 18" below the frame.



- The set comes with 2 clamps per pole. One being attached 2" below frame, while the other being attached 2" above the end of the lower pole.



- After inserting the plastic bracket, clasp the leg into the clamp. Secure tightly with the steel brackets and nuts.

