



Bike Shed



1.a Lay the floor down in the desired position, check that the floor is level using a spirit level before proceeding.

1.b Each floor joist should be as near as possible supported along its full length to prevent the floor from dipping in the middle.


1.c Ensure 65mm nails are driven through the side and gable panel base rails, through the floor boards in a position where they will finally penetrate the floor joist.




Important

- The floor panel must be laid on a firm level base.
- The underside of this floor must be treated with a quality wood preserver.
- Before starting assembly, you may need to remove transport blocks (marked x) from the bottom of some panels.

1. Base




2.a Position one end gable panel on to one end of the floor panel.



2.b Offer up a side wall panel and secure this to the gable by using the 38mm nails through the sides in to the gables.

2.c Then use the coach screws provided, through the pre-drilled holes in the gable, from the outside.

2.d Place the second gable panel in position and secure this to the side panel, again using the coach screws provided.




Important
Check that the sides are at right angles to the gables and to the floor, then tighten all coach screws to secure the sides and the gables. (fig. 1)
The floor panel must be laid on a firm and level base.

2. Gables & Sides


3. Roof Boards

3.a Place the roof panels in position and secure these internally to each other with the 65mm nails provided. You may need someone to help you pull the two panels together before you can nail them.

3.b Nail the roof to the gables and side frame with 38mm and 65mm nails provided.



Troubleshoot:
If at this point the roof panels do not align correctly, the door does not open/close properly or the building looks twisted at all then it would suggest that the base is not correctly level. Therefore, one or more corners of the building may need adjusting so the base is square.



4. Roof Felt


Please be aware that certain sizes of building may need the roll of felt cutting in to more than two pieces.

4.a Roll out the mineral roofing felt along the lower part of one side of the roof. Allow sufficient overhang to fold down onto the roof framing (but not the underside of the roof).

4.b Use clout nails to tack along the top edge of felt into the roof boards. Repeat this process on the other side of the roof.

4.c On some wider sheds you may be provided extra felt to cover the ridge of the building. On smaller buildings (for example 7x5) there will be adequate felt without the need for the ridge piece as long as the felt has not been set too low.

Important:
The ridge piece should overlap the lower strips of felt equally on either side and leave approx 75mm of felt overhanging each end.




5. Bargeboards & Finials

Please be aware that the bargeboards may need cutting to size before installing.

5.a Fit the bargeboards to the roof panels, trapping the overhanging end of the felt in between to provide a weather seal.

5.b Secure the diamond finials over the top of the bargeboards.

Please note there are no bargeboards supplied for the lower edges of the roof.



6. Corner Strips

6.a Secure the corner strips at each corner of the shed with the 38mm nails provided.

Important:
Please be aware that these corner strips may need cutting to size.



Check List

- | | |
|---|---|
| <input type="checkbox"/> x1 Floor | <input type="checkbox"/> (Found In Polytube Pack) |
| <input type="checkbox"/> x2 Gables (triangular) | <input type="checkbox"/> x4 Bargeboards |
| <input type="checkbox"/> x2 Sides (rectangular) | <input type="checkbox"/> x2 Diamond Finials |
| <input type="checkbox"/> x2 Roof Panel | <input type="checkbox"/> x4 Corner Strips |
| <input type="checkbox"/> Roofing Felt | <input type="checkbox"/> Fixing Pack |

Treat your building annually: Although it may come with a factory basecoat you should treat your new garden building inside and out shortly after installation with a good quality water resistant treatment. This process should then be repeated annually with care taken to brush the treatment into all wooden components involved within the construction of the building, inside and out.

Ensure nothing is in contact with your building: Any overhanging tree or hedge growth poses a threat to your garden building and should be cut back at regular intervals. If a tree branch makes contact with your building it may pierce the roofing felt and encourage water ingress. You should also take care not to allow plants to grow too close to the walls of your building to prevent leaks.

Check and replace any damaged felt: If you do find any damage sustained to your roofing felt over time it is essential that you act upon this without delay. Should you discover a rip or tear in the felt it is recommended that this area be stripped from the roof and a new covering of high grade, heavy duty, mineral felt (which can be purchased online and/or at most retail DIY stores) be affixed immediately.

You should also ensure that your new building is covered on your household insurance policy, as we cannot be held responsible for damage caused by storms or vandalism.

For more help and advice on installing and maintaining your garden building please visit our comprehensive help centre at: www.tigersheds.com/helpcentre.asp