Easy-to-Follow Instructions

Tools you will need

Tape Measure

Tin Snips

## What comes in a GridMAX kit?

This kit is for a 100 sq ft room.

- (12) 4' wall molding covers
- (14) 4' main covers
- (28) 2' tee covers (You will have extra 2' tees once installed correctly.)

Existing metal wall angle

Wall Molding Cover

Slide on wall Molding Cover

Metal T-Bar

Slide long flange over the tip of the metal Tee

Metal T-Bar

Wall Molding Cover

Main & Tee Covers

2' x 2' Ceiling Panel & Grid System

Existing Metal Grid
GridMAX Wall Molding Caps
GridMAX 4' Main
GridMAX 2' Tee

Step 1 — INSTALL WALL MOLDING COVERS

Install the wall molding covers by sliding the cover over the existing metal wall angles. Continue to install the covers by abutting them end-to-end around the entire room. (**See Tip #1**)

Step 2 — INSTALL 4' MAIN COVERS

Install the 4' main covers over the existing metal grid by placing them parallel to each other every 24" on-center. The 4' main covers can be installed parallel in either direction. It is suggested that you place the 4' main covers over the existing metal mains.

Measure and cut your first 4' main cover so the notch is aligned over the first metal grid intersection. (**See Tip #2**) Install the 4' main cover by sliding the longer flange over the lip of the existing metal grid. Then simply slide your thumb down the middle or the opposite edge and snap the cover on. The remaining 4' main covers in that row will line up by simply abutting the end of the next 4' main cover to the end of the already installed 4' main cover. When each row is complete, cut the last 4' main cover so it ends at the wall bracket cover.

Step 3 — INSTALL THE 2' TEE COVERS

The 2' tee covers are installed perpendicular to the 4' main covers.

2' x 4' Ceiling Panel & Grid System

Existing Metal Grid
GridMAX Wall Molding Caps
GridMAX 4' Main
GridMAX 2' Tee

4' Main's butt here

Step 1 — INSTALL WALL MOLDING COVERS

Install the wall molding covers by sliding the cover over the existing metal wall angles. Continue to install the covers by abutting them end-to end-around the entire room. (**See Tip #1**)

Step 2 — INSTALL 4' MAIN COVERS

Install the 4' main covers over the existing metal grid by placing them parallel to each other every 48" on-center. The 4' main covers should be installed along the 4' side of the tile.

Measure and cut your first 4' main cover so the notch is aligned over the first metal grid intersection. (**See Tip #2**) Install the 4' main cover by sliding the longer flange over the lip of the existing metal grid. Then simply slide your thumb down the middle or the opposite edge and snap the cover on. The remaining 4' main covers in that row will line up by simply abutting the end of the next 4' main cover to the end of the already installed 4' main cover. When each row is complete, cut the last 4' main cover so it ends at the wall bracket cover.

Step 3 — INSTALL THE 2' TEE COVERS

The 2' tee covers are installed perpendicular to the 4' main covers.

INSTALLATION TIPS

TIP 1: At each room corner, measure the distance from the last cover to the inside corner and cut the wall molding cover at a 45° angle using a tin snips or a pair of scissors.

TIP 2: Starting at the wall, measure the length from the wall molding cover to the first intersection. Using the length, measure from the start of the notch towards the end and cut off the excess. (If the measurement is greater than 12" measure and cut from the second notch.)

TIP 3: When installing on a 2' x 4' grid system, every-other notch on the mains will fall onto the metal grid intersections.

For additional tips and information visit: acpideas.com