

ASSEMBLY INSTRUCTION

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present.

IMPORTANT : PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"

"DO NOT OVERTIGHT ANY HARDWARE"

WARNING : SMALL PARTS AND HARDWARE NOT FOR CHILDREN UNDER 3 YEARS. ADULT ASSEMBLY REQUIRED.

TABLE OF CONTENTS

HARDWARES LIST

PAGE 2

PARTS LIST

PAGE 2 - 3

PARTS' LOCATION

PAGE 4

ASSEMBLY STEPS


PAGE 5 - 7

ASSEMBLY COMPLETED


PAGE 7

ASSEMBLY TOOLS REQUIRED

1. Screwdriver (not provide)











Skip the power drill this time.




ASSEMBLY INSTRUCTION







HARDWARES LIST

ITEM	DESCRIPTION	DRAWING	QTY
A	JCBB SCREW M8 x 20MM		8 PCS
D	SPRING WASHER M6 x 13MM		22 PCS
E	FLAT WASHER M6 x 19MM		22 PCS
F	CSK C/B SCREW (M4 x 32MM)		8 PCS
G	M4 ALLEN KEY (65MM)		1 PC
H	M5 ALLEN KEY (65MM)		1 PC
I	JCBC SCREW M6 x 40MM (BLACK)		10 PCS
J	JCBB SCREW M6 x 45MM		12 PCS




PARTS LIST (BOX 1)

ITEM	DESCRIPTION	DRAWING	QTY
1	HEADBOARD		1 PC

ASSEMBLY INSTRUCTION


ITEM	DESCRIPTION	DRAWING	QTY
2	HEADBOARD SUPPORT LEG - RIGHT		1 PC
3	HEADBOARD SUPPORT LEG - LEFT		1 PC
5	FOOTBOARD		1 PC
6	FOOTBOARD SUPPORT LEG - RIGHT		1 PC
7	FOOTBOARD SUPPORT LEG - LEFT		1 PC
10	CENTRE SUPPORT LEG (WITH PLASTIC COVER)		4 PCS

PARTS LIST (BOX 2)

ITEM	DESCRIPTION	DRAWING	QTY
4	HEADBOARD AND FOOTBOARD SUPPORT (TOP)		2 PCS
8	SIDE RAIL		2 PCS
9	SLAT WITH NUT		4 PCS

ASSEMBLY INSTRUCTION

PARTS ' LOCATION




ASSEMBLY INSTRUCTION

ASSEMBLY STEPS


STEP 1

Turn (10) clockwise to connect to (9) as shown.

x 4




Take off this plastic cover before assembly




STEP 2

Insert 5 pieces (I),(D) and (E) to combine (1) and (4). Then Insert 6 pieces (J),(D) and (E) to combine the (2) and (3) to the (1) as shown.




Use (I)JCBC SCREW M6 x 40MM (BLACK) here.



ASSEMBLY INSTRUCTION


STEP 3

Insert 5 pieces (I),(D) and (E) to combine (5) and (4).Then Insert 6 pieces (J),(D) and (E) to combine the (6) and (7) to the (5) as shown.



STEP 4


Insert all the (A) to combine the (2),(3),(6),(7) and (8) as shown.




ASSEMBLY INSTRUCTION

STEP 5


Put all the (9) -(combined in step 1) on the wood of (8).Then insert the 8 pieces (F) to fix it.



STEP 6



Adjust leveling feet (10) to touch floor.



ASSEMBLY COMPLETED

** FOR ALL MODEL AND ALL SIZE BED

