


NOTE:

This brochure contains IMPORTANT safety info. Please read and keep for future reference.

MAINTAINANCE AND WARNING


- 1.Keep furniture away from heat sources.
- 2.Do not clean furniture with harsh cleaner or polishes.Do not use detergents,solvents,abrasives,spray packs or leather cleaner.
Use non-color mild soa with warm water to clean spills(Mix 1:10 soap to water).
- 3.Do not place furniture under direct sunlight,material will possibly fade over time.
- 4.Do not use on site dry cleaning machine.Children should not climb or jump on the furniture.
- 5.Do not write on furniture that is not protectedby a padded barrier.
- 6.Not for commercial use,only for residential use.



















Weight Limitation

150 LBS










EXPLOSIVE VIEW

















PARTS LIST

| | | | |
|---|---|--|---|
| <div>A</div> <div>x1</div> <div></div> | <div>B</div> <div>x1</div> <div></div> | <div>C</div> <div>x1</div> <div></div> | <div>D</div> <div>x1</div> <div></div> |
| <div>E</div> <div>x1</div> <div></div> | <div>F</div> <div>x1</div> <div></div> | <div>G</div> <div>x1</div> <div></div> | <div>H</div> <div>x1</div> <div></div> |
| <div>I</div> <div>x2</div> <div></div> | <div>J</div> <div>x1</div> <div></div> | <div>K</div> <div>x1</div> <div></div> | <div>L</div> <div>x1</div> <div></div> |
| <div>M</div> <div>x1</div> <div></div> | <div>N</div> <div>x3</div> <div></div> | <div>O</div> <div>x3</div> <div></div> | <div>P</div> <div>x2</div> <div></div> |



PARTS LIST

| | | | | | | | |
|---|----|--|----|---|----|---|----|
| Q | x1 | R | x2 | S | x1 | T | x1 |
|  | |  | |  | |  | |
| U | x1 | V | x1 | W | x1 | X | x4 |
|  | |  | |  | |  | |
| Y | x1 | | | | | | |
|  | | | | | | | |







HARDWARE LIST

| | | | | | | | | | | | |
|--|-----|--|----|---|-----|---|-----|---|----|---|----|
| #1 | x8 | #3 | x1 | #4 | x28 | #5 | x12 | #6 | x8 | #7 | x8 |
|  | |  | |  | |  | |  | |  | |
| ø1/4"*1-3/4" | | | | ø3*14mm | | | | | | ø5/32*3/4" | |
| #8 | x24 | #9 | x4 | #10 | x4 | #11 | x52 | #12 | x4 | #13 | x4 |
|  | |  | |  | |  | |  | |  | |
| ø8#*1" | | | | | | ø3.5*14mm | | | | | |
| #14 | x4 | #15 | x2 | | | | | | | | |
|  | |  | | | | | | | | | |
| ø3.5*35mm*7# | | | | | | | | | | | |

TOOL LIST

| | | | |
|---|----|---|----|
| #2 | x1 | #16 | x1 |
|  | |  | |
| M4 | | | |


HARDWARE SPARE LIST



| | | | | | | | | | | | |
|---|----|---|----|---|----|---|----|---|----|---|----|
| #4 | x2 | #8 | x2 | #11 | x5 | #5 | x1 | #1 | x1 | #7 | x1 |
|  | |  | |  | |  | |  | |  | |
| ø3*14mm | | ø8#*1" | | ø3.5*14mm | | | | ø1/4"*1-3/4" | | ø5/32*3/4" | |

ASSEMBLY INSTRUCTIONS

STEP-1

1. Attach leg (X/Y) to bottom panel (B) with bolt (#1), tight it with Allen wrench (#2).







| | | | |
|---|----|---|----|
| #1 | x8 | #2 | x1 |
|  | |  | |
| $\phi 1/4" \times 1-3/4"$ | | M4 | |

ASSEMBLY INSTRUCTIONS

STEP-2

1.Attach Magnet (#3) to front rail (C) with screw (#4), tight it with screwdriver (#16).




| | | | | | |
|--|----|---|----|---|----|
| #3 | x1 | #4 | x2 | #16 | x1 |
|  | |  | |  | |
| | | ø3*14mm | | | |

ASSEMBLY INSTRUCTIONS

STEP-3


1.Slide front rail (C) to middle left vertical panel (E) and middle right vertical panel (F).



ASSEMBLY INSTRUCTIONS

STEP-4

1. Attach left side panel (D) and right side panel (G) to preassemble unit at step 3, and tight it with Allen wrench (#2).





| | |
|----|----|
| #2 | x1 |
| | |
| M4 | |

ASSEMBLY INSTRUCTIONS

STEP-5

1. Attach bottom panel (B) to preassembly unit at step 4, and tight it with Allen wrench (#2).




| #2 | x1 |
|---|----|
|  | |
| M4 | |

ASSEMBLY INSTRUCTIONS

STEP-6


1. Attach top panel (A) to preassembly unit at step 5, and tight it with Allen wrench (#2).



ASSEMBLY INSTRUCTIONS

STEP-7

1.Attach back panel (H) to preassembly unit at step 6 with screw (#4), tight screw with screwdriver (#16).




| | |
|---------|-----|
| #4 | x26 |
| | |
| ø3*14mm | |

| | |
|-----|----|
| #16 | x1 |
| | |

ASSEMBLY INSTRUCTIONS

STEP-8

1. Insert shelf holder (#5) to preassemble unit at step 7, and attach adjustable shelf (I/J) to it.







| #5 | x12 |
|----|-----|
| | |
| | |


ASSEMBLY INSTRUCTIONS

STEP-9

1. Connect part (N&O) to part (K) using screw #8 and tighten it with screwdriver #16. Slide in the part (R) into the groove in part (N&O). make sure they are also in groove in part (K).



| | |
|---|----|
| #8 | x4 |
|  | |
| ø8#*1" | |


| | |
|---|----|
| #16 | x1 |
|  | |

ASSEMBLY INSTRUCTIONS


STEP-10





1. Connect part (N&O) to part (P) using screw #8 and tighten it with screwdriver #16.
2. Attach knob (#6) to drawer front left (K) with bolt (#7), Tight bolt with screwdriver (#16).

1:



2:






| | | | | | | | |
|---|----|---|----|---|----|---|----|
| #6 | x1 | #7 | x1 | #8 | x4 | #16 | x1 |
|  | |  | |  | |  | |
| | | ø5/32*3/4" | | ø8#*1" | | | |

ASSEMBLY INSTRUCTIONS

STEP-11

1.Connect part (N&O) to part (M) using screw #8 and tighten it with screwdriver #16.Slide in the part (R) into the groove in part (N&O). make sure they are also in groove in part (M).




| | | | |
|---|----|---|----|
| #8 | x4 | #16 | x1 |
|  | |  | |
| ø8#*1" | | | |

ASSEMBLY INSTRUCTIONS


STEP-12

- 1.Connect part (N&O) to part (P) using screw #8 and tighten it with screwdriver #16.
- 2.Attach konb (#6) to drawer front (M) with bolt(#7),Tight bolt with screwdriver (#16).

1:



2:







| | | | | | | | |
|----|----|------------|----|--------|----|-----|----|
| #6 | x1 | #7 | x1 | #8 | x4 | #16 | x1 |
| | | | | | | | |
| | | ø5/32*3/4" | | ø8#*1" | | | |

ASSEMBLY INSTRUCTIONS

STEP-13

1.Connect part (N&O) to part (L) using screw #8 and tighten it with screwdriver #16.Slide in the part (S) into the groove in part (N&O). make sure they are also in groove in part (L).




| | | | |
|---|----|---|----|
| #8 | x4 | #16 | x1 |
|  | |  | |
| ø8#*1" | | | |

ASSEMBLY INSTRUCTIONS

STEP-14


- 1.Connect part (N&O) to part (Q) using screw #8 and tighten it with screwdriver #16.
- 2.Attach konb (#6) to drawer front (L) with bolt(#7),Tight bolt with screwdriver (#16).





| | | | | | | | |
|----|----|------------|----|--------|----|-----|----|
| #6 | x2 | #7 | x2 | #8 | x4 | #16 | x1 |
| | | | | | | | |
| | | ø5/32*3/4" | | ø8#*1" | | | |

ASSEMBLY INSTRUCTIONS


STEP-15



Attention: When installing the drawer,slide the steel ball slide rail of side panel to the most front as picture show.




Schematic diagram of slide rail disassembly



ASSEMBLY INSTRUCTIONS

STEP-16

- 1.connect part #9 to part (T/W) with screw #11, tight screw with screwdriver #16.
- 2. connect part #6 to part (T/W) with screw #7, tight screw with screwdriver #16.




| | | | | | | | | | |
|----|----|------------|----|----|----|-----------|----|-----|----|
| #6 | x2 | #7 | x2 | #9 | x4 | #11 | x8 | #16 | x1 |
| | | | | | | | | | |
| | | ø5/32*3/4" | | | | ø3.5*14mm | | | |

ASSEMBLY INSTRUCTIONS

STEP-17


1. connect part #10 to part (U/V) with screw #11, tight screw with screwdriver #16.
2. connect part #6 to part (U/V) with screw #7, tight screw with screwdriver #16.



| | | | | | | | | | |
|----|----|------------|----|-----|----|-----------|----|-----|----|
| #6 | x2 | #7 | x2 | #10 | x4 | #11 | x8 | #16 | x1 |
| | | | | | | | | | |
| | | ø5/32*3/4" | | | | ø3.5*14mm | | | |

STEP-18


1. Attach left door (T) and right door (W) to preassembly unit at step 15 with screw (#11), tight screw with screwdriver (#16).



ASSEMBLY INSTRUCTIONS

STEP-19


1. Attach middle left door (U) and middle right door (V) to preassembly unit at step 18 with screw (#11), tight screw with screwdriver (#16).




ASSEMBLY INSTRUCTIONS

STEP-20


Concealed hinges are three-way adjustable:




Horizontal
by screw adjustment!




Concealed hinges are three-way adjustable:




In-and-out
by loosening the hinge arm
mounting screw or via cam
adjustment!




Concealed hinges are three-way adjustable:



Vertical via slots in
the mounting plate
or via cam
adjustment!



Hinge adjustment method







Video for door adjustment

ASSEMBLY INSTRUCTIONS





STEP-21

1.Attach bracket (#12) to preassembly unit at step 19, with screw (#11), and tight screw with screwdriver (#16).





| | | | | | |
|---|----|---|----|---|----|
| #11 | x4 | #12 | x2 | #16 | x1 |
|  | |  | |  | |
| ø3.5*14mm | | | | | |

ASSEMBLY INSTRUCTIONS


| | | | | | | | |
|---|----|---|----|---|----|---|----|
| #12 | x2 | #13 | x4 | #14 | x4 | #16 | x1 |
|  | |  | |  | |  | |
| | | | | Ø3.5*35mm*7# | | | |

STEP-22

1. Install the anti-collapse device.
2. Mark the position on the wall, that corresponds to the location of part (#12) on the Top panel (A); Drill and insert the expandable screw (#13) by hammer.
3. Assemble the part (#12) to the well. Align the hole in the part (#12) with the expandable screw (#13), use screw (#14) to attach it and tighten by screwdriver (#16)




ASSEMBLY INSTRUCTIONS



STEP-23

Let the plastic belt #15 pass through the both part #12 and pull tightly.



WARRANTY

1. We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed.
2. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive.
3. Replacement parts by purchasing them with our company if they are available.