













CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	TOP PANEL		1X
B	LEFT ASSEMBLY		1X
C	RIGHT ASSEMBLY		1X
D	DIVIDER		1X
E	SHELF		1X
F	FRAME		4X
G	BACK PANEL		1X
H	DRAWER FRONT		2X
I	DRAWER LEFT		2X
J	DRAWER RIGHT		2X
K	DRAWER BACK		2X
L	DRAWER BASE		2X













Model# CNS5001A
Product Dimensions: 42"W x 14"D x 31"H





WEIGHT CAPACITY :
TOP : 110 LBS
DRAWER : 30 LBS
SHELF : 40 LBS

WARNING: DO NOT OVER TORQUE
BOLTS/SCREWS

PIECE	DESCRIPTION	PICTURE	QUANTITY
1	1" ROUND HEAD SCREW	M4x25mm 	8X
2	1 1/4" FLAT HEAD SCREW	M3x32mm 	16X
3	3/4" FLAT HEAD SCREW	M3x19mm 	8X
4	5/8" FLAT HEAD SCREW	M3x16mm 	10X
5	CAMBOLT		19X
6	CAMLOCK		19X
7	MACHINE SCREW		2X
8	HANDLE		2X
9	WOODEN DOWEL		4X
10	WEDGE		10X



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 1 ATTACH CAMBOLTS TO TOP PANEL, LEFT AND RIGHT ASSEMBLIES AND FRAMES.</p>	<p>STEP 2 ATTACH FRAMES TO TOP PANEL USING 1" ROUND HEAD SCREWS.</p>



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 3 ATTACH DIVIDER TO UNIT USING CAMLOCKS.</p>	<p>STEP 4 ATTACH FRAMES TO UNIT USING CAMLOCKS.</p>



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 5 ATTACH LEFT ASSEMBLY TO UNIT USING CAMLOCKS.</p>	<p>STEP 6 SLIDE BACK PANEL INTO THE GROOVE OF UNIT.</p>



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

 <p>This diagram illustrates the process of attaching a shelf (labeled E) to the main unit. A camlock (labeled 9) is shown being inserted into a hole in the shelf, and a dowel (labeled 6) is shown being inserted into a hole in the unit's frame. The shelf is positioned horizontally across the unit.</p>	 <p>This diagram illustrates the process of attaching the right assembly (labeled C) to the main unit. A camlock (labeled 9) is shown being inserted into a hole in the right assembly, and a dowel (labeled 6) is shown being inserted into a hole in the unit's frame. The right assembly is positioned vertically on the right side of the unit.</p>
<p>STEP 7 ATTACH SHELF TO UNIT USING CAMLOCKS AND DOWELS.</p>	<p>STEP 8 ATTACH RIGHT ASSEMBLY TO UNIT USING CAMLOCKS AND DOWELS.</p>





PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 9 ATTACH WEDGES TO UNIT USING 5/8" FLAT HEAD SCREWS. ADJUST THE ADJUSTER THAT HAS ALREADY BEEN ASSEMBLED TO THE LEGS TO STABILIZE YOUR UNIT.</p>	<p>STEP 10 ATTACH HANDLE TO DRAWER FRONT USING MACHINE SCREWS. ATTACH DRAWER LEFT AND RIGHT TO DRAWER BACK USING 1 1/4" FLAT HEAD SCREWS. SLIDE DRAWER BASE INTO THE GROOVE. ATTACH DRAWER FRONT TO DRAWER LEFT AND RIGHT USING 1 1/4" FLAT HEAD SCREWS.</p>

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 11 LOOSEN SLIGHTLY THE SCREWS PRE-INSTALLED ON THE BACK OF THE DRAWER FRONTS.</p>	<p>STEP 12 INSERT THE DRAWER INTO THE UNIT, THEN ADJUST THE DRAWER FRONT PANEL LEFT OR RIGHT AND UP OR DOWN UNTIL THE DRAWER GAPS LOOK PROPORTIONAL.</p>
	
<p>STEP 13 PULL THE DRAWER OPEN SLOWLY AND RE-TIGHTEN THE SCREWS FROM STEP 11. MAKE SURE THE FRONT PANEL DOES NOT MOVE AND LOCK THE DRAWER FRONT PANEL INTO POSITION WITH 3/4" FLAT HEAD SCREWS.</p>	<p>STEP 14 SLIDE THE DRAWERS INTO UNIT.</p>