




# INSTALLATION & ASSEMBLY



**Tools required  
(not included)**



**2 people for assembly**

# Notes:

## 1. ASSEMBLY PREPARATION AND TIPS FOR ASSEMBLY

- 1). Remove all packaging materials, staples and packing straps from the carton.
- 2). Refer to Parts List and Hardware List, and ensure parts and hardware are correct before assembly. Contact customer service for missing parts.
- 3). Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent scratch and damage to parts.
- 4). Allow ample room for assembly and assemble the product near where the product will be placed.
- 5). During assembly, do not over-tighten any fittings as this may cause damage.
- 6). Always place the product on a flat, level surface.

## 2. CARE AND MAINTENANCE

- 1). KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
- 2). Wipe clean with a soft, dry cloth; avoid the use of harsh chemicals or household cleaners as they may damage the exterior finish of the furniture.
- 3). Hardware may loosen over time. Periodically, check that all connections are tight; re-tighten as necessary.

## 3. TIPS TO PROTECT & CARE FOR YOUR FURNITURE

- 1). Avoid placing your furniture in direct sunlight, as sunlight causes fading.
- 2). Use a protective pad when writing on the furniture surface.
- 3). Use cutting boards and trivets for food preparation in order to avoid damaging the top for the unit.

### **WARNING**




Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install the provided tray.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place the heaviest items in the lowest drawers.




This is a permanent label.  
Do not remove!



















# 2-Person Assembly



















# ASSEMBLY OVERVIEW




# PART LIST

<p>① X1 PCS</p> 	<p>② X2 PCS</p> 	<p>③ X2 PCS</p> 	<p>④ X2 PCS</p> 	<p>⑤ X2 PCS</p> 
<p>⑥ X1 PCS</p> 	<p>⑦ X1 PCS</p> 	<p>⑧ X1 PCS</p> 	<p>⑨ X1 PCS</p> 	<p>⑩ X1 PCS</p> 
<p>⑪ X2 PCS</p> 	<p>⑫ X3 PCS</p> 	<p>⑬ X3 PCS</p> 	<p>⑭ X3 PCS</p> 	<p>⑮ X3 PCS</p> 
<p>⑯ X3 PCS</p> 	<p>⑰ X3 PCS</p> 	<p>⑱ X1 PCS</p> 		

# HARDWARE LIST

<p><b>A</b></p>  <p>29mm</p>	<p><b>B</b></p>  <p>Ø15*10mm</p>	<p><b>C</b></p>  <p>Ø6*30mm</p>	<p><b>D</b></p>  <p>M5*48mm</p>	<p><b>E</b></p>  <p>S3</p>
75 PCS (Extra 4)	75 PCS (Extra 4)	24 PCS (Extra 2)	22 PCS (Extra 2)	1 PCS
<p><b>F</b></p>  <p>12"</p>	<p><b>G</b></p>  <p>6*3.5*12mm</p>	<p><b>H</b></p> 	<p><b>I</b></p>  <p>L=572</p>	<p><b>J</b></p> 
3 PCS	26 PCS (Extra 2)	1 PCS	1 PCS	6 PCS (Extra 2)
<p><b>K</b></p>  <p>Ø20mm</p>	<p><b>L</b></p>  <p>Ø13*5mm</p>	<p><b>M</b></p> 	<p><b>N</b></p>  <p>Ø3*16mm</p>	<p><b>O</b></p> 
14 PCS (Extra 2)	4 PCS (Extra 1)	8 PCS (Extra 2)	8 PCS (Extra 2)	1 PCS
<p><b>P</b></p> 				
2 PCS				

# Instructions For Fastening CAM-BOLT and CAM-LOCK




CAM-BOLT




CAM-LOCK


Tools Required




## INSERTING AND TIGHTENING CAM-BOLT



Place Cam-bolt on pre-drilled hole and screw in vertically




Shoulder is flushed (on the same level) with the panel.



Shoulder is above the panel.

Place Cam-bolt on the designated pre-drilled holes on the panel. Use a Phillips Screwdriver to screw-in Cam-bolt vertically until shoulder is flushed (on the same level) with panel.

## INSERTING CAM-LOCK




Insert Cam-lock with arrow align to Cam-bolt head

CORRECT

WRONG



## TIGHTENING CAM-LOCK




Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.

Use a Flat-head Screwdriver to turn Camlock clockwise so it locks onto the head of the Cam-bolt. Turn until it is snug (about 3/4ths of a turn) -- over-tightening could damage Cam-lock or/and Cam-bolt.



### Step 1.





### Step 2.





Step 3.





Step 4.




Step 5.



Step 6.




Step 7.




Step 8.







B x10




0 x1








Step 9.

 A x7	 0 x1	 D x10	 E x1	
--	---	--	---	--





Step 10.



Step 11.


 <p>L x4</p>	 <p>C x4</p>	
---	---	--




Step 12.




B x10




0 x1



Step 13.




I x1




Step 14.





B x10




0 x1







Step 15.

			
<b>B x7</b>	<b>C x2</b>	<b>0 x1</b>	








Step 16.

 M x8	 N x8	 0 x1	
---	---	---	--





Step 17.



 H x1	 G x2	 O x1	 K x2	
--	---	---	---	--




Step 18.





Step 19.





Step 20.




Step 21.



Step 22.



Step 23.



End.

