


1、 Measure the flatness of the embedded box and vertical wall with parallel ruler.If the wall is not flat,you can fix it to make sure the angle between the vertical wall is mostly close to the ideal angle of 90 degrees in order to pave tiles.

2、 Remove the part of the embedded box which is above the tile wall




6

1、 Purpose: Flush the impurities and silt in the pipe in case of the blocking

2、 Open the protective plastic sheet and protective cover.Turn on the tap and Open up the supply valve rod to flush the pipe.Close the spool and test the pressure resistance and tightness to make sure there is no leakage.


3、 Blocked all outlets of pipes with plastic plugs(1/2) and turn on the tap. Check whether the connection port of the upper of the outlet pipe are tight and the status of pipeline pressure.Make sure there is no leakage.

4、 After the test of tightness,revert the protective plastic sheet and protective cover.




5

- 1、 If there is leakage after the spool has some wear and tear.Turn off the tap
- 2、 Remove the handle and panel in sequence.Remove the cover cup and the cover.Pick out the spool and the copper sleeve.
- 3、 Remove the two waterstop screws of the embedded box and mount the screws on the inlet of the pipe in order to stop the water and make sure the providing of water in the other room is normal.
- 4、 Replace it with a new spool and reinstall them in sequence.After that,it's complete.Here is the chart below



- 1、 Remove the protective plastic sheet and protective cover
- 2、 According to the following chart,connect the decoration panel and handle to the control valve.After this,it's complete.



8

7