








Assembly Instructions

Caution: You must read this before you proceed.





BARSTOOL



Parts List


Part NO.	Picture	Description	QTY
A		Chair Back	1
B		Right Leg Frame (Mark With FR)	1
C		Left Leg Frame (Mark With FL)	1
D		Short Support Rail	1
E		Middle Support Rail	1
F		Long Support Rail	1





Hardware






①		Screw(M7*35mm)	12
②		Allen Key	1
③		Wood Button	6
④		Foam Pad	4

Assembly Preparation

Before Beginning Assembly:




 X 12  X 6
  X 4


-  • Read instructions, cover to cover-
-  • Have 2 adults on hand for assembly-
-  • Do not assemble on flooring or carpet-
-  • Assemble on a clean non-marring surface (packing foam)-
-  • Save all packaging until finished-

Assembly Steps

Parts Introduction




Step 1




Step 1.1 Assemble Right Leg Frame (B) , Left Leg Frame (C) , Short Support Rail (D) , Middle Support Rail (E) , and Long Support Rail (F) together by using the Screw ① as shown. Step 1.2 Tighten Screw ① by Allen Key ②

Step 2



Attach the Right Leg Frame (B) , Left Leg Frame (C) to the chair back (A) . Secure it using Screw ① . Tighten it with Allen Key ② .

Step 3



Place the Barstool on a Level Surface to check if it wobbles.


Lift The Barstool some 30mm to 50mm high from the ground, keep your feet and toes well away from the drop zone, and drop the barstool freely and vertically with all four legs, hitting the ground at the same time.

This drop Test will help to ensure that all the Bolts and Gaps reach full alignment.

Test again for evenness on Level Surface.


If no wobbles are found, proceed to tighten all the Screws.

Step 4




Insert the wood button ③ into the leg support rail screw Hole.

Step 5



Adhere the Foam Pad ④ under the Legs.

Finish



Your Barstool is ready to use.
This Barstool can only be used on a flat, level surface.