

*Coca-Cola*®

Americana Cooler

*Cooluli*®



# AMERICANA 10LG USER MANUAL

K10LGA

# WARRANTY INFORMATION

## **1-YEAR LIMITED WARRANTY - REGISTER AT: [www.cooluli.com/register](http://www.cooluli.com/register)**

Read all the instructions before attempting to use this product.

This 1-year limited warranty applies to repair or replacement if product, at COOLULI's option, is found to be defective in material or workmanship.

1. This warranty only applies to personal, non-commercial use. This warranty is not applicable to any damage resulting from commercial, abusive, unreasonable use or supplemental damage. Defects that are the result of normal wear and tear will not be considered manufacturing defects under this warranty.

**COOLULI IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.**

2. This warranty does not cover damage resulting from any unauthorized attempts to repair or from any use not in accordance with the instruction manual.

3. This warranty applies only to the original purchaser of this product from the original date of purchase. This warranty applies only if the unit is purchased new from an authorized retailer and is non-transferable from the original purchaser of the item. Any warranties accompanied with this product is only valid in the country of purchase.

4. Unit is manufactured according to North American voltage specifications. Warranty is void if unit is plugged into a 220-230 volt outlet.

5. Please read the Instruction Manual carefully before setting up or using this product. If you believe this product to be suffering from a manufacturing fault, or if you have inquiries about this product, please contact Customer Support:

COOLULI  
ATTN: Customer Support  
217 E. Highland Pkwy  
Roselle, NJ 07203  
Phone: (718) 834-5312  
Email: [support@cooluli.com](mailto:support@cooluli.com)

When contacting Customer Support, please have the information below along with the proof of purchase. All warranty requests must be accompanied by proof of purchase, which is a copy of the original receipt/invoice.

Model: \_\_\_\_\_

Date of purchase: \_\_\_\_\_

Purchased from: \_\_\_\_\_

*Coca-Cola*

# Product Characteristics

- This thermo-electric cooler and warmer is a great way to keep food and drinks cool during the summer and warm during the winter. Perfect to use at home, in your office, or in your car during a long car ride. Wherever you are, you can always enjoy fresh food and drinks.
- Lightweight design allows for easy portability. Its sleek profile makes it a stylish choice for any décor or setting.
- Shelves are removable. To remove, gently push the shelf up and slide it out.
- Included AC and DC plugs make it ideal for outdoor and indoor use. This thermo-electric cooler/warmer unit is ultra-durable, eco-friendly and safe to use. Its semiconductor operation consumes minimal power and uses no compressors, cryogen, refrigerants or Freons.

## Applications

- At home, keep snacks and drinks at hand while enjoying your favorite shows and movies uninterrupted.
- Store on top of your office desk and use it as your own personal mini fridge.
- Great for picnics, camping and fishing trips when cold drinks and warm food are a necessity.
- Ideal for long road trips, and for commuters, and truck and taxi drivers who want to keep food and drinks fresh and close by.
- Perfect for parents who need to store breast milk at a desired temperature.
- Safely store medications that need to be kept at a specific temperature.

## Optimizing Performance

- Pre-chilled food and drinks are recommended to put into this unit. If drinks are at room temperature it will take 2-3 hours to chill them.
- This thermo-electric cooler and warmer is not designed to heat cold food; this unit only preserves hot foods at a warm temperature. However, this unit does have the ability to heat some foods that are semi-cool if given a minimum of 2 hours.
- With proper use, this thermo-electric cooler and warmer unit can preserve the temperature of food, warm or cold, for hours.

# How to Use the Cooler and Warmer

1. Before plugging in the cooler/warmer unit, make sure the switch on the back of the unit is set to the OFF setting. Then, insert the suitable power cord into the unit.
2. Insert the plug into a wall outlet or the appropriate cigarette-lighter outlet in a car/vehicle.  
If powering the cooler/warmer unit in a car/vehicle, the vehicle's engine must be turned on first.
3. For Cooling: Set the power switch to the COLD setting. A green light will turn on to indicate that the unit is in cooling mode.
4. For Warming: Set the power switch to the WARM setting. A red light will turn on to indicate that the unit is in warming mode.
5. This unit ONLY works on 100-120V (in compliance with North American standards).

## **For optimal 12-can storage of standard Coca-Cola cans (12 fl oz/355 mL):**

- Remove basket shelf on interior door
- Remove topmost interior shelf from unit by gently pushing the shelf up and sliding it out
- Refer to Fig.1 for suggested can configuration

Fig. 1

Can placement: overhead  
interior view of top shelf






Fig. 2

Can placement: interior, top and bottom shelf view



# Attachments

1. Plug the 120V AC power cord into the cooler/warmer.
2. Insert the other end of the 120V AC power cord into a standard wall outlet.
3. Set the cooler/warmer to the desired setting and enjoy your cold drinks or warm food anywhere in your home or office!



## While Using Car Power

1. Car engine must be on before plugging in the cooler/warmer. This precaution prevents a power surge that can lead to the unit overheating and/or becoming a potential fire risk.
2. Plug the 12V DC power cord into the DC port in the back of the device.
3. Plug the other end of the 12V DC power cord into the car/vehicle cigarette lighter.
4. Set the cooler/warmer unit to the desired setting and enjoy your cold drinks or warm food anywhere on the go!

## While Using Household Power

1. Plug the 120V AC power cord into the cooler/warmer.
2. Insert the other end of the 120V AC power cord into a standard wall outlet.
3. Set the cooler/warmer to the desired setting and enjoy your cold drinks or warm food anywhere in your home or office!

# WARNING

**PLEASE READ THESE DIRECTIONS CAREFULLY BEFORE USING THIS COOLER/WARMER UNIT TO ENSURE PROPER OPERATION. IMPROPER USE, INSTALLATION, ADJUSTMENT, ALTERATION, SERVICE OR MAINTENANCE CAN CAUSE INJURY OR PROPERTY DAMAGE.**

1. To ensure optimal performance, keep the cooler/warmer unit's fans clear of dirt and debris. Stuck fans will overheat the unit and can pose a potential fire hazard.
2. Do not place any cloth or paper products on the unit.
3. When plugging in the unit, ensure that the power cord is inserted tightly into the socket. A loose socket can cause damage or fire.
4. When using the unit in a car/vehicle with the DC power cord, the vehicle's engine must be turned on first. When the engine is running, the unit can then be plugged into the vehicle's adapter. This prevents a power surge and potential property damage, injury, and/or fire.
5. Keep the unit away from flammable items and running water to prevent damage, injury, and/or fire.
6. DO NOT attempt to open, break, or refit the appliance.
7. This unit ONLY works on 100-120V (in compliance with North American standards).
8. To switch temperature control, the unit must be turned to the OFF setting for 30 minutes before shifting the unit from COLD to WARM.
9. DO NOT submerge or rinse under running water.
10. When packing the unit, do not place upside-down.
11. Avoid dropping or banging the unit.
12. DO NOT leave the appliance in the rain.
13. Adult use and supervision only. This is not a toy. Children should not play with this cooler and warmer unit. For people with reduced physical, sensory, and/or mental capabilities, use precaution and follow all instructions when operating this unit to ensure safety.
14. Always keep ventilation openings clear of obstruction.
15. DO NOT use other electrical appliances inside the food storage compartments of the appliance.
16. If the power cord that is supplied with the cooler and warmer unit is damaged in any way—DO NOT attempt to repair it; damaged power cords must be replaced by the manufacturer.



Distributed by Cooluli®  
New York, NY 10950  
Made in PRC  
Cooluli™ is a trademark of  
LISSE USA LLC  
(718) 834-5312  
Copyright ©2018 all rights reserved