



USER'S MANUAL























Computer Desk
















BOARD IDENTIFICATION



Part List

	1	1PC
	2	1PC
	3	1PC
	4	2PC
	5	3PC
	6	1PC
	7	1PC
	8	1PC
	9	1PC
	10	1PC
	11	1PC
	12	1PC
	13	1PC
	14	1PC
	15	2PC
	16	2PC
	17	2PC
	18	2PC
	19	2PC
	20	1PC
	21	1PC
	22	3PC

Hardware List


	A	47PCS
	B	47PCS
	C	10PCS
	D	4PCS
	E	4PCS
	F	20PCS
	G	32PCS
	H	4PC
	I	4PC
	J	4PCS
	K	8PCS
	L	2PCS
	M	2PCS

REPLACEMENT PARTS

We are devoted to provide the best products and services for customers.

Please contact us via the "Contact Seller" button in the detail page of your order for any concern and we'll response as soon as possible.

STEP 1



Attach rail (H) to part (8) using 2 screw (G)s.


Attach rail (I) to part (9) using 2 screw (G)s.

Attach rail (I) to part (10) using 2 screw (G)s.


Repeat the above steps three times.

Attach rail (H) to part (9) using 2 screw (G)s.

Repeat the above steps three times.




STEP 2



Insert cam bolt (A) into part (9) with screwdriver.

Attach part (3, 4) to part (9) through bolt (A).


Insert and secure cam lock (B) to part (3, 4) to lock part (9).





Insert the cam bolt (A) into the part (9) at the same location on the other side.

Attach part (5) to part (9) through bolt (A).

Insert and secure cam lock (B) to part (5) to lock part (9).




STEP 3



Insert cam bolt (A) into part (8) with screwdriver.

Attach part (8) to part (3, 4) through bolt (A)


Insert and secure cam lock (B) to part (3, 4) to lock part (8).



Arrow on lock (B) should point in the direction of bolt (A).

Be careful not to over tighten.


STEP 4



Insert cam bolt (A) into part (10) with screwdriver.


Attach part (10) to part (5) through bolt (A).

Insert and secure cam lock (B) to part (5) to lock part (10).



Be careful not to over tighten.

STEP 5




Insert cam bolt (A) into part (2) with screwdriver.



Insert part (C) into part (9, 10).

Attach part (2) to part (9, 10) through bolt (A).


Insert and secure cam lock (B) to part (9, 10) to lock part (2).



STEP 6


 M6*35mm		 M6*25mm	
D	4PC	E	4PC

Attach metal (M) to metal (L) through bolt (D).
Attach metal base (L, M) to part (2) through bolt (E) .






STEP 7

Slide part (20) into grooves of part (9), part (10) and part (2) as per diagram.



STEP 8




Insert cam bolt (A) into part (1) with screwdriver.

Insert part (C) into part (8, 9, 10).


Attach part (1) to part (3, 8, 9, 10) through bolt (A, C).

Insert and secure cam lock (B) to part (3, 8, 9, 10) to lock part (1).



11

STEP 9



Attach part (16, 17) to part (13) using screw (F) with screwdriver.

Slide part (21) into grooves of part (13), part (16) and part (17) as per diagram.


Attach part (16, 17) to part (14) using screw (F) with screwdriver.

Slide part (22) into grooves of part (14), part (16) and part (17) as per diagram.





Attach part (18, 19) to part (15) using screw (F) with screwdriver.

Slide part (22) into grooves of part (15), part (18) and part (19) as per diagram.





Repeat the above steps two times.



12



STEP 10




Insert cam bolt (A) into part (6,7) with screwdriver.

Attach part (6,7) to part (16,17) through bolt (A).


Put part (21) in the slot of part (6), put part (22) in the slot of part (7).

Insert and secure cam lock (B) to part (16,17) to lock part (6,7).


Attach (J) to part (6,7) using screw (K)s.




STEP 11




Insert cam bolt (A) into part (11, 12) with screwdriver.
 Attach part (11, 12) to part (18, 19) through bolt (A).
 Put part (22) in the slot of part (11, 12).
 Insert and secure cam lock (B) to part (18,19) to lock part (11, 12).
 Attach (J) to part (11, 12) using screw (K)s.



STEP 12





Attach rail (I, H) at the bottom of drawers using screw (G) as per diagram.
 Repeat the above steps four times.



STEP 13

Place the assembled drawers into the slides.



Congratulations on successfully assembling your own computer desk!