


10' × 14' Metal Patio Gazebo

ASSEMBLY MANUAL



MODEL#: LGMF1597B

Missing part? Damaged? Contact us via email at

service@domioutdoorliving.com

www.domioutdoorliving.com

Pre-assembly



1. Two or more people are required for assembly.




2. You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Please use a Phillips screw driver.



6. For ease of construction, you may need a drill.



7. You may need a safety goggle.



8. Do not fully tighten screws prior to complete assembly.

Warning & Attention



-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;



-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

▲ Use bolts to secure the frame to the ground to against the strong wind.



1



If the deck is hard wood and the depth of it is over 3 inch, you can use **5/16 in. x4 in. Structural Wood Screw** to mount the gazebo.






2




If the ground is concreted and the depth of it is over 3 inch, you can use 1/4 inch expansion bolts to mount the gazebo

3



Or you can make a concrete footing for gazebo, **15×15×15 inches** is recommended. use expansion bolts to mount the pergola like (2) shows.

IMPORTANT:
Anchor is not recommended





A 4x Pole




C 2x Beam



C1 2x Beam



D 2x Beam




D1 2x Beam



E 4x Corner Roof Bar




E1 4x Corner Roof Bar Connector




E2 4x Roof Bar



F 4x Solidfying Bar




G 2x Solidfying Bar




G1 2x Solidfying Bar




H 2x Finishing Bar




H1 2x Finishing Bar




H2 2x Finishing Bar



J 2x Finishing Bar




J1 2x Finishing Bar



J2 2x Finishing Bar




K 2x Finishing Bar




K1 2x Finishing Bar




K2 2x Finishing Bar




K3 2x Finishing Bar




L1 2x Roof Panel



L2 2x Roof Panel




M1 2x Roof Panel




M2 2x Roof Panel




M3 2x Roof Panel




M4 2x Roof Panel




M5 2x Roof Panel




M6 2x Roof Panel



N1 2x Roof Panel




N2 4x Roof Panel




N3 2x Roof Panel



(P1) 2x Roof Panel




(P2) 2x Roof Panel




(P3) 2x Roof Panel




(P4) 4x Roof Panel




(P5) 2x Roof Panel




(P6) 2x Roof Panel




(P7) 2x Roof Panel




(P8) 2x Roof Panel



(Q) 2x Net Frame



(Q1) 2x Net Frame



(Q2) 2x Net Frame



(T) 2x Track



(T1) 2x Track



(T2) 2x Track




(T3) 2x Track




(B) 4x Base







(B1) 8x Bracket




(C2) 4x Union Bar



(R) 4x Corner Solidifying Bar


			
(R1) 4x Corner Solidifying Bar	(S) 1x Inside Roof Connector	(S1) 1x Outside Roof Connector	(S2) 3x J-Hook
			
(U) 4x Bracket	(U1) 4x Bracket	(U2) 4x Bracket	(U3) 4x Bracket
			
(V) 112x Hook	(W) 100x Black Rubber	(X) 4x Joint Cover	(X1) 4x Corner Cover
			
(X2) 6x Finishing End	(X3) 12x Finishing End	(Y) 4x Solid Sidewall	(Y1) 4x Mosquito Netting
			
(Z) 60x Plastic Bracket	(Z1) 4x Plastic Bracket	(Z2) 4x Plastic Bracket	(Z3) 2x Plastic Bracket
			
(Z4) 2x Plastic Bracket	(1) 1x S4	(2) 24x ST6.3x15	(3) 24x ST5x16
			
(4) 32x M6x35	(5) 104x M6	(7) 20x M6x10	(8) 204x M6x16
			
(9) 8x M6x25	(10) 72x M6x28	(12) 20x M6x50	



5

POST ASSEMBLY:

- (1) Attach 2 Part #B1 to Part #A with 4 Bolts #8.
- (2) Attach Part #B to Part #A with 3 Bolts #8.
- (3) Repeat the above procedures to assemble the other 3 Part #A.



A 4x



B 4x



B1 8x




1 1x




M6x16


8 28x




X4




C 2x




C1 2x




C2 2x



X 2x




1 1x






M6x16

8 20x

(1) Insert Part #C2 into Part #C1 and secure with 3 Bolts #8.




(2) Insert the other side of Part #C2 into Part #C and secure with 3 Bolts #8.



(4) Insert Part #X into the beam and secure with 1 Bolt #8.







(3) Connect Part #C1 and Part #C through Part #C2.




(5) Secure the bottom of Part #X and Part #C/C1 with 3 Bolts #8.

X2




(6) Repeat the above procedures to assemble the other Part #C and Part #C1.

-  **C2** 2x
-  **D** 2x
-  **D1** 2x
-  **X** 2x
-  **1** 1x
-  **8** 20x
- M6x16**
- 8**

(1) Insert Part #C2 into Part #D, and secure with 3 Bolts #8.




(2) Insert the other side of Part #C2 into Part #D1 and secure with 3 Bolts #8.



(4) Insert Part #X into the beam and secure with 1 Bolt #8.

(3) Connect Part #D and Part #D1 through Part #C2.







(5) Secure the bottom of Part #X and Part #D/D1 with 3 Bolts #8.

X2


(6) Repeat the above procedures to assemble the other Part #D and Part #D1.

TRACK ASSEMBLY:


(1) Slide the plastic hooks to the double-rail track #T & T1 (each slot should slide 6 plastic hooks).




(2) Repeat the above procedures for the another track #T & T1.



T2 2x




T3 2x



V 64x

(1) Slide the plastic hooks to the double-rail track #T2 & T3 (each slot should slide 8 plastic hooks).



(2) Repeat the above procedures for the another track #T2 & T3.

✓ S4

1 1x




M6x16

8 12x

(1) Use 6 Bolts #8 to fix the track T & T1 to the beam C & C1.

(2) Repeat the above procedures for another beam C & C1.



✓ S4


1 1x



M6x16

8 16x


(1) Use 8 Bolts #8 to fix the track T2 & T3 to the beam D & D1.
(2) Repeat the above procedures for another beam D & D1.



12





1 1x



M6x35

4 32x



(1) Connect Part #C/C1 and #D/D1 to Part #A with 8 Bolts #4.
(From Outside)

(2) Repeat the above procedures to assemble the other 3 corners.

▲ Please don't tighten all bolts.



S4


1 1x



M6x16





8 16x

(1) Connect Part #C/C1 and #D/D1 to Part #A with 4 Bolts #8.
(From Inside)





14

(2) Repeat the above procedures to assemble the other 3 corners.
▲ Please don't tighten all bolts.


-  **R** 4x
-  **R1** 4x
-  **S4**
- 1** 1x
-  **M6x16**
- 8** 32x

(1) Affix Part #R and Part #R1 to the frame with 8 Bolts #8.



(2) Repeat the above procedures to assemble the other 3 corners.

▲ Tighten All Bolts.





X1 4x



ST5x16



3 16x








(1) Cover the corner with Part #X1.

(2) Secure with 2 Self-tapping Screws #3. (from top to bottom)


(3) Secure with 2 Self-tapping Screws #3. (from bottom to top)




(4) Repeat the above procedures to assemble the other 3 corners.



Assemble the 4 Corner Roof Bars:




(1) Connect Part #E1 and Part #E with 2 Bolts #8 .



(2) Attach Part #U to Part #E with Bolt #8 .

(3) Repeat the above procedures to assemble the other 3 Corner Roof Bars.



S 1x



1 1x




M6x16

8 16x


Please have a freestanding ladder ready at the center of the gazebo.

(1) Place 4 Part #E1 on the 4 corners of Part #S.
Secure with 8 Bolts #8 (from bottom to top)

ATTENTION: You can also finish this step on the ground and then lift 4 corner roof bar and inside roof connector to the top together. (Need 2 people and 2 ladder)













Outside View




Outside View

(2) Place 4 Part #E on 4 Part #A; Secure with 8 Bolts #8.

-  **E2** 4x
-  **U1** 4x
-  **S4**
- 1** 1x
-  **M6x10**
- 7** 4x



(1) Attach Part #U1 to Part #E2 with Bolt #7 .
 (2) Repeat the above procedures to assemble the other 3 roof bars.



E2 2x




1 1x






M6x16

8 6x

(1) Place Part #E2 on Part #S.
Secure with Bolt #8 (from bottom to top).




Outside View



Inside View

(2) Connect Part #E2 and the Assembled Beam(D&D1) with part #U1.
Secure with 2 Bolts #8.

(3) Repeat the above procedures to assemble the opposite side.



E2 2x





1 1x





M6x16

8 6x

(1) Place Part #E2 on part #S. Secure with Bolt #8 (from bottom to top).




Outside View



Inside View

(2) Connect Part #E2 and the Assembled Beam(C&C1) with part #U1. Secure with 2 Bolts #8 .

(3) Repeat the above procedures to assemble the opposite side.





(S1) 1x




(S2) 3x


Secure Part #S2 to Part #S and Part #S1.
(From Bottom to Top)




ATTENTION: The holes of Part #S and Part #S1 need to be aligned on the same vertical line.




G 2x



G1 2x



U3 2x



1 1x




M6x10

7 2x




M6x16

8 4x




Inside View


- (1) Insert Part #U3 into Part #G and Part #G1.
- (2) Attach Part #G and Part #G1 to the Part #E2 with 1 Bolt #7 and 2 Bolts #8.
- (3) Repeat the above procedures to assemble the opposite side.




Outside View



F 4x



U3 2x



1 1x




M6x10

7 2x




M6x16

8 4x



Inside View


- (1) Insert Part #U3 into 2 Part #F.
- (2) Attach 2 Part #F to the Part #E2 with 1 Bolt #7 and 2 Blots #8.
- (3) Repeat the above procedures to assemble the opposite side.



Outside View



U2 4x






1 1x



M6x16


8 12x



(1) Insert Part #U2 into Part #F and Part #G1.


(2) Secure with 2 Bolts #8.

(3) Secure them to Part #E with Bolt #8.




25


(4) Repeat the above procedures to assemble the other 3 sides.




J1 2x




J2 2x



Q1 2x



Q2 2x



1 1x




5 8x



7 8x


26

(1) Connect Part #J1 and Part #Q1 with 2 Bolts #7 and 2 Nuts #5.




X2

(2) Connect Part #J2 and Part #Q2 with 2 Bolts #7 and 2 Nuts #5.




X2





ST6.3x15


2 2x




2



Inside View




(1) Place the Assembled J1 & Q1 and J2 & Q2 on Part #E2, securing with 1 Self-tapping Screw #2.





(2) Repeat the above procedures to assemble the opposite side.


(1) Connect Part #J and Part #Q with 2 Bolts #7 and 2 Nuts #5.




(2) Place the Assembled Part #J & #Q on Part #E2, securing with 1 Self-tapping Screw #2.




(3) Repeat the above procedures to assemble the opposite side.



J 2x



Q 2x



1 1x



5 4x



7 4x



2 2x




X3 4x




ST6.3x15

2 4x


(1) Place Part #J and Part #J1 on Part #E;
put on Part #X3 and secure with Self-tapping Screw #2.




Inside View




Inside View




(2) Repeat the above procedures to assemble the other 3 corners.



L1 2x



L2 2x



Z 4x






Z1 2x




Z2 2x




X2



Section View



X2




30


Attach Part #Z, #Z1 & #Z2 by lightly tapping with screwdriver.

Cover Part #Z to Roof Panels.


N1 2x






N2 4x




N3 2x




Z 8x



Section View




X2




X2

ATTENTION: The bigger roof panel need to cover the smaller one.




(1) Insert Part #N1 and Part #N2 into the frame.


(2) Insert Part #N3 and Part #N2 into the frame.



(3) Repeat the above procedures to assemble the opposite side.



H1 2x



H2 2x





X2 2x




ST6.3x15

2 2x

(1) Place Part #H1 and Part #H2 on Part #E2;
put on Part #X2 and secure with Self-tapping Screw #2.



(2) Repeat the above procedures to assemble the opposite side.






H 2x



ST6.3x15

2 2x

- (1) Insert Part #L1 into the frame.
- (2) Insert Part #L2 into the frame.



- (3) Attach Part #H to Part #E2, securing with Self-tapping Screw #2.

- (4) Repeat the above procedures to assemble the opposite side.




X3 4x




ST6.3x15

2 4x

(1) Place Part #H and Part #H2 on Part #E1;
put on Part #X3 and secure with Self-tapping Screw #2.












Outside View




(2) Repeat the above procedures to assemble the other 3 corners.


Cover Part #Z & #Z1 to Roof Panels

-  **P1** 2x
-  **P2** 2x
-  **P3** 2x
-  **P4** 4x
-  **P5** 2x
-  **Z** 12x
-  **Z1** 2x





P6 2x



P7 2x



P8 2x





Z 12x




Z2 2x




Cover Part #Z & #Z2 to Roof Panels




X2




▲ Part #W should be inserted between roof panels and solidifying bar or beams, then secure with bolts and nuts.





W 14x



1 1x




M6

5 14x



M6x28


10 12x




M6x50

12 2x

ATTENTION: The bigger roof panel need to cover the smaller one.




(1) Insert Part #P1, Part #P2 and Part #P3 into the frame.




(3) Place 1 Part #W between roof panels and solidifying bars.

Then secure with 1 Bolt #12 and 1 Nut #5.




Solidifying Bar




(2) Place 6 Part #W between roof panels and beams.

Then secure with 6 Bolts #10 and 6 Nuts #5.



Beam

(4) Repeat the above procedures to assemble the opposite side.



W 16x



1 1x



M6

5 16x



M6x28


10 14x




M6x50

12 2x


ATTENTION: The bigger roof panel need to cover the smaller one.




(1) Insert Part #P8, Part #P7 and Part #P6 into the frame.




(3) Place 1 Part #W between roof panels and solidifying bars. Then secure with 1 Bolt #12 and 1 Nut #5.



Solidifying Bar




(2) Place 7 Part #W between roof panels and beams. Then secure with 7 Bolts #10 and 7 Nuts #5.



Beam

(4) Repeat the above procedures to assemble the opposite side.

40



W 26x



1 1x




M6

5 26x



M6x28

10 18x





M6x50

12 8x


ATTENTION: The bigger roof panel need to cover the smaller one.

(1) Insert Part #P4 and Part #P5 into the frame.

(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5.




(2) Place 9 Part #W between roof panels and beams. Then secure with 9 Bolts #10 and 9 Nuts #5.




Beam


(4) Repeat the above procedures to assemble the opposite side.



W 4x




1 1x




M6x25

9 4x




(1) Place 2 Part #W between Part #P5 and Part #E2.
Then secure with 2 Bolts #9.

(2) Repeat the above procedures to assemble the opposite side.



W 20x



1 1x



M6

5 20x



M6x28


10 16x




M6x50

12 4x



ATTENTION: The bigger roof panel need to cover the smaller one.



(1) Insert Part #M1 and Part #M2 into the frame.




(2) Insert Part #M6 and Part #M5 into the frame.




(3) Place 8 Part #W between roof panels and beams. Then secure with 8 Bolts #10 and 8 Nuts #5.


(4) Place 2 Part #W between roof panels and solidifying bars. Then secure with 2 Bolts #12 and 2 Nuts #5.



(5) Repeat the above procedures to assemble the opposite side.



W 16x



1 1x




M6

5 16x



M6x28

10 12x




M6x50


12 4x

ATTENTION: The bigger roof panel need to cover the smaller one.


(1) Insert Part #M3 into the frame.



(3) Place 2 Part #W between roof panels and solidifying bars. Then secure with 2 Bolts #12 and 2 Nuts #5.




(2) Insert Part #M4 into the frame.




(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5.

(5) Repeat the above procedures to assemble the opposite side.



W 4x





1 1x




M6x25

9 4x


(1) Place 2 Part #W between roof panels and Part #E2. Then secure with 2 Bolts #9.



(2) Repeat the above procedures to assemble the opposite side.



K2 2x



K3 2x





X2 2x




ST6.3x15

2 2x




(1) Place Part #K2 and Part #K3 on Part #E2;
put on Part #X2 and secure with Self-tapping Screw #2.

(2) Repeat the above procedures to assemble the opposite side.



(K) 2x



(K1) 2x





(X2) 2x



ST6.3x15

(2) 2x

(1) Place Part #K and Part #K1 on Part #E2;
put on Part #X2 and secure with Self-tapping Screw #2.



(2) Repeat the above procedures to assemble the opposite side.




X3 4x



ST6.3x15

2 4x



(1) Place Part #K3 and Part #K on Part #E;
Put on Part #X3 and secure with Self-tapping Screw #2.


(2) Repeat the above procedures to assemble the other 3 corners.



ST5x16


3

8x








(1) Attach roof panels to finishing bars with 2 Self-tapping Screws #3.


(2) Repeat the above procedures to assemble the other 3 sides.



Y1 4x






Hang up Mosquito Sidewalls to Inside Track





Hang up Solid Sidewalls to **Outside Track**

Y 4x



Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and

friendly, easy-to-reach after-sales service. So if you

have any questions about our product and assembly,

please feel free to contact us. We will be here for you.

Support:



After-sales contact email:

service@domioutdoorliving.com

Please tell us your order ID when contact.

Attach photos of damaged part for instant reply.