




Listed Dimensions:
48" L x 20" W x 30" H

Front View



Top View

Suggested concrete pad 54" x 26"



IDEAL CONCEALING APPLICATIONS:

- Residential and Commercial Backflow Devices 2"
- External Water Pumps and Equipment
- Residential Utility Pedestals and Enclosures

Sample Interior Spacing

Height	Length	Width
6"	41"	10"
12"	34"	15"
24"	39"	6"
28"	36"	4"




Will Cover a 2" Reduced Pressure Backflow 36" in length at approximately 28" in height

<p>Insulation Pouch</p>	<p>Concrete Anchors</p>	<p>Heat Cables</p>	<p>Ventilation</p>
-------------------------	-------------------------	--------------------	--------------------

<p>6" Plastic Stakes included</p>		
-----------------------------------	--	--



DEKORRA ROCK COLOR OPTIONS:



ASSE STANDARD 1060 CLASSIFICATION

- Class I** Freeze protection. Class I and I-V shall have a minimum thermal resistance value of R-8 and a positive means of heat. have been designed and constructed to maintain a minimum internal temp. of 40°F.
- Class II** Freeze retardant. Class II and II-V shall have a minimum thermal resistance value of R-8. have been designed and constructed to be installed in minimum external temperatures of 33°F.
- Class III** Non Freeze protection. Class III and III-V are designed and constructed to provide system security for components when freezing temperatures are not a consideration.

INSTALLATION INSTRUCTIONS:

- If Class I-V Heat required, installations will require GFI protected power mounted at least 6" above all water discharge ports per local code regulations.
- Pour concrete pad per measurements provided or if mounting to ground, level area where enclosure is to be installed.
- If installation requires self regulated heat tape, install per instructions securing to piping and valve. Place insulated pouch over valve and piping assembly.
- Place rock over device. Verify that rock does not interfere with device. Insert included stakes for soil installation. For concrete installations see optional concrete installation instructions.

CONCRETE ANCHOR INSTALLATIONS

- Drill hole with same diameter as anchor of sufficient depth. Clean drilled hole of dust and debris.
- Place washer and nut onto threaded anchor as required.
- With nut, washer and set pin in place insert anchor through rock flange column and into concrete base.
- Using a proper size hammer set pin with several sharp and square strikes on head of pin until pin is flush with top of threaded anchor.

