

GAZEBO INSTALLATION MANUAL



SIZE 11x17

PARTS LIST

ITEM#	PART #	DESCRIPTION	QTY
1	WWRS-4884	Window Wall (Right Side) 48"	6
2	WWLS-4884	Window Wall (Left Side) 48"	5
3	WWCP-2484	Window Wall (Center Panel) 24"	2
4	DOOR-4884	Door 48"	1
5	CRNR-0202	Corner 2"x2"	4
6	HEEN-11875	End Header 118.75" (2 sections plus 1 joiner piece)	2 sets
7	HESI-19075	Side Header 190.75" (3 sections plus 2 joiner piece)	2 sets
8	CHIP-0080	Corner Hip 80"	4
9	SRAF-0585	Side Rafters 58.5"	10
10	CHUB-1117	Center Hub for 11x17 Gazebo	1
11	PRCO-5225	Corner Roof Panel, Right 52.25"	4
12	PLCO-5225	Corner Roof Panel, Left 52.25"	4
13	PCSQ-0215	Center Roof Panel 21.5"	2
14	PCSQ-0455	Center Roof Panel 45.5"	4
15	RCAP-1117	Roof Cap for 11x17 Gazebo	1
16	KNOB-0000	Door Knobs	2
17	BOLT-0000	Lag Bolts	4
18	SCRW-0015	Door Knob screws 1.5"	2
19	SCRW-0025	Screws 2.5"	250
20	SBIT-0000	Robertson Screw Bit	1

PARTS LIST

1

Window Wall
(Right Side)
48"



2

Window Wall
(Left Side)
48"



3

Window Wall
(Center Panel) 24"



4

Door 48"



5

Corner 2"x2"



PARTS LIST

6

End Header 118.75" (2 sections plus 1 joiner piece)



7

Side Header 190.75" (3 sections plus 2 joiner piece)



8

Corner Hip 80"



9

Side Rafters 58.5"



10

Center Hub
for 11x17
Gazebo



PARTS LIST

11

Corner Roof Panel, Right
52.25"



12

Corner Roof Panel, Left
52.25"



13

Center Roof Panel
21.5"



14

Center Roof Panel 45.5"



15

Roof Cap for
11x17 Gazebo



16

Door Knobs



17

Lag Bolts



18

Door Knob screws 1.5"



19

Screws 2.5"



20

Robertson Screw Bit



INSTALLATION PROCEDURE


IMPORTANT: Please read the full instructions in entirety before starting assembly of the gazebo. The assembly of this gazebo requires you to provide a 1/2" socket wrench, a 6 foot step ladder, a cordless drill, and a minimum of 2 persons.



1. Ensure that the surface you will be installing the enclosure on is flat, smooth and level. Starting with a Corner and Window Wall (48") align them in an upright position. The inside edge of the Window Wall (48") should be flush with the end of the Corner. Secure the Corner to the Window Wall (48") with four 2.5" screws.



2. Align a Window Wall (48") at a 90 degree angle from the first Window Wall (48") and secure the Corner to the second Window Wall (48") with four 2.5" screws.



3. Align a Window Wall (24") next to the previous Window Wall (48") and secure with six 2.5" screws (more specifically, 2 screws side by side at the top; 2 screws side by side adjacent to the bottom of the window opening; 2 screws one at the top and one at the bottom of the wood skirt).



4. Align a Door (48") next to the previous Window Wall (24") and secure with six 2.5" screws. Secure window walls to one another as previously described with six 2.5" screws.

INSTALLATION PROCEDURE



5. Align and secure a Corner to the previous Door (48"). Make sure the inside edge of the Door (48") is flush with the end of the Corner. Secure the Corner to the Window Wall (48") with four 2.5" screws.



6. Align the next Window Wall (48") at a 90 degree angle from the Door. Secure the Corner to the Window Wall (48") with four 2.5" screws.



7. Align and attach three more Window Walls (48") to the previous Window Wall (48"). Secure window walls to one another as previously described with six 2.5" screws.



8. Align and attach a Corner to the last Window Wall (48") secure with four 2.5" screws. Then align and attach another Window Wall (48") at a 90 degree angle from the previous Window Wall (48"). Secure the Corner to this subsequent Window Wall (48") with four 2.5" screws.

INSTALLATION PROCEDURE



9. Align and attach a Window Wall (24") to the previous Window Wall (48"). Secure window walls to one another as previously described with six 2.5" screws.





10. Align and attach a Window Wall (48") to the previous Window Wall (24") secure window walls to one another as previously described with six 2.5" screws. Then align and attach a Corner the Window Wall (48") with four 2.5" screws.




11. Align a Window Wall (48") at a 90 degree angle from the previous Window Wall. Secure the Corner to this Window Wall (48") with four 2.5" screws. Then secure the final two Window Walls (48") in place to complete the assembly of the gazebo body.

INSTALLATION PROCEDURE



12. Assemble the End Headers. Each set of End Headers consist of three pieces. There are two 59 3/8" inch sections plus one joiner piece that is 48" in length. Connect the two sections to the joiner piece with eight 2.5" screws. Do this again for the second End Header. Once you have assembled the End Headers the full length of each assembled End Header should be 118 3/4" .



13. Assemble the Side Headers. Each set of End Headers consist of five pieces. There are two 71 3/8" inch sections, one 48" piece, plus two joiner pieces that are 29" in length. Connect the three sections with the joiner pieces with sixteen 2.5" screws. Do this again for the second Side Header. Once you have assembled the Side Headers the full length of each assembled Side Header should be 190 3/4" .




14. Align and attach the Corner Hips to the Side Headers and End Headers with the Lag Bolts. The Lag bolts should be only hand tight for now.



15. Raise the Center Hub and attach the Corner Hips to the Center Hub. Use one 2.5" screw on each Corner Hip.

INSTALLATION PROCEDURE



16. Once the Corner Hips are attached to the Center Hub you can proceed to tighten the Lag Bolts with a socket wrench. Make sure the top of the Header is flush with the bottom of the dado. Also, make sure the inside of the Header is flush with the inside block on the Corner Hip.



17. Place the Side Rafters in the slots along the Headers and attach the Side Rafters to the Center Hub. Make sure the edge of the Side Rafter is flush with the miter of the Center Hub. Use one 2.5" screw. Do not screw down the Side Rafters to the Headers at this time.



18. Insert Corner Roof Panels into the Roof Frame and secure the Corner Roof Panels to the Corner Hips. Do not secure the Corner Roof Panels to the Side Rafters at this time.

19. Once all the Corner Roof Panels are attached to the Corner Hips, insert the Center Roof Panels in place and secure the Center Roof Panels and the Corner Roof Panels to the Side Rafters. Use one 2.5" screw for each Roof Panel.

INSTALLATION PROCEDURE



20. Attach each Side Rafter to the Headers with one 2.5" screw.



21. Attach the Roof Cap to the top of the Side Rafters with one 2.5" screws per Side Rafter. And now the Roof should be completely assembled.



22. Lift the entire assembled roof (lifting needs 3 to 4 people) above the walls and slide the entire Roof onto the body of the gazebo and secure the Roof to the body of the gazebo by screwing along the perimeter. Use two 2.5" screws for each Window Wall (48").



23. Attach Door Knobs to the Doors with 1.5" screws.



24. The gazebo is now complete and ready to enjoy.