


# ASSEMBLY INSTRUCTION


## 30INCH BATH VANTINY (COMBO)






Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

**"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"**

  
\* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!  
\* Please assemble on a clean soft surface to avoid damage.



### Tools Required



(Not included)



(Not included)

**IMPORTANT:**

**PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY**

# PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!  
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

1. Note: This is not a clothing storage cabinet and it is not recommended to use it as a clothing storage cabinet.
2. All cabinets come with TRD, stainless steel or our "L-Bracket "when shipped.







# Before Installation

**Important – Please read these instructions fully before starting assembly**


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

## Cam Lock Assembly Instructions















	<p>Diagram A</p> <p>Insert Cam Bolt into hole as shown in diagram A.</p>
	<p>Diagram B</p> <p>Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.</p>
	<p>Diagram C</p> <p>Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.</p>
	<p>Connect the panels together.</p>
	<p>ARROW SIGN</p> <p>Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.</p>
	<p>To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i></p>

## Detail View - CABINET

















**Identifying the Hardware -Identify the hardware using the illustrations below.**






# Part List

1	 Front Top Bar - 1pc	2	 Top Side Panel (R) - 1pc
3	 Top Side Panel (L) - 1pc	4	 Mid Panel - 1pc
5	 Top Panel Rear - 1pc	6	 Bottom Panel Rear - 1pc
7	 Crossbar Front - 1pc	8	 Mid Panel - 1pc
9	 Bottom Side Panel (R) - 1pc	10	 Bottom Side Panel (L) - 1pc
11	 Bottom Frame - 1pc	12	 Cabinet Feet - 4pcs
13	 Door - 1pc	14	 Round Bar - 2pcs















## Part List

15		16	
	Left Panel of Door - 1pc		Right Panel of Door (R) - 1pc
17		18	
	Mid Panel of Door - 2pcs		Top Drawer Face - 1pc
19		20	
	Top Drawer Side Panel (L) - 1pc		Top Drawer Side Panel (R) - 1pc
21		22	
	Top Drawer Back Panel - 1pc		Top Drawer Bottom Panel - 2pcs
23		24	
	Mid Drawer Face - 1pc		Mid Drawer Back Panel - 1pc
25		26	
	Mid Drawer Side Panel (L) - 1pc		Mid Drawer Side Panel (R) - 1pc
27		28	
	Bottom Drawer Face - 1pc		Bottom Drawer Back Panel - 1pc

## Part List





<div data-bbox="199 342 252 383">29</div> <div data-bbox="389 367 558 521">  </div> <div data-bbox="225 528 753 577">Bottom Drawer Side Panel (L) - 1pc</div>	<div data-bbox="813 342 866 383">30</div> <div data-bbox="1034 358 1203 512">  </div> <div data-bbox="837 528 1366 577">Bottom Drawer Side Panel (R) - 1pc</div>
<div data-bbox="199 589 252 629">31</div> <div data-bbox="311 584 624 768">  </div> <div data-bbox="263 772 713 817">Bottom Drawer Bottom Panel - 1pc</div>	<div data-bbox="813 589 866 629">32</div> <div data-bbox="1008 627 1187 739">  </div> <div data-bbox="888 772 1315 817">Bottom Drawer Bottom Bar - 1pc</div>
<div data-bbox="199 831 252 871">33</div> <div data-bbox="360 846 612 999">  </div> <div data-bbox="418 1014 558 1059">Sink - 1pc</div>	


## Hardware List

<b>A</b>  <b>ø6x35mm</b>	<b>B</b>  <b>ø14.5x12mm</b>	<b>C</b>  <b>ø8xø4x32mm</b>
<b>Three in one bolts - 48pcs</b>	<b>Three in one lock - 48pcs</b>	<b>Round head screw - 16pcs</b>
<b>D</b>  <b>ø8xø4x25mm</b>	<b>E</b>  <b>ø13x1/4"x40mm</b>	<b>F</b>  <b>ø1/4"x16x1mm</b>
<b>Round head screw - 2pcs</b>	<b>Hex-Head bolts - 4pcs</b>	<b>Washer - 4pcs</b>
<b>G</b>  <b>4mm</b>	<b>H</b>  <b>ø24x24mm</b>	<b>I</b>  <b>ø5/32"x19mm</b>
<b>Allen key - 1pc</b>	<b>Handle - 5pcs</b>	<b>Handle screw - 3pcs</b>
<b>J</b>  <b>ø5/32"x32mm</b>	<b>K</b> 	<b>L</b>  <b>ø7xø3.5x15mm</b>
<b>Handle screw - 2pcs</b>	<b>Damping hinge - 2pcs</b>	<b>Flat head screw - 12pcs</b>
<b>M</b>  <b>ø8x30mm</b>	<b>N</b> 	
<b>Wood dowel - 44pcs</b>	<b>Anti fall hardware (1set)</b>	





## STEP: 1

A	E	F	M
			
4PCS	4PCS	4PCS	4PCS




## STEP: 2

B

4PCS






## STEP: 3

**A**



**4PCS**



## STEP: 4

**B**





**4PCS**


**C**




**4PCS**




## STEP: 5




**A**




**9PCS**




## STEP: 6



**A**



**11PCS**





## STEP: 7

**A**



**2PCS**



## STEP: 8

**B**



**2PCS**

**D**




**2PCS**


**M**





**1PC**




## STEP: 9







# STEP: 10





<b>B</b>		<b>M</b>	
<b>9PCS</b>		<b>8PCS</b>	




## STEP: 11

**A****8PCS**




# STEP: 12



B	K	L	M
			
8PCS	2PCS	4PCS	12PCS






## STEP: 13


H	I	L
		
1PC	1PC	8PCS




Use the screws to adjust up or down




Use the screws to permanent







Use the screws to adjust left or right




Use the screws to adjust in or out







## STEP: 14

C	H	I	J
			
8PCS	2PCS	1PC	1PC




## STEP: 15

C	H	J
		
8PCS	1PC	1PC




## STEP: 16




**A**



**10PCS**



## STEP: 17



**B**







**4PCS**


**M**




**2PCS**

## STEP: 18


B	H	I	M
			
6PCS	1PC	1PC	6PCS




## STEP: 19



## **STEP: 20**




Wall




## **STEP: 21**

Install the sink on the cabinet with glue.  
Let stand for 24 hours




\*Silicone glue is not included  
in the package to comply  
with safety regulations in  
certain shipping conditions.

## **STEP: 22**



# HINGE ADJUSTMENTS




## ① Sideways / Tilt adjustment

Turn the screw

**clockwise** to move the door further away from the side of the cabinet

**anticlockwise** to move the door closer to the side of the cabinet




## ② ④ Height adjustment

While supporting the weight of the door, turn the screws

**clockwise** to move the door up

**anticlockwise** to move the door down



## ③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

**clockwise** to decrease the gap between the door and the cabinet

**anticlockwise** to increase the gap between the door and the cabinet

