



Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.  
Make sure no parts are missing or damaged before assembly.


# BOARD IDENTIFICATION




① (120x40x1.5cm)X1




② (75.6x39.9x2.5cm)X1




③ (75.6x39.9x1.2cm)X1




④ (75.6x39.9x2.5cm)X1




⑤ (72.2x30.3x0.3cm)X2




⑥ (28.1x6x1.2cm)X4




⑦ (28.1x9.2x1.2cm)X1




⑧ (26.9x4.8x1.2cm)X2




⑨ (28.1x8x1.2cm)X2




⑩ (28.1x9.2x1.2cm)X1




⑪ (75.6x39.9x1.2cm)X1




⑫ (58.8x40x1.2cm)X1




⑬ (35x14x1.2cm)X6




⑭ (35x14x1.2cm)X6




⑮ (22.7x26.3x1.5cm)X6




⑯ (22x14x1.2cm)X6




⑰ (23x34.7x0.3cm)X6




⑱ (35x9.7x1.2cm)X1




⑲ (35x9.7x1.2cm)X1




⑳ (15.9x58x1.5cm)X1




㉑ (53.7x9.7x1.2cm)X1




㉒ (54.7x34.7x0.3cm)X1




㉓ (33.7x6x1.2cm)X1




㉔ (58.9x12x1.2cm)X1




②⑤ (58.9x12x1.2cm)X1




②⑥ (58.8x38.7x1.2cm)X1




②⑦ (58.6x16.5x1.2cm)X1




②⑧ (58.6x8x1.2cm)X1




②⑨ (58.6x11.7x1.2cm)X1




③⑩ (58.8x38.7x1.2cm)X1




③① (30.7x10.6x1.2cm)X2























③② (30.7x10.6x1.2cm)X2



③③ (105x25x0.4cm)X1







# HARDWARE PART LIST


<p>(A) X97+3</p>		<p>(B) X97+3</p>		<p>(C) X36+3</p>		<p>(D) X98+3</p>	
<p>Ø15*9.5</p>		<p>Ø6.5*35</p>		<p>Ø6*30</p>		<p>Ø3.5*12</p>	
<p>(E) X14+2</p>		<p>(F) X52+3</p>		<p>(G) X20+2</p>		<p>(H) X2+1</p>	
<p>Ø3*12</p>		<p>Ø4*35</p>		<p>Ø3*14</p>		<p>Ø4*12</p>	
<p>(I) X6</p>		<p>(J) X7</p>		<p>(K) X1</p>		<p>(L) X7</p>	
<p>45*12</p>		<p>120*38*17</p>		<p>109*99*38.5</p>		<p>CL L=350</p>	
<p>(L) X7</p>		<p>(L) X7</p>		<p>(L) X7</p>		<p>(M) X1</p>	
<p>CR L=350</p>		<p>DL L=350</p>		<p>DR L=350</p>		<p>145*55*45</p>	
<p>(N) X20+2</p>		<p>(O) X1</p>		<p>(P) X10</p>		<p>(Q) X1set</p>	
<p>Ø21</p>		<p>70*30*5</p>					


# Cam Lock Fastening System


Insert the cam bolt into the hole first, then insert the cam lock and lock it.





# STEP 1




(D)	X18
	
Ø3.5*12	





(L)	X3
	
CL	
L=350	

(L)	X3
	
CR	
L=350	





# STEP 2


(B)	X18
	
Ø6.5*35	





# STEP 3




(D)	X12
	
Ø3.5*12	


(L)	X1
	
CL L=350	


(L)	X3
	
CR L=350	






# STEP 4






(D)	X12
	
Ø3.5*12	

(L)	X3
	
CL	
L=350	


(L)	X1
	
CR	
L=350	



**FLIP OVER**








LEFT CABINET MEMBER










RIGHT CABINET MEMBER

# STEP 5


(B)	X18
	
Ø6.5*35	



# STEP 6






Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

# STEP 7


(A)	X18
	
Ø15*9.5	





Insert the cam bolt into the hole first, then insert the cam lock and lock it.




# STEP 8

(A)	X18
	
Ø15*9.5	







Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

# STEP 9



# STEP 10






<b>A</b>	X4
ø15*9.5	


<b>B</b>	X9
ø6.5*35	

<b>C</b>	X2
ø6*30	






<b>N</b>	X4
ø21	




Insert the cam bolt into the hole first, then insert the cam lock and lock it.




# STEP 11



Insert the cam bolt into the hole first, then insert the cam lock and lock it.



# STEP 12





<b>A</b>	X4
$\phi 15 * 9.5$	



<b>B</b>	X9
$\phi 6.5 * 35$	

<b>C</b>	X2
$\phi 6 * 30$	

<b>N</b>	X4
$\phi 21$	








Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK


# STEP 13



**FLIP OVER**





Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK


# STEP 14




Ⓡ	X6
	
45*12	


Ⓔ	X12
	
∅3*12	


THIS STEP REQUIRES 2 PEOPLE





# STEP 15







(B)	X10
	
ø6.5*35	

(C)	X6
	
ø6*30	


(F)	X10
	
ø4*35	




# STEP 16







THIS STEP REQUIRES 2 PEOPLE




Insert the cam bolt into the hole first, then insert the cam lock and lock it.



# STEP 17







Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

# STEP 18





When installing the No. 5 plate, pay attention to the distance and direction of the round hole, the narrow distance is on it.





You can install the hair dryer rack(K) on the left or right according to your needs

# STEP 19





(E)	X2
	
Ø3*12	


(M)	X1
	





# STEP 20



<b>A</b>	X24
	
$\phi 15 * 9.5$	

<b>B</b>	X24
	
$\phi 6.5 * 35$	



<b>D</b>	X12
	
$\phi 3.5 * 12$	

<b>F</b>	X24
	
$\phi 4 * 35$	


<b>J</b>	X6
	
$120 * 38 * 17$	






Step 1



Step 2



Step 3




Proper orientation of CAM LOCK

Insert the cam bolt into the hole first, then insert the cam lock and lock it.

**X6**

# STEP 21




<b>A</b>	X5
Ø15*9.5	

<b>B</b>	X5
Ø6.5*35	


<b>D</b>	X2
Ø3.5*12	

<b>F</b>	X6
Ø4*35	


<b>J</b>	X1
120*38*17	




Step 1






FLIP OVER



Step 2




Step 3





Proper orientation of CAM LOCK


Insert the cam bolt into the hole first, then insert the cam lock and lock it.


# STEP 22



(D)	X36
	
Ø3.5*12	


(L)	X6
	
L=350	


(L)	X6
	
L=350	





X6


# STEP 23






(D)	X6
	
Ø3.5*12	

(L)	X1
	
L=350	

(L)	X1
	
L=350	




# STEP 24




# STEP 25

Pass the bulb wire through the pre punched plate, then gently press the bulb and make it adhere to the plate, and then connect the adjacent bulbs successively through the wire head slot on the opposite side (corresponding to the line of the same color).





# STEP 26

Put the Glass "33" in the slot reserved for the panel.




# STEP 27




⚠ WARNING	
	<b>Children have died from furniture tipover. To reduce the risk of furniture tipover:</b> <ul style="list-style-type: none"><li>• ALWAYS install tipover restraint provided.</li><li>• NEVER put a TV on this product.</li><li>• NEVER allow children to stand, climb or hang on drawers, doors, or shelves.</li><li>• NEVER open more than one drawer at a time.</li><li>• Place heaviest items in the lowest drawers.</li></ul> <p><i>This is a permanent label. Do not remove!</i></p>
	


## Install the tipping restraint hardware




1. make mark on the wall




2. drill two Ø6 holes on the wall



3. put two anchors in the holes



4. fix the device on the wall by the long screws



5. Push the cabinet close to the wall so that the two bases are close to each other, and then put on nylon tie to tighten it.

