



---

## Elevated Planter Box

### Installation Guide

---

### Thank You!

You're only a few steps away from your perfect vegetable garden or elevated planter. We hope you enjoy!

Model# E281719 / E281719G  
Dimensions 17" L x 19" W x 28" H

### Before You Start

Please read the instructions carefully to familiarize yourself with every detail and step involved. Keep this manual for future reference. Find a suitable space to assemble your new Elevated Planter Box.

You need at least 18" x 20" (46 x 51cm) for the finished product. A flat and firm area (like a garage floor or flat yard space) is perfect! The only tool you may need is a rubber mallet.

### Important Notes

Small parts are included; we advise you to keep them away from children and pets.

We also suggest having another person help you assemble. Maximum Load Capacity: approximately 2.8 cu. ft. of soil

★ [Subscribe at www.everbloom-garden.com](http://www.everbloom-garden.com)  
for extra savings and upgrading information!



**Everbloom-Garden.com**

Questions or Comments?  
Email us at [service@everbloom-garden.com](mailto:service@everbloom-garden.com)

# Parts List

Elevated Planter Box - 17" L x 19" W x 28" H

Left Corner  
Post  
X 2

Top



Bottom


Right Corner  
Post  
X 2

Top



Bottom

Short  
Board A  
X 4




420mm

Short  
Board B  
X 4




420mm

Bottom  
Board  
X 2



460mm

Post Cap  
X 4



+ 2pc  
replacement

Garden Bed  
Liner  
X 1



# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

---

There are 2 different assembly methods providing 2 different planting depths: 10" (as shown in Image 1) and 7.5" (as shown in Image 2).

\* For deeper planting depth of 10", please follow steps from page 4.

\* For easier but shallower planting depth of 7.5", please go to page 10.

IMAGE 1

Depth 1 - 10" from page 4





IMAGE 2

Depth 2 - 7.5" from page 10



# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H


Start by making sure each corner post is oriented correctly, as shown in Image 3. Slide one short board B into the corner brackets from above.

Note: The short boards need to be placed in the inward "U" shape of the brackets, as shown in Image 4.

IMAGE 3



IMAGE 4




# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

---

Slide another short board B into the other two corner brackets from above, as shown in Image 5.

IMAGE 5




# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

With the help of another person holding the 2 assembled parts, slide another two short boards B into the brackets from above. Make sure that one short board B goes straight to the bottom, while the other one stays in the middle of the way (don't push to the bottom), with the top edge between the 2nd and 3rd holes of the post.

IMAGE 6




# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

---

Put the bottom boards on lower slots of short boards B. Make sure the 2 ends of these bottom boards go into the lower slots and rest in them with enough contact as shown in Image 7. Adjust the height of the higher short board B slightly to hold these bottom boards if necessary.

IMAGE 7




# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

---

Push down the higher short board B to the bottom, as shown in Image 8.

IMAGE 8




# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

---

Slide the remaining boards into place, as shown in Image 9. Now you get an elevated planter box with 10" planting depth. Then, go to page 15, and follow the steps afterwards.

IMAGE 9



# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

Start by making sure each corner post is oriented correctly, as shown in Image 3a. Slide one short board B into the corner brackets from above.


Note: The short boards need to be placed in the inward "U" shape of the brackets, as shown in Image 4a.

IMAGE 3a

Top



IMAGE 4a




# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

---

Slide another short board B into the other two corner brackets from above, as shown in Image 5a.

IMAGE 5a




# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

---

With the help of another person holding the 2 assembled parts, slide the other two short boards B into the brackets from above, as shown in Image 6a.

IMAGE 6a




# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

---

Put the bottom boards on the long support boards, as shown in Image 7a.

IMAGE 7a




# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

---

Slide the remaining boards into place, as shown in Image 8a. Now you get an elevated planter box with 7.5" planting depth.

IMAGE 8a




# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

If necessary, use your rubber mallet to ensure the boards are tightly in place. Cover the brackets with the 4 end caps, as shown in Image 10.

IMAGE 10



# Assembly

## Elevated Planter Box - 17" L x 19" W x 28" H

For additional stability, we highly suggest using the included 8 self-tapping screws with washers (Image 11). Fasten 2 screws into each side of the inward facing corner posts using a #2 Phillips screwdriver (not included), as shown in Image 12.

Screws also can be fastened from outside, as shown in Image 13.  
Do not fasten the screws into the same height holes facing to each other on the same post.

IMAGE 11




IMAGE 12






IMAGE 13



# Assembly

Elevated Planter Box - 17" L x 19" W x 28" H

---

Unfold the liner and cover the bottom of the garden bed, as shown in Image 14 and Image 15.

IMAGE 14





IMAGE 15



# Note

Elevated Planter Box - 17" L x 19" W x 28" H

---

Sometimes there might be a misalignment of the Corner Posts as shown in Image 16 and Image 17, which may result in difficulty of sliding boards into the brackets. Please adjust them to the right position so that they are parallel to each other, and perpendicular to the ground.

IMAGE 16

Assembling Problem 1





IMAGE 17

Assembling Problem 2



# Bloom On.

**Everbloom-Garden.com**

US Patent Pending

★ Subscribe at [www.everbloom-garden.com](http://www.everbloom-garden.com) for  
extra savings and upgrading information!

Distributed by:  
Dynaforge Trading LLC  
St. Paul, MN55101  
Email: [service@everbloom-garden.com](mailto:service@everbloom-garden.com)

# 4PK 2" Caster Wheels

## Installation Guide

Parts Includes:

- 1. 2" Swivel Caster Wheel .....x 4
- 2. Stainless Steel Bolt ..... x 4
- 3. Stainless Steel Nylon Lock Nut .....x 4
- 4. 5mm hex key .....x 1
- 5. 13mm nut driver .....x 1


### Installation 1

Install on Everbloom


**E281719 Elevated Planter Box**

**E283612 Elevated Trough Planter Box**

Before installation the wheels, carefully flip over the garden bed so that it lays flat with the long side facing towards the sky.



1. Insert the wheel



Pay attention to the direction of wheel and the corner post.

2. Insert the bolt, Be sure it goes through the support bracket inside the post



3. Turn on the nylon lock nut and tighten them with hex key and nut driver



4. Install the lower wheel



5. Assemble the remaining wheels using the same method. Attn: The direction of each wheel aligns with the corner posts.



6. After installing all wheels, carefully flip over the Planter Box. Then, you get a mobile planter box.

### Installation 2

Install on Everbloom

**E213612 Deep Trough Planter Box /**

**E211719 Corner Stone Planter Box /**

**E144519 Deskside Planter Box /**

**E143612 Trough Planter**

Before installation the wheels, carefully flip over the garden bed so that it lays flat with the long side (or short side of post) pointing towards the sky.



1. Remove bolts and nuts on the post bracket with hex key and nut driver and take out one support bracket, as shown in Pic. 1a and Pic.1b.

Note:

Please pay attention to the position of the support bracket that need to be taken out.



2. Insert the wheel



3. Insert the bolt



4. Turn on the nylon lock nut and fasten it



5. Insert another bolt in the pack from side to side. Turn on the nut and fasten it. Be sure it goes through the support brack inside the post.



6. Take off the bolts and nuts on post brackets on the other side, and insert the wheel. Fix it with bolts and nuts.



7. Flip over the garden bed, then install another two wheels following the steps above.



8. Flip over the bed again so it stands upright

