

Specifications

DESCRIPTION

- Brass construction
- Thread: G1/2

FLOW




- Water usage is limited to these maximum flow rates as indicated by the corresponding product markings
- Tub spout: 6 gpm max@60psi;
- Handheld shower: 2.5 gpm max@60psi

CARTRIDGE

- Ceramic disk cartridge

STANDARDS

- Certified to CUPC
 - Certified to Ab1953
 - Certified to NSF/ANSI 61
- ADA for lever handle




Freestanding Bathtub Faucet

NOTE :THIS FAUCET IS DESIGNED TO
BE INSTALLED HOLE Ø2-3/4"MIN




Freestanding Bathtub Faucet Installation


INSTALLATION MANUAL Tools You Will Need :



Pipe tape



Adjustable wrench



Philips Screwdriver

Notes before installation :

1. Please check that all components are present.
2. Before installation ensure that all feed lines are clear of debris and on/off valve is present.
3. Ensure water pressure is between 20-125 PSI (includes combination of hot and cold feed lines).
4. Pictures in the manual are general in content and may not represent exactly your purchased faucet. If you are having difficulties please contact a professional plumber.
5. If you will be away from home for an extended period you should shut off the main water supply.

Daily maintenance

1. Use a soft cloth and vinegar to remove hard-water spots.
2. Check aerator (if present) regularly for calcium build up are when water stream is not optimum.
3. DO NOT use caustic cleaning products as the use will break down finish and will void the product warranty.
4. Acceptable cleaners include vinegar or mild non-abrasive liquid detergents.
5. If the water pressure appears to be less than optimum remove, inspect, clean or replace aerator.


(1) Put the cover onto the standing tube

(2) Tighten bracket onto standing tube, turn till tight

(3) Put the two waterlines through the bracket into standing tube

(4) tighten up the waterlines into main faucet by wrench and then connect them to (H) and (C)

(5) Scew the standing tube tighten to the main faucet.




(1) Drill 3 holes in corresponding positions on the floor


(2) Hammer the three bolts into the holes

(3) Connect the red waterline to hot water supply, blue waterline to cold water supply.

(4) put the bracket (with the faucet) onto the bolts, tighten up three screw nuts by wrench.



Connect the shower hose to main faucet and hand shower.



Double check the entire installation for any leaks and make sure the faucet is functioning. If ok, we can use it normally.

