
Hardware List


ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
Α	Cam Bolt	OT THE	34 pcs	Н	Magnetic Bar	0	2 pcs
В	Camlock		34 pcs	ı	Hinge		4 pcs
С	Wooden Dowel		32 pcs	J	Screw		5 pcs
D	Knob Bolt	Salara Caraca	2 pcs	K	Screw	3*12mm	18 pcs
Е	Knob	©	2 pcs	L	Fixed Button	পুত	4 pcs
F	Screw	3*14mm	4 pcs	М	Screw	3*16mm	4 pcs
G	Magnetic Catch		2pcs				


Parts List

ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
1	Top Panel		1 pc	7	Top Connect Bar		2 pcs
2	Shelf		1 pc	8	Upper Back Panel		1 pc
3	Bottom Panel		1 pc	9	Lower Back Panel		1 pc
4	Left Side Panel		1 pc	10	Left Door		1 pc
5	Divide Panel		1 pc	11	Right Door		1 pc
6	Right Side Panel		1 pc	12	Shelf and Bottom Connect Bar		2 pcs


Parts List Assembly Overview








STEP 3




STEP 4


- a) Screw in Cam-bolt (A) into designated holes on Left Side Panel (4).
- b) Insert Wood Dowel (C) into designated holes on Top Connect Bar (7).
- c) Attach (7) to (4) via Cam-bolts and Wood Dowels.
- d) Insert Cam-lock (B) into designated holes on (7) then turn clockwise to lock onto Cam-bolt. Do not overtighten.




STEP 5

- a) Screw in Cam-bolt (A) into designated holes on Right Side Panel (6).
- b) Insert Wood Dowel (C) into designated holes on (2, 3, 7 & 12).
- c) Attach (6) to (2, 3, 7 & 12) via Cam-bolts and Wood Dowels.
- d) Insert Cam-lock (B) into designated holes on (2, 3, 7 & 12) then turn clockwise to lock onto Cam-bolt. Do not overtighten.





STEP 7



STEP 8

