



EN_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.


USING CAM LOCK AND QUICKFIT




EN_QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.



















EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.









EN_Turn cam lock clockwise to tighten.

PACKING DELALS


NO.	PARTS	QTY	SPARE
①		x1	
②		x1	
③		x1	
④		x1	
⑤		x2	
⑥		x1	
⑦		x1	
⑧		x1	
⑨		x3	
⑩		x3	

NO.	PARTS	QTY	SPARE
⑪		x6	
⑫		x6	
⑬		x6	
⑭		x6	
⑮		x6	
	 Hardware Kit		





A x4





E x18

CL x3



CR x3

4 x1




H x2

I x2





I x2

6 x1




Note: Due to the sinking of the upper part of board 4 during installation with board 6, a plate from board 9 or 10 can be used as a cushion to prevent board 4 from sinking, as shown in the figure.



9 OR 10



horizontal plane



D x3



D






7 x1

8 x1



A x6







1 x1










A








Note: When standing up boards 4, 6, 7, and 8, at least two people are needed, with their hands supporting them 6. Plates 7 and 8, as shown in the figure.






















E x36

DL x6


DR x6





x3



x3





D x2




L x2




J x2




K x2




First fix the anti-rewind screw in the reserved hole of the product.




Then, put the expansion bolt into the hole



then, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.



Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.



Then use a tape drill to make holes in the wall that are suitable for the product screws.

