



# Assembly Instructions




# General Assembly Guidelines






- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The two main types of hardware used to assemble this product are: wood dowels and screws.
- V. A Phillips head screwdriver is required for the assembly of this product (not included)




# Parts List




# Hardware List

A		Ø 6x30mm	Wood Dowel	10pcs
B		Ø 5x14mm	Foot	6pcs
C		Ø 3,5x14mm	Screw	36pcs
D		Ø 6x8mm	Screw	24pcs
E		Ø M4x10mm	Screw	12pcs
F		Ø 6x35mm	Cam Bolt	40pcs
G		Ø 15mm	Cam Lock	50pcs
H		Ø 1,5x22mm	Nail	60pcs
I		Ø 30x20mm	Handle	12pcs
J		Ø 14x14mm	Back Support	12pcs
K			Wall Anchor	2pcs
L		H 732mm	Back Join	2pcs
M		350mm	Slider	6pcs
O		Ø 6x50mm	Wood Dowel	5pcs
P		400mm	Cam Bolt	5pcs


**STEP 1.** Secure cam bolts (F) into parts (1,2,3,9). Insert dowel (A) into part (5).




**STEP 2.** Attach sliders (M) to parts (1,2,4) using screw (D). Secure feet (B) to parts (1,2,4) using nail (H).




**STEP 3.** Insert panel (8) into the drawer frame (7) groove. Then attach part (9) to part (7) using cam lock (G).








**STEP 4.** Attach handle (I) using screw (E). Then attach sliders (M) to part (7) using screw (C). Insert support (J) in the bottom of part (7) and then secure using screw (C).




**STEP 5.** Secure parts (5) to part (2) using cam lock (G).




**STEP 6.** Secure part (4) to parts (5) using dowel (O), cam bolt (P) and cam lock (G).




**STEP 7.** Secure parts (5) to parts (1,4) using cam lock (G).




**STEP 8.** Secure part (3) to parts (1,2,4) using cam lock (G).



**STEP 9.** Join back panels (6) using back join (L). Attach back panels (6) to frame using nails (H).



**STEP 10.** Insert drawer into frame.



## WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

### - Assembly Instructions

Your furniture comes with a tipping restraint. Once attached to the furniture and to wall, it will help prevent the furniture from tipping over at small child attempt to climb on the furniture. It is recommended that the restraint be attached directly to a wood stud if possible. If this not possible, it is best to use the wall anchor included.


**Step 1** - Determine the location of your furniture. Find the center of the back edge of the top of your furniture, and once determined, mark it. Make a matching mark on the wall.

Attach the metal clip (D) exactly as shown in the diagram using screw (E).

**Step 2** - Attach the second metal clip (D) to the wall anchor (B) (if you can not use a wall stud) and schew (A) as shown.

**Step 3** - Once the clips are secure and tight, place the furniture with clips as close to the wall with clip. Then attach the cable tie (C) as shown, making sure it 'locks' and pulls together. If you wish, you can cut the top end of the tie to conceal this hardware.

As an additional safety measure, it is recommended to place all heavier items on the lower drawers of the furniture.



A	Wall Screw 4,5x35	01	B	Wall Plug ø 6MM	01
C	Strap	01	D	135° Bracket	02
E	Furniture Screw 4,0x20	01			