AUTO STORAGE SHELTER



Ideal for all purpose outdoor storage 10' x 20' x 8' (3 x 6.1 x 2.4 m)

ASSEMBLY MANUAL

Model NO.:103-1105N



Tools required for assembly (not included)















IMPORTANT SAFETY INSTRUCTIONS



WARNING!

- Read all safety instructions to reduce the risk of injury or death.
- This is a temporary structure and is not recommended as a permanent structure.
- Choose your shelter's location carefully. Check for overhead utility lines, branches, etc. DO NOT install near roofs or other structures that may shed snow, ice or excessive run-off onto your shelter. Keep away from electrical wires!
- Install your shelter on a level surface.
- Check municipal by-laws prior to setting up the product.
- Have an overview of all parts before attempting installation. Make sure all components are available.
- D0 NOT use this product in environments for which it is not intended (i.e. extreme cold, high winds, extreme heat, heavy rainfall, etc).
- Always wear safety glasses when assembling this product. Wear gloves when working with tubing to prevent cuts or abrasions.
- **Caution!** Anchors must be used with all shelters. Covers should NOT be installed on any product untill it has been properly anchored to the ground.





- Proper anchoring and keeping cover tight and free of snow and debris, is the responsibility of the consumer.

 Damages caused by improper anchoring are not covered under warranty.
- Warning! Keep all flame and heat sources away from the shelter fabric The fabric will burn if left in continuous contact with a flame source.
- DO NOT use open flames or cooking or heating devices inside or in close proximity to the product, including all types of stoves, gas heaters, gas lanterns, citronella torches, mosquito coils, etc.



- cook, smoke, refuel or use any open flame devices in or around the shelter.
- store flammable liquids (gasoline, kerosene, propane, etc.) in the shelter.
- operate gas powered vehicles/equipment in or around the shelter.
- Keep open flames a safe distance away from the shelter.
- DO NOT use hard-edged tools or instruments, such as rakes or shovels, to remove snow. These can cause punctures to the cover.
- NEVER start the engine of any vehicle or machine inside a closed shelter. Ensure that there is adequate ventilation for starting engines and for any work with paints, cleaners, etc.
- This shelter is NOT designed to support heavy snow or ice loads. Snow or ice accumulation may cause your shelter to collapse. To avoid overload, brush snow and ice off the roof top with a broom or mop.
- To prevent collapse, damage to property, personal injury and/or death, NEVER clear the roof of snow or debris from inside the shelter.
- DO NOT use bleach, alkaline or harsh detergents for cleaning. Doing so will damage the pe material. Soap and warm water are recommended.



INTENDED USE

This temporary shelter is intended to offer protection from damages caused by the sun, light rain, light snow, tree sap, bird and animal excrements. Do not use it to shield goods from high winds, heavy snow or ice storms. Only use it for its intended use.







1	Part#	Description	Drawing	Qty.
10	1	Leg Tube (Center Part)	0	6
4 Roof Horizontal Tube 5 Shoulder Horizontal Tube 6 Bottom Cross Rails 7 4-Way Peak Connector 8 3-Way Side Connector-Left 9 3-Way Side Connector Right 10 Bent Corner Leg 11 4-Way Peak Connector 12 3-Way Peak Connector 12 3-Way Peak Connector 13 4-Way Cross Rail Clamp 14 3-Way Cross Rail Clamp 15 15"Anchor 16 Cable-1'Lengths 17 Cable Clamps 18 Foot Plate 19 Pin Bolt 19 Pin Bolt 20 Open Pin 21 M6×45 Bolts 22 M6×40 Bolts 23 M6 Washer 24 M6 Lock Nuts 25 Roof Tarp 26 Door Panel with Zipper 27 Back Panel 28 Ratchet 29 Clasp 4	2	Leg Tube (Corner Part)	o	4
5 Shoulder Horizontal Tube 6 Bottom Cross Rails 7 4-Way Peak Connector 8 3-Way Side Connector-Left 9 3-Way Side Connector - Right 10 Bent Corner Leg 4 11 4-Way Peak Connector 12 3-Way Peak Connector 12 3-Way Peak Connector 13 4-Way Cross Rail Clamp 14 3-Way Cross Rail Clamp 15 15'Anchor 16 Cable-1'Lengths 17 Cable Clamps 18 Foot Plate 19 Pin Bolt 20 Open Pin 20 Open Pin 21 M6×45 Bolts 22 M6×40 Bolts 23 M6 Washer 24 M6 Lock Nuts 25 Roof Tarp 26 Door Panel with Zipper 27 Back Panel 28 Ratchet 29 Clasp 4	3	Rafter Tube	0	10
Section Cross Rails	4	Roof Horizontal Tube		4
7 4-Way Peak Connector 8 3-Way Side Connector-Left 9 3-Way Side Connector -Right 10 Bent Corner Leg 11 4-Way Peak Connector 12 3-Way Peak Connector 13 4-Way Cross Rail Clamp 14 3-Way Cross Rail Clamp 15 15'Anchor 4 4 16 Cable-1'Lengths 4 4 17 Cable Clamps 4 6 19 Pin Bolt 20 Open Pin 21 M6×45 Bolts 22 M6×40 Bolts 23 M6 Washer 24 M6 Lock Nuts 25 Roof Tarp 26 Door Panel with Zipper 27 Back Panel 28 Ratchet 29 Clasp	5	Shoulder Horizontal Tube	0	8
8 3-Way Side Connector-Left 9 3-Way Side Connector -Right 10 Bent Corner Leg 4 4 11 4-Way Peak Connector 12 3-Way Peak Connector 13 4-Way Cross Rail Clamp 14 3-Way Cross Rail Clamp 15 15"Anchor 16 Cable-1'Lengths 4 4 17 Cable Clamps 4 6 19 Pin Bolt 20 Open Pin 21 M6×45 Bolts 22 M6×40 Bolts 23 M6 Washer 24 M6 Lock Nuts 25 Roof Tarp 26 Door Panel with Zipper 27 Back Panel 28 Ratchet 29 Clasp	6	Bottom Cross Rails	0 0	8
9 3-Way Side Connector -Right 10 Bent Corner Leg 4 11 4-Way Peak Connector 12 3-Way Peak Connector 13 4-Way Cross Rail Clamp 14 3-Way Cross Rail Clamp 15 15"Anchor 16 Cable-1"Lengths 17 Cable Clamps 4 18 Foot Plate 19 Pin Bolt 20 Open Pin 21 M6×45 Bolts 22 M6×40 Bolts 23 M6 Washer 24 M6 Lock Nuts 25 Roof Tarp 26 Door Panel with Zipper 1 Back Panel 28 Ratchet 29 Clasp 4 4 4 4 4 4 4 4 4 4 4 4 4	7	4-Way Peak Connector		3
10 Bent Comer Leg	8	3-Way Side Connector-Left		2
11	9	3-Way Side Connector -Right		2
12 3-Way Peak Connector 2 13 4-Way Cross Rail Clamp 12 14 3-Way Cross Rail Clamp 8 15 15"Anchor 4 16 Cable-1"Lengths 4 17 Cable Clamps 4 18 Foot Plate 6 19 Pin Bolt 6 20 Open Pin 6 21 M6×45 Bolts 10 22 M6×40 Bolts 16 23 M6 Washer 0 24 M6 Lock Nuts 26 25 Roof Tarp 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	10	Bent Corner Leg		4
13 4-Way Cross Rail Clamp 12 14 3-Way Cross Rail Clamp 8 15 15"Anchor 4 16 Cable-1'Lengths 4 17 Cable Clamps 4 18 Foot Plate 6 19 Pin Bolt 6 20 Open Pin 6 21 M6×45 Bolts 10 22 M6×40 Bolts 16 23 M6 Washer 26 24 M6 Lock Nuts 26 25 Roof Tarp 1 26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	11	4-Way Peak Connector		6
14 3-Way Cross Rail Clamp 8 15 15"Anchor 4 16 Cable-1'Lengths 4 17 Cable Clamps 4 18 Foot Plate 6 19 Pin Bolt 6 20 Open Pin 6 21 M6×45 Bolts 10 22 M6×40 Bolts 16 23 M6 Washer 26 24 M6 Lock Nuts 26 25 Roof Tarp 1 26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	12	3-Way Peak Connector	8	2
15 15"Anchor	13	4-Way Cross Rail Clamp		12
16 Cable-1'Lengths 4 17 Cable Clamps 4 18 Foot Plate 6 19 Pin Bolt 6 20 Open Pin 6 21 M6×45 Bolts 10 22 M6×40 Bolts 16 23 M6 Washer 26 24 M6 Lock Nuts 26 25 Roof Tarp 1 26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	14	3-Way Cross Rail Clamp		8
17 Cable Clamps 4 18 Foot Plate 6 19 Pin Bolt 6 20 Open Pin 6 21 M6×45 Bolts 10 22 M6×40 Bolts 16 23 M6 Washer 26 24 M6 Lock Nuts 26 25 Roof Tarp 1 26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	15	15"Anchor		4
18 Foot Plate 6 19 Pin Bolt 6 20 Open Pin 6 21 M6×45 Bolts 10 22 M6×40 Bolts 16 23 M6 Washer 26 24 M6 Lock Nuts 26 25 Roof Tarp 1 26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	16	Cable-1'Lengths	annumanns	4
19 Pin Bolt 20 Open Pin 6 6 21 M6×45 Bolts 10 10 22 M6×40 Bolts 23 M6 Washer 24 M6 Lock Nuts 25 Roof Tarp 26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 29 Clasp	17	Cable Clamps		4
20 Open Pin 6 21 M6×45 Bolts 10 22 M6×40 Bolts 16 23 M6 Washer 26 24 M6 Lock Nuts 26 25 Roof Tarp 1 26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	18	Foot Plate		6
21 M6×45 Bolts 10 22 M6×40 Bolts 16 23 M6 Washer 26 24 M6 Lock Nuts 26 25 Roof Tarp 1 26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	19	Pin Bolt		6
22 M6×40 Bolts 16 23 M6 Washer 26 24 M6 Lock Nuts 26 25 Roof Tarp 1 26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	20	Open Pin		6
23 M6 Washer 26 24 M6 Lock Nuts 26 25 Roof Tarp 1 26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	21	M6×45 Bolts		10
24 M6 Lock Nuts 26 25 Roof Tarp 1 26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	22	M6×40 Bolts		16
25 Roof Tarp 1 26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	23	M6 Washer		26
26 Door Panel with Zipper 1 27 Back Panel 1 28 Ratchet 4 29 Clasp 4	24	M6 Lock Nuts		26
27 Back Panel 1 28 Ratchet 4 29 Clasp 4	25	Roof Tarp		1
28 Ratchet 4 29 Clasp 4	26	Door Panel with Zipper		1
29 Clasp 4	27	Back Panel		1
	28	Ratchet		4
# Owner 's Manual 1	29	Clasp		4
	#	Owner 's Manual		1

[&]quot;#" Indicates a non-illustrated part

ASSEMBLY PREPARATION

- Place all parts from the packaging box in a cleared area and arrange them on the ground in front of you.
- Remove all packaging materials and place them back in the box. Do not dispose of the packaging materials until assembly is complete.
- · Check for completeness and transport damages.

WARNING!



- Do not place the product under trees from which hard fruit such as apples, walnuts or heavy pine cones, etc., may fall.
- Keep children away during assembly. This product contains small parts which can be swallowed by children.
- Do not attempt to assemble the product if any parts are missing.
- At least 3 people are needed to complete the assembly as some of the steps require heavy lifting.


ASSEMBLY



WARNING!

• Do not leave the shelter unattended during assembly. Otherwise, personal injury or damage to the shed may occur!

Frame assembly overview



Step 1: Preparing the Roof Parts

Select level and suitable location for your shelter. Layout the roof parts as shown in Diagram B.

Please pay attention to the differences to the 5 connectors with reference to Diagram C below (connectors are also individually numbered).

Note:

- When installed, the welded socket for the cross rail must be below the bend.
- 2.Parts #8, #9, #11 are Side bend connectors with sharp bend.
- 3.Parts #12 & #7 is top bend connectors with sloping bend.

Step 2: Assembling the Roof

Assemble the roof frame by connecting the parts lay out in the above.

Note:

- 1. The hole end on Part #4 needs to be connected to Part #12 and #7 (See Diagram D1& D2) by the fittings #21, #23 and #24.
- 2. There is spring button on both ends of Part #4. Make sure the button needs to pop-up when connecting with Part #12, Part #7. (See Diagram D3)
- 3. Use a rubber or wooden mallet to ensure all pipes are fully inserted.

Step 3: Attaching the legs

There are 10 legs for the whole shelter.

- Follow Drawing E1 connected tube #2 & #10 to get the 4 Corner Legs.
- b. Then connect tube #1 to get the 6 Center Legs.
- c. Insert the Center Legs into the Foot Plate (#18). Align holes in the pole and foot plate, push the Pin Bolt (#19) through all the holes, insert the cotter pin (#20) and split the tongues of the cotter pin with a slot screwdriver to secure this connection. (See Diagram E2, E3 # E4)
- Insert the prepared Center Legs and Corner Legs into
 the side connectors as Diagram E4.

Diagram B




Diagram C




Diagram D





Diagram E



e. Repeat to assemble the other side(as shown in Diagram F).

Step 4: Assemble Bottom Cross Rails

- a. Install the Bottom Cross Rails(#6) between each two legs withCross Rail Clamps (Part#13 & #14) by the fittings (Part #22, #23 & 24). Part #13 is for Center Legs, and #14 is for Corner Legs. (see Diagram G)
- b. Slide the cover rails so that they are both 10''up from the ground. Do not tighten the bolts now.

Step 5: Square and Anchor the Frames

- a. Check the mearsure of frame both 10' at the front and back corners, as well as the center.
- Take a diagonal measure as shown in Diagram H.
 When these two measures are equal the frame is square. Adjust the frame until they are equal to within 1".
- c. Once equal check the width measures again to ensure all are equal at 10'.
- d. Next, install Anchors (Part # 15, #16 & #17) at the 4 Corner bent legs by screwing the removable anchor (#15) into the ground and to the inside of the shelter. Secure with Cable (#16) and Cable Clamp(#17) (as shown in Diagram I).

Diagram F




Diagram G




Diagram H





Diagram I



Step 6: Installing the Front and Back Covers.

The front cover contains a zippered door to allow entry and exit to the shelter. Ensure to locate this cover to the desired end. Also, ensure the zipper is in the 'closed' position while installing. The back cover is a solid piece of polyethylene. The covers are installed in the same fashion.

- a. To make sure the strap will stay in the sleeve when assembly thread the strap through the spindle of the ratchet, and make sure the strap will stay in the clasp.
- Begin with the front cover and first locate the webbed belt that runs the perimeter of the cover.
- c. The webbing is exposed at the peak, the shoulders and the feet of the cover. And there are 3 buckles at the above 3 positions.
- d. Unlock the buckle, slip the webbed belt around the side 3-way connector and relock the buckle again.
- e. Repeat this step for the opposite shoulder.
- f. Move to the peak of the shelter using a step stool or ladder if necessary. Unlock the buckle around the peak
 3-way connector and relock the buckle again.
- g. While one person remains on the stool and standing at the peak of the shelter, the other person inserts the S-hook of the clasp into both sides of corner legs (K3).
- h. The person standing at the peak assists by ensuring the tarp is partially folded over the pipes of the end frame and inside or toward the interior of the shelter.
- i. The other person make sure the door panel flat and then pulls the strap tightens.
- Repeat above steps for the other side of the Back Panel assembling.

DO NOT OVERTIGHTEN RATCHETS AT THIS TIME!

Diagram J





Diagram K



Step 7: Installing the Main Cover

- a. To make sure the strap will stay in the sleeve when assembly thread the strap through the spindle of the ratchet. Raise and lower the handle two or three times to wind the strap onto the spindle (as shown in Diagram L).
- b. Lay the cover on the ground next to the frame with inside of the cover (the side with pipe pockets)facing upword and the webbing on the front and rear of the corner of the building.
- c. Tie one end of a rope to the eyelets on one corner of the cover, then another rope to the other corner eyelets.
- d. Pull cover over the frame by the help of the rope as Diagram
 L, making sure to center cover on frame. There should be an equal amount of overhanging at all four corners.
- e. Insert the ''S''- hook on ratchet into hole on the Bent Corner Leg. Wind the ratchet so that the webbing overlaps itself.
- f. Disassemble cover rails and slide through fabric pockets at each leg and reattach with clamps to each leg. Repeat this on the other side. Push down on cover rails to tighten cover, before tightening bolts completely.
- g. When the cover rails are all secured, then proceed to the 4-corners and tighten the end covers to the end frames through the ratchet action.

NOTE: Over-tightening can cause damage to straps and/or the anchor point.

DO NOT over-tighten!

The shelter is now ready for use.

Note: Please check periodically (two to three times in the first week-weekly for the balance of the first month of set up) and tighten ratchet tie-downs and all hardware as needed. Monthly inspection is recommended throughout usage.

Disassembly:

When disassembling the shelter, depress the springloaded bar and open ratchet handle completely to allow the webbed belt to disengage the ratchet.

PLEASE RE-READ ALL WARNINGS CONTAINED ON PAGE 2 OF THIS INSTRUCTIONS. SAVE THESE INSTRUCTIONS FOR FUTURE USE.

To dismantle, execute all instructions in reverse order.

Store your shelter in a cool, dry location between seasons to prolong usable life of all components.

Components are not equally durable and will require replacement over time at differing intervals.

Diagram L

