


Installation manual



Notes:

1. Open the package and check that the number/code of boards and hardware is complete according to this instruction manual.
2. Follow the picture in the instructions, assemble it step by step and in order ((Tips: Note that the boards and holes are aligned as shown in the picture)).

General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.
- If there are any defective or missing parts after unpacking, please cease assembly and get in contact with us immediately.




Notes

- The product must be assembled and used in accordance with the provisions of the manual.
- There may be some odour after unpacking the parcel, please put this item in a ventilated place for a few days and the odour will dissipate.

Warnings

- During the assembly process, keep any small parts out of the reach of children. It may be fatal if swallowed or inhaled.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (films, plastic bags and foam, etc.) away from babies and children.
- Do not stand or sit on the product.
- Never touch with sharp objects or corrosive chemicals, which may damage the surface of the item.
- Do not expose product to direct sunlight or rain; and do not put it in a humid place.


Tools Required:



Bolt Bolzen
Boulon Bullone
Perno



Connecting piece
Verbindungsbeschlag
Pièce de raccord
Pezzo di bloccaggio
Pieza de sujeci ó n




Adjust connecting piece direction until it is properly lined up with the hole.

Stellen Sie den Verbindungsbeschlag so ein, dass er wie im Bild gezeigt ausgerichtet ist

Ajustez l' é crou selon le sch é ma

Regolare la direzione di pezzo di collegamento come la condizione illustrata

Ajustar la pieza de sujeci ó n seg ú n la direcci ó n ilustrada






Insert bolt when connecting piece direction is properly lined up.












Setzen Sie erst dann den Bolzen ein


Ins é rez le boulon quand la pièce de raccord est dans telle condition






















Inserire il bullone quando il pezzo di collegamento è in tale condizione

Insertar el perno cuando se encuentre as í la pieza de sujeci ó n





<div>1</div>  <div>x1</div>	<div>2</div>  <div>x1</div>	<div>3</div>  <div>x1</div>
<div>4</div>  <div>x1</div>	<div>5</div>  <div>x1</div>	<div>6</div>  <div>x2</div>
<div>7</div>  <div>x1</div>	<div>8</div>  <div>x2</div>	<div>9</div>  <div>x2</div>
<div>10</div>  <div>x2</div>	<div>11</div>  <div>x2</div>	




A	x6	B	x6	C	x6	D	x4
							
M6x25		M12x9		M6x30		M3x12	
E	x16+1	F	x8	G	x1	H	x2
							
M3.5x16		M5x50		M3			
I	x4	J	x 4	K	x 4	L	x 1
							
M	x 8	N	x 8	O	x 12+1	P	x 1
							
Q	x 1	R	x 1	S	x 1	T	x1
							
U	x 12+1						
							






STEP 1



	A x 2
--	--------------


STEP 2





	A x 4		S x 1
	E x 4		T x 1
	H x 2		


Note: After confirm the number of the screw and holes,tighten the screws.

STEP 3




	I x 4
	J x 4





STEP 4




	C x 2
---	--------------


STEP 5




	B x 1		U x 4
	F x 4		G x 1








STEP 6



	P x 1
--	--------------


STEP 7



	B x 1		U x 4
	F x 4		G x 1

Note: After place board "⑤" and tighten part "F".



STEP 8






Note: Put the part "⑩" into the groove, pay attention to the direction of the board.


	L x 1
--	--------------

STEP 9





Note: Put the "C" inside, pay attention to the direction of the board.



	B x 4		
	C x 4		U x 4



STEP 10


Note: The location of the plastic peices "O" can be arbitrary, mainly to increase the stability of the cabinet.





	E x 12
	O x 12


STEP 11

Note: Attach the cabinet to the wall with anti-toppling device and protects it from tipping over.




	Q x 1
	R x 1

STEP 12



	N x 8
---	--------------

STEP 13




Note: Manually press "M" to install the door, paying attention to the direction of "M".



M x 8

STEP 14



D x 4



K x 4