


ASSEMBLY INSTRUCTIONS

METAL GARDEN SHED

8 x 6 Metal Shed



E-mail:
hofficeservice@gmail.com




Please read the instructions strictly,
please assemble this table according to the instruction assembly order.

SITE PREPARATION

Level the ground surface.



Recommendation: Construct a wooden or concrete base as a foundation.



BEFORE STARTING ASSEMBLY


Remove all of the pieces from the 2 packages and spread them out on the ground. Before installation, please check the type and quantity of parts first.

It is recommended to use a clean work surface to spread the parts out and for pre-assembly steps. Review all instructions before you begin, continue to refer to instructions during assembly.

Be sure to follow all steps thoroughly.

Please prepare these components in advance at the beginning of each stage.

REQUIRED TOOLS



CAUTION






















Some parts have steel edges. Please be careful when handling components. Always wear work gloves, eye protection and long sleeves when assembling or performing any maintenance on your shed. Do not attempt assembly on days with strong winds or low temperatures.



























Requires two people and takes 3 hours for Installation.
Recommended to wear gloves to avoid scratches.
Please read the manual carefully before installation.

**DO NOT RETURN YOUR UNIT
TO THE STORE**
Contact us first
hofficeservice@gmail.com









ROOF PARTS

<p>A3 X2</p> 	<p>A4 X2</p> 	<p>T3 X2</p> 
<p>C5 X4</p> 	<p>GC X4</p>  <p>F5 X4</p> 	
<p>GE X2</p> 	<p>M2 X2</p> 	<p>M2L X2</p> 
<p>M9 X2</p> 	<p>M10 X2</p> 	<p>M11 X4</p> 
<p>M13 X2</p> 		
<p>PE3 X2</p> 		
<p>PE4 X4</p> 		
<p>PE5 X2</p> 		
<p>PE6 X2</p> 		



















WALL PARTS

			
W1A X12	WS2A X4	WS3A X2	ULA X1
			
			
			
			
			
			
			
			


DOOR PARTS

					
DLA X1	DLB X1	DRB X1	DRA X1	DG X1	DH X4
					
					
DX2 X4					

SCREW


   <p>F1(X334) M4*10</p>	    <p>F2(X20) M4*10</p>
   <p>F3(X32) M5*12</p>	    <p>F4(X5) M6*10</p>
    <p>F6(X4) M4*16</p>	

CONTENTS




Bottom frame construction

09-12
(page)



Wall construction

13-19
(page)



Roof Mount


20-27
(page)




Door installation

28-36
(page)


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6



STEP 7




STEP 8



STEP 9




Tips: Align the gasket with the hole, and then use the electric drill to drill the V2 into the hole.




STEP 10




Please align the screws with the screw holes for installation.






STEP 11





STEP 12




STEP 13




STEP 14






STEP 15







STEP 16







STEP 17






STEP 18






STEP 19



STEP 20










STEP 21




STEP 22


Note: The door frame (ULA,UR1) should cover the raised part on the wall panel, not insert.




STEP 23



STEP 24




STEP 25





Note: M2L is pressed into M2.



STEP 26




STEP 27




STEP 28



Note: Finally tighten all F2.




STEP 29




STEP 30


Note: Do not install F1 and V2 in the holes near the outer side of PE5.




STEP 31





STEP 32






STEP 33




Note: Do not install F1 and V2 in the holes near the outer side of PE5.




STEP 34





STEP 35




STEP 36





STEP 37




x2




STEP 38



x4




STEP 39




STEP 40


The other door operates the same way




x2





STEP 41





The other door operates the same way





STEP 42






STEP 43






STEP 44





STEP 45




STEP 46





STEP 47



X2




STEP 48




X4




STEP 49



Put it on the screw tip to prevent injury.



FINISH



CARE & SAFETY

- Unsuitable for storage of flammable or corrosive substances.
- It is of utmost importance to assemble all of the parts according to the directions. Do not skip any step.
- Please consult your local authorities if any permits are required to erect shed.
- Periodically check shed to assure that it remains stable and that the site remains level.
- It is highly recommended to secure the shed to an immovable object or to the ground by drilling holes in the floor at the pre-marked locations and inserting proper screws into the ground (screws are not included).
- Wear safety-goggles and always follow the manufacturer's instructions when using power tools.
- Wash shed with garden hose or a mild detergent solution. Using a stiff brush or abrasive cleaner could damage shed.
- Hot items such as recently used grills, blowtorches, etc. Must not be stored in the shed.
- Heavy articles should not be leaned against the walls, as this may cause distortion.
- Keep roof clean of snow and leaves. Heavy amounts of snow on roof can damage the shed making it unsafe to enter.
- Although wind direction varies, it is an important factor when taking into account where to place your shed. Therefore, it is recommended to reduce wind exposure of the shed in general, and the door side in particular.
- Keep doors closed and locked to prevent wind damage.
- Do not stand on the roof.

