


WATER TEST AND LEAK TEST

Purpose: to flush out impurities and sludge in the pipeline to avoid blockage and affect the water outlet function.

1. Open the protective cover, remove the white plug of the water outlet, open the water source, rinse the pipeline; then open and close the valve core, check the pressure resistance and sealing performance of the pipeline to ensure that there is no leakage.

2. After the sealing test, please install the protective cover as it is.



SINGLE FUNCTION INSTALLATION DIAGRAM

INSTALLATION INSTRUCTIONS

INSTALLATION HEIGHT PARAMETERS ARE FOR REFERENCE ONLY

Installation Notes


Installation mode:
Embedded depth of mixing valve box switch before ceramic tile placement: 55MM

Hydraulic requirements for installation:
Minimum water pressure of 0.5 bar, recommended water pressure of 3.0 Bar a water pressure of 1.0 bar

PPR Plumbing requirements:
Water intake 4 Branch pipe,
Out of the water 4 Branch pipe
(Self-purchase)


■ Hot Water
■ Cold water
■ Mixed water

Height is tentatively 170cm



Installation Notes

1. According to the size of the embedded box, the pipe wall slotted;
2. Align the embedded box with the hot and cold water inlet pipe and mix the water outlet pipe.
3. After the ceramic tile is attached, cut the redundant parts of the embedded box according to the external dimension.
4. Install the switching valve with the matching hexagonal tool, switch the handle.
5. Installation complete



Installation Notes

1. According to the basic size of the product, refer to the above picture to open the wall and dig the main embedded hole, the hot and cold water inlet and the upper shower arm connection.




2. Connect the hot and cold water inlet hose and the upper shower arm connection pipe to the embedded box respectively, and tighten with a wrench. Special attention must be paid to the connection of cold and hot water pipes in the embedded box: hot water on the left and cold water on the right.

Water test and leak test

1. Purpose: flush the impurities and sludge in the pipeline to avoid blocking and affecting the water outlet function.
2. Open the plastic protective cover, turn on the water switch to open the spool rod upward, flush the pipeline; close the spool to test the pressure resistance and sealing performance of the pipeline to ensure that there is no leakage.
3. Use raw material tape to block each outlet pipe, open the water source, check whether the connections of the upper outlet pipe are tight and the pipeline is under pressure to ensure that there is no leakage.
4. After sealing test, please install the protective cover as it is.

ENJOY COMFORTABLE BATHROOM SPACE

Installation schematic diagram of main body of concealed installation shower



The groove depth of blank wall should be 55mm
Total Height of ceramic tile 80 mm is preferred

