

AquaDance®

Premium 6-setting Hand Shower

Includes Shower Handle, 5 ft. Stainless Steel Shower Hose, Angle-Adjustable Overhead Bracket and Plumber's Tape

To Connect

1. Remove old shower head by turning it counter-clockwise. Remove any excess material left on Shower Arm threads. Use steel wool if necessary.
2. Make sure Thick Washer is positioned FLAT and STRAIGHT inside Connection Nut of Bracket (Fig. 1, 4). Hand tighten Connection Nut onto Shower Arm.

WARNING: DO NOT OVERTIGHTEN Connection Nut as it may cause Washer to dislocate and be squeezed into Shower Arm. If leakage occurs, see below.

3. Turn Holder clockwise to position Hose Outlet pointing Down (Fig. 1). If it does not turn, loosen Ball Joint Nut slightly by turning it in CLOCKWISE Direction (Fig. 1), then tighten it back after you are done.
4. Turn on water to check for leakage. If leakage occurs, follow instructions below.
5. Screw Short Hose Nut with Hose Washer in place onto Hose Outlet (Fig. 2). Screw Handle with Hose Washer in place onto Long Hose Nut (Fig. 3), then insert Handle into Holder (Fig. 5).

Have a Leak? Make your shower 100% leak-free in less than a minute!

Leakage between Bracket and your Shower Arm is caused by Washer inside Connection Nut not pressing evenly against edge of Shower Arm Thread (fig. 1). This is usually the result of Washer not nested correctly. To seal properly, Washer must stay FLAT and STRAIGHT inside Connection Nut (Fig. 4).

You can eliminate this leak by simply re-positioning Thick Washer: 4

Unscrew Bracket from Shower Arm and adjust position of Washer by a) pushing it down with your finger, or b) using screwdriver or pointed metal tool to press down around Washer edges until it nests completely FLAT and STRAIGHT inside Nut (fig. 4). Once Washer is nested correctly, re-connect Bracket and run water to test.

If Washer is positioned correctly but leak remains, it is likely the result of Damaged Washer Surface or Worn Shower Arm Threads. If you suspect Damaged Washer Surface, using screwdriver or pointed metal tool, pull out Washer from Connection Nut, turn it up-side-down and nest back into Nut (repeat step 2). If the leak is caused by Worn Shower Arm Threads, wrap some Plumber's Tape (included) around Shower Arm threads.

IMPORTANT: Hand tighten connections ONLY. DO NOT use wrench or pliers.

DO NOT overtighten - this may cause washer to bend and be pushed into shower arm. Use plumber's tape ONLY if needed on shower arm thread if Washer fails to stop leakage. DO NOT use plumber's tape on any other connections.

NOTE: If your shower arm has a ball on the end of it instead of thread, it will not work with this shower unit and will need to be replaced with a standard shower arm available at most plumbing supply stores.

