


Assembly Instructions




Before Assembly

Tips Before Your Start:


- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until the assembly is completely assembled.
- Keep all hardware parts out of reach of children.

QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


CAM LOCK



When fitting a cam lock, ensure the starting position is correct before inserting the connecting QUI CKFIT

Quickfit head should be in the centre of the cam lock when the two panels are joined.

Cam lock should be inserted before quickfit.




Turn cam lock clockwise to tighten.


Before Assembly

Tips Before Your Start


How to separate the drawer slider:



Drawer Front Alignment
















If the drawer front panel is NOT level after being assembled, then...




Loosen the screws on the left and right hand side, then adjust the drawer slide up or down, untill the drawer fronts are even/level, then tighten the screws.


Part List

No. A Quantity:56 Pcs Cam Lock Dowel 8*28mm 	No. B Quantity:56 Pcs Cam φ15 	No. C Quantity:56 Pcs Sticker Ø20 	No. D Quantity:13 Pcs Dowel 8*40mm 
No. E Quantity:7 Pcs Drawer Slider 10" 	No. F Quantity:7 Pcs Screw M4*16mm 	No. G Quantity:7 Pcs Handle 	No. H Quantity:56 Pcs Screw M3.5*12mm 
No. I Quantity:4 Pcs Slip Mat Ø20 	No. J Quantity:28 Pcs Screw M4*30mm 	No. K Quantity:1 Pcs Adjust The Foot 	No. L Quantity:16 Sets Plastic Wedge 
No. M Quantity:1 Sets Anti-falling Parts 			

Product structure




STEP 1




No. A
Quantity: 18 Pcs
8*28 mm




STEP 2



The first screw hole should corresponded with the board location hole



No. E
Quantity: 2 Sets
10"



No. H
Quantity: 8 Pcs
M3.5*12mm




×2


STEP 3



The first screw hole should corresponded with the board location hole




No. E
Quantity: 2 Sets
10"




No. H
Quantity: 8 Pcs
M3.5*12mm



STEP 4




The first screw hole should corresponded with the board location hole



No. A
Quantity: 8 Pcs
8*28 mm



No. E
Quantity: 3 Sets
10"




No. H
Quantity: 12 Pcs
M3.5*12mm




STEP 5

No. B
Quantity: 4 Pcs
Ø15




STEP 6

No. B
Quantity: 4 Pcs
Ø15




STEP 7




No. B
Quantity: 4 Pcs
Ø15



No. D
Quantity: 4 Pcs
8*30mm



STEP 8





STEP 9

No. B
Quantity: 8 Pcs
Ø15




No. D
Quantity: 4 Pcs
8*30mm




STEP 10

No. A
Quantity: 2 Pcs
8*28 mm




STEP 11




No. B
Quantity: 2 Pcs
Ø15



No. D
Quantity: 2 Pcs
8*30mm



STEP 12





STEP 13


No. B
Quantity: 6 Pcs
Ø15




No. D
Quantity: 3 Pcs
8*30mm



STEP 14



STEP 15




No. I
Quantity: 4 Pcs
Ø20




No. K
Quantity: 1 Pcs



STEP 16



×1



×2

No. A
Quantity: 12 Pcs
8*28 mm





No. F
Quantity: 3 Pcs
M4*16mm



No. G
Quantity: 3 Pcs



STEP 17



No. A
Quantity: 16 Pcs
8*28 mm






No. F
Quantity: 4 Pcs
M4*16mm




No. G
Quantity: 4 Pcs




STEP 18




No. J
Quantity: 28 Pcs
M4*30mm



STEP 19





STEP 20



No. B
Quantity: 12 Pcs
Ø15



STEP 21





No. B
Quantity: 16 Pcs
Ø15




STEP 22



The first screw hole should corresponded with the board location hole



No. E
Quantity: 3 Sets
10"



No. H
Quantity: 12 Pcs
M3.5*12mm




STEP 23




back

The first screw hole should corresponded with the board location hole




No. E
Quantity: 4 Sets
10"




No. H
Quantity: 16 Pcs
M3.5*12mm




STEP 24




STEP 25




No. L
Quantity: 16 Sets




STEP 26



STEP 27



No. M
Quantity:1 Set



Note:
Please lift up the furniture by two people when moving is needed.
Dragging may cause the legs failure.