

1. Remove the two sides of the frame and lay them on their side. They are not side specific or end specific.




2. Swing the cross arms open as shown. Lay the frame open as shown.




3. Insert the rivets into the appropriate set of keyhole slots for the size bed you have. The set closest to the leg is the Twin setting, middle is Full/Double and the set closest to the end is for Queen. Put the head of the rivet through the round hole and pull the rails in the opposite direction so the rivet slides into the narrow part of the keyhole. Do not be concerned if the frame does not fully lock out at this point. They will lock in place in the next step.

4. In the top of the cross arm, there is a hole. Install a nut and bolt in this hole on the cross arms at both ends of the frame. Secure with wrenches provided.



ZOP EZ Twin-Full Bed Frame

5. Now put the black glides/feet on all 4 legs. So, at this point, the frame should look like this.



6. Install the brown angle end caps on the ends of the side rails. If you are attaching to a headboard you will only need them on the foot end. Either end can be the head or foot end.



7. If you are using a headboard, find the headboard mounting brackets. They can be used as either left or right. Pick a set of the round holes that look like the right height for the headboard mounting holes. Loosely attach the brackets to the frames as shown. Hold the headboard up to the frame and see if you have selected the proper holes. Once you have selected the proper holes, tighten the bracket. The brackets can be turned in or out, or one can be turned in and one out. Whatever configuration you need to securely attach the headboard.

