


















CUSTOMER MANUAL



ASSEMBLY STRUCTURE REFERENCE DIAGRAM




PARTS




PARTS

15




X 1

16




X 1

17




X 4

18




X 1

19




X 2

20



X 2

21



X 1

PARTS

A



X 48+2

B




X 48+2

C



Ø6 x 30mm
X 44+2

D




Ø3 x 12 x 6mm
X 22+1

E




X 4

F




Ø3 x 14mm
X 40+2

G




X 8

H



Ø3.5 x 14mm
X 32+2

I



M6 x 25mm
X 4

J



X 2

K



X 4

L



X 8+1

M




X 16+2

N



X 4

O




X 4

P




Ø4 x 35mm
X 4

Q




M4
X 1

R




X 1

S



Ø3 x 12 x 6mm
X 2


T




X 1

PARTS


V2



X 2




V3




X 1

V4







X 10


V5



X 1




How to work the Knock Down (kd) assembly system




How to install Wood Dowel


Insert the wood dowel [II] at least half way by tapping lightly with a rubber mallet, IF NECESSARY.



How to use the Cam Lock system




1. Screw the cam bolt [I] into the threaded insert on the panel.
2. Connect both panels together making sure cam bolt [I] goes into the pre-drilled large hole on the end of panel for cam lock [IV].
3. Insert the cam lock [IV] into the pre-drilled large hole on the panel. **Make sure the cross slot of cam lock [IV] faces out.**
4. Rotate the cam lock [IV] **clockwise** with a self-supplied philips screwdriver to lock the cam bolt [I] in place.




You are now ready to assemble the Glass Door Sideboard (With Light)

It is divided into three parts in total:

1. Install the base part
2. Install the middle part
3. Install the top part





We recommend using a power
drill to assemble.



Step 1

Securing Cam Bolt (B) into Board (3).









Step 2

Inserting Wooden Dowel (C) into Board (③)



Attach Board (⑨) to Board (③)

Using Cam Lock (A) secure Board (⑨) to Board (③)



Step 3

Securing Cam Bolt (B) into Board (④).






Step 4

Inserting Wooden Dowel (C) into Board (4)


Attach Board (4) to Board (3/9)

Using Cam Lock (A) secure Board (4) to Board (3/9)



Step 5

Securing Cam Bolt (B) into Board (5).





Step 6

Inserting Wooden Dowel (C) into Board (5)


Attach Board (5) to Board (3/9)

Using Cam Lock (A) secure Board (5) to Board (3/9)




Step 7

Inserting Wooden Dowel (C) into Board (10)
Using Screws (I) to assemble Board (10) to Board (4).



Step 8

Securing Cam Bolt (B) into Board (6).






Step 9


Inserting Wooden Dowel (C) into Board (6)

Attach Board (6) to Board (3/9)

Using Cam Lock (A) secure Board (6) to Board (3/9)




- A  x 3
- C  x 2





Step 10

Securing Cam Bolt (B) into Board (7).




Step 11

Inserting Wooden Dowel (C) into Board (7)
Attach Board (7) to Board (3/9)
Using Cam Lock (A) secure Board (7) to Board (3/9)



Step 12


Inserting Wooden Dowel (C) into Board (10)
Using Screws (I) to assemble Board (10) to Board (7).



Step 13


Using Screws (D) to secure (J) to Board (8)

TIP: Pay attention to the front and back sides, please install the front side.




Step 14

Securing Cam Bolt (B) into Board (11 13)




Step 15

Using Screws (H) to secure (G) to Board (11 13).




Step 16



Step 17


Attach the LED Strip Light (V2) to Board (13).

TIP: When pasting, please align the corners of the light strip with the center of the 2 guide holes to ensure that the light strip is straight.




Step 18

Using Screws (D) to secure (V4) to Board (13).





Step 19



Inserting Wooden Dowel (C) into Board (8)
Attach Board (8) to Board (11 13)



Step 20

Using Screws (D) to secure (E) to Board (8 11 13)






- D  x 4
- E  x 2

Step 21

Inserting Wooden Dowel (C) into Board (④⑤)


Attach Board (⑪ ⑬) to Board (④⑤)

Using Cam Lock (A) secure Board (⑪ ⑬) to Board (④⑤)



Step 22

Securing Cam Bolt (B) into Board (15).





Step 23

Inserting Wooden Dowel (C) into Board (3)


Attach Board (15) to Board (3)

Using Cam Lock (A) secure Board (15) to Board (3)




Step 24

Securing Cam Bolt (B) into Board (12 14)



Step 25


Using Screws (H) to secure (G) to Board (12 14).



Step 26


Attach the LED Strip Light (V2) to Board (14).

TIP: When pasting, please align the corners of the light strip with the center of the 2 guide holes to ensure that the light strip is straight.




Step 27

Using Screws (D) to secure (V4) to Board (14).





Step 28

Inserting Wooden Dowel (C) into Board (8)
Attach Board (8) to Board (12 14)



Step 29

Using Screws (D) to secure (E) to Board (8 12 14)






Step 30


Inserting Wooden Dowel (C) into Board (6/7)

Attach Board (12/14) to Board (6/7)

Using Cam Lock (A) secure Board (12/14) to Board (6/7)




A		x 6
C		x 4





Step 31

Securing Cam Bolt (B) into Board (16).





Step 32

Inserting Wooden Dowel (C) into Board (3)
Attach Board (16) to Board (3)
Using Cam Lock (A) secure Board (16) to Board (3)



Step 33

Securing Cam Bolt (B) into Board (①②).



Step 34




Inserting Wooden Dowel (C) into Board (4⑤⑥⑦)

Attach Board (①②) to Board (④⑤⑥⑦⑧)

Using Cam Lock (A) secure Board (①②) to Board (④⑤⑥⑦⑧)



⚠ ORIENTATION ALERT

Verify board orientation
THROUGH alignment holes!



Step 35


Using Screws (D) to secure (V4) to Board (①②).




Step 36

Using Screws (H) to assemble Hinges (G) to the Board (19/20)

TIP: When installing the glass door, please be careful not to tighten the screws too quickly. Make sure the two cabinets are at the same height before tightening the screws.





- ①. TO ADJUST THE DOOR TO RIGHT OR TO LEFT.
- ②. TO ADJUST THE DOOR UP OR DOWN.



Step 37



Attach (K) to Board (19 20)

Using Screws (L) to secure (K) to Board (19 20)




Step 38

Securing support Accessories (M) into Board (④⑤⑥⑦),
There Are Three Heights Can Be Adjusted




Step 39

Place the Board (17) into Board (4 5 6 7).




Step 40



Using Screws (S) attach Board (T) to Board (2).



Step 41



Using Screws (F) through Anti-tipping Belt (N) assemble Back Panels (18 21) to the main body. And Take the Light Strip out of the hole.





F		x 40
N		x 4

Step 42



Connect Accessories(V3)&(V5) to the 2 Light Strip (V2).



- V3  x 1
- V5  x 1



Step 43



Drill 4 holes in the wall and Hammer the (O) in.




Step 44

Using Screw (P) attach Anti-tipping Belt into the wall.






+



+



||

