











CAST ALUM. RECT COFFEE TABLE




# PARTS LIST

<b>A</b> 	<b>B</b> 	<b>C</b> 
<b>Leg</b> 4 PCS	<b>Top</b> 1 PC	<b>Stretcher</b> 1 PC

# HARDWARE LIST

<b>1</b> 	<b>2</b> 	<b>3</b> 	<b>4</b> 	<b>5</b> 
<b>Cylinder Bolt</b> (M8*35) 4PCS	<b>Spring Washers (M8)</b> 8 pcs.	<b>Flat Washers (M8)</b> 8 pcs.	<b>Nuts (M8)</b> 8 pcs.	<b>Nut Caps (M8)</b> 8 pcs.
<b>6</b> 				
<b>Wrench</b> (M6 &M8) 1 PC				



Step 1: Place Top (B) upside down on a soft cloth.






Insert all Cylinder Bolts (Part #1) into the pre-drilled holes of Top (B).


Step 2: Attach two adjacent Legs (B) by inserting the Cylinder Bolts (Part #1) through the holes in Legs (A) by fitting the leg on top of the attached cylinder bolt. Secure the Legs (B) using Flat Washers (Part #3), Spring Washers (Part #2), and Nuts (Part #4). Note - -Tighten the Nuts (Part #4) only half way at this time using wrench (Part #6).

Step 3: Attach Stretcher (C) to the two attached Legs (A) with Flat Washers (Part #3), Spring Washers (Part #2), and Nuts (Part #4). Note - -Tighten the Nuts (Part #4) only half way at this time.


Attach the other two legs (B) to the Top (B) & Stretcher (C) using the same method as the first two legs. Tighten all Nuts (Part #4) completely.

Step 4: Cover all Nuts (Part #4) with Nut Caps (Part #5). Turn the table over to the upright position. Adjust the levelers on the bottom of the legs to level the table.

- |                 |   |     |
|-----------------|---|-----|
| ① Bolt          |  | x 4 |
| ② Spring Washer |  | x 8 |
| ③ Flat Washer   |  | x 8 |
| ④ Nut           |  | x 8 |
| ⑤ Nut Cap       |  | x 8 |



**Figure 1**  
Flathead screw driver (not included)



**Figure 2**