



# Assembly Instructions




*Please visit our website for the most current instructions, assembly tips, report damage, or request parts.*

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product .




- VIII. Concealed hinges are three-way adjustable.



Horizontal  
by screw adjustment




In-and-Out  
by loosening the hinge-arm  
mounting screw or via cam  
adjustment























Vertical  
Via slots in the mounting  
plate or via cam adjustment

# Parts List



# Hardware List


|   |   |          |               |        |
|---|---|----------|---------------|--------|
| A |    | Ø8x30mm  | Wooden dowel  | 12 pcs |
| B |    | Ø6x35mm  | Cam bolt      | 4 pcs  |
| C |    | Ø15x11mm | Cam lock      | 4 pcs  |
| D |    | Ø30mm    | Sticker       | 4 pcs  |
| E |    |          | Glass holder  | 12 pcs |
| F |    | Ø4x22mm  | Handle Bolt   | 2 pcs  |
| G |    |          | Handle        | 2 pcs  |
| H |    |          | Hinge         | 4 pcs  |
| J |    | Ø3x15mm  | Screw         | 24 pcs |
| K |    | Ø3x17mm  | Screw         | 12 pcs |
| L |  |          | Plastic wedge | 12 pcs |
| M |  | M 4      | Hex Key       | 1 pcs  |
| N |  | Ø6x12mm  | Bolt          | 16 pcs |
| P |  | Ø6x50mm  | Screw         | 8 pcs  |
| Q |  |          | Plastic strap | 1 pcs  |
| R |  | Ø4x35mm  | Screw         | 1 pcs  |
| S |  |          | Nut           | 1 pcs  |
| T |  | Ø4x15mm  | Screw         | 1 pcs  |
| U |  |          | Glue tube     | 1 pcs  |



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

## Step 1





Insert wooden dowel (A) into part (2) as per diagram.

## Step 2





Insert wooden dowel (A) into part (4, 5) as per diagram. Secure cam bolt (B) to part (4,5) with Phillips head screwdriver.

## Step 3



Attach part (2) to part (4) using cam lock (C) with Philips head screwdriver as per diagram.


## Step 4



Attach part (5) to part (2) using cam lock (C) with Philips head screwdriver as per diagram.




## Step 5




Slide part (8) into grooves as per diagram.

## Step 6




Attach part (3) to part (5, 4) using screw (P) with hex key (M) as per diagram.

## Step 7




x 4




Attach part (12) to part (3) using bolt (N) with hex key (M) as per diagram.

## Step 8




Slide part (6) into grooves of part (4) as per diagram.

## Step 9




Slide part (7) into grooves and attach to part (6) as per diagram.

## Step 10




Slide part (6) into grooves of part (7, 5) as per diagram.

## Step 11



Attach part (1) to part (5, 4) using screw (P) with hex key (M) as per diagram.




## Step 12



Place sticker (D) over holes as per diagram.




## Step 13



Secure plastic wedge (L) to back panel using screw (K) with Philips head screwdriver as per diagram.



## Step 14



Attach hinge (H) to parts (10,11) using screw (J) with Phillips head screwdriver as per diagram.


Attach handle part (G) to parts(10,11) using handle bolts (F) with Phillips head screwdriver as per diagram.

## Step 15




Attach part (10) to part (4) using screw (J) with Philips head screwdriver as per diagram.

## Step 16




Attach part (11) to part (5) using screw (J) with Philips head screwdriver as per diagram.

## Step 17






Insert glass holder (E) into part (4, 5) as per diagram.

## Step 18





x 3



Loosen screw of glass holder (E), place and secure part (9) to glass holder (E) with Philips head screwdriver as per diagram.


## Step 19




Attach plastic strap (Q) to back of part (1) using screw (T) with Philips head screwdriver.

## Step 20

### WARNING




Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.



1. Place unit in desired location and mark the wall for plastic strap location, drill hole using 6mm size bit.
2. Insert nut (S) into wall at desired location.
3. Secure furniture to wall using plastic strap (R) and screw (R) per diagram.



## Step 21



## Final Assembly