


BED FRAME




DEAR CUSTOMER,

Thank you for choosing our product. Please read this manual carefully before assembling or using the product, to avoid damage caused by improper use. If the product is passed on to third parties, this manual has to be passed on along with the product. For any question don't hesitate to contact us.










Parts Identification 1/2

Not actual size























Parts Identification 2/2

Not actual size

 <p>ⓐ J2 x 1</p>	 <p>ⓑ K x 28</p>
 <p>ⓒ L x 1</p>	 <p>ⓓ M x 1</p>
 <p>ⓔ N x 2</p>	 <p>ⓕ O x 2</p>
 <p>ⓖ P x 2</p>	 <p>ⓗ Q x 2</p>
 <p>ⓓ R x 2</p>	


Parts Identification 1/2

Not actual size

 $\text{\O}1/4" \times 11\text{mm}$ 1 x 20	 $\text{\O}1/4" \times 16\text{mm}$ 2 x 34	 $\text{\O}1/4" \times 35\text{mm}$ 3 x 4	 $\text{\O}1/4" \times 50\text{mm}$ 4 x 20
BOLT spare: 2	BOLT spare: 3	BOLT spare: 1	BOLT spare: 2
 $\text{\O}3 \times 12\text{mm}$ 5 x 2	 $\text{\O}4 \times 20\text{mm}$ 6 x 8	 $\text{\O}1/4" \times 20\text{mm}$ 7 x 8	 8 x 1
SOCKET	SOCKET	BOLT spare: 1	SOCKET
 9 x 1	 10 x 1	 11 x 56	 12 x 5
LED STRIP	CABLE HOLE COVER	PLASTIC CAP	CASTER
 13 x 4	 14 x 2	 M4 15 x 1	 M4 16 x 4
CASTER	CASTER	SPANNER	SCREW
 17 x 2	 18 x 4	 M5 19 x 1	 M4 20 x 1
Latch chain	PLASTIC CAP	SPANNER	ALLEN KEY








Parts Identification2/2

Not actual size







CASTER

STEP 1






Please pay attention to the direction of the metal bolt plate.

STEP 2




STEP 3


 Please tighten the bolts to 80% first, and tighten them all when all parts are assembled.




①	x 5
---	-----





②	x 5
---	-----








⑳	x 1
---	-----







⑫	x 5
---	-----




STEP 4






STEP 5





STEP 6

 Please tighten the bolts to 80% first, and tighten them all when all parts are assembled.


	
---	---



	
Ø1/4" x 16mm	
2	x2


	
M4	
20	x 1





STEP 7

 Please tighten the bolts to 80% first, and tighten them all when all parts are assembled.


	
---	---



	
Ø1/4" x 16mm	
2	x2


	
M4	
20	x 1





STEP 8

 Please tighten the bolts to 80% first, and tighten them all when all parts are assembled.

	
---	---


	$\text{Ø}1/4" \times 50\text{mm}$
(4)	x 4



	M4
(20)	x 1





STEP 9


x 2

 Please tighten the bolts to 80% first, and tighten them all when all parts are assembled.





	
---	---

	$\text{Ø}1/4" \times 50\text{mm}$
(4)	x 6





	M4
(20)	x 1



STEP 10





STEP 11




ATTENTION: This metal plate is on the bottom instead of on top. Don't install it wrongly.


STEP 12




Assemble the slats




1. Squeeze the clamp (11) tightly.



2. Put the clamp into the gaps.



3. Put the slat (11) into the clamp.



4. Finished.

STEP 13


⚠ Please tighten the bolts to 80% first, and tighten them all when all parts are assembled.

Ø1/4" x 20mm

7	x 8
---	-----

M4

20	x 1
----	-----



STEP 14

⚠ Please tighten the bolts to 80% first, and tighten them all when all parts are assembled.

Ø4 x 20mm


6	x 8
---	-----

14	x 2
----	-----






M5

19	x 1
----	-----








18	x 4
----	-----





STEP 15




STEP 16




STEP 17




Assemble the slats




1. Squeeze the clamp (11) tightly.



2. Put the clamp into the gaps.






3. Put the slat (11) into the clamp.




4. Finished.




STEP 18





The bolt can be closed by taking it out when the supporting foot is put away




STEP 19



Place the LED tape over the back of Board (B), as shown



The LED switch is free to put onto or hidden underneath the board (M)



Connect LED strip usb and interface of socket.