



# ASSEMBLY INSTRUCTIONS



## **Tools Recommended**

THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION.  
PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.

*Need Parts or Assistance? Email us at [cs@nbrehome.com](mailto:cs@nbrehome.com)*

# IMPORTANT NOTICE

- This product contains small components, please ensure that they are kept away from small children.
- THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION.  
PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.
- Read each step carefully. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.
- Make sure all parts are included. Most parts are labelled or stamped on the raw edge.
- Work in spacious area, preferably on a carpet, near the place the unit will be used.
- Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.
- Move your new furniture carefully, with two people lift and carry the unit to it's new location.
- Never push, drag or pull your furniture (especially on carpet)






## PLEASE DO NOT RETURE PRODUCT TO US IMMEDIATELY





















If a part is missing or damaged, email our customer service.  
We will gladly ship your replacement parts FREE of charge.

Need Parts or Assistance? Email us at [cs@nbrehome.com](mailto:cs@nbrehome.com)

For Prompt, reliable service, please have your assemble instruction ready.


<b>! WARNING</b>	
	<b>Children have died from furniture tipover. To reduce the risk of furniture tipover:</b> <ul style="list-style-type: none"><li>• ALWAYS install anti-tip device provided.</li><li>• NEVER put a TV on this product.</li><li>• NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.</li><li>• NEVER open more than one drawer at a time.</li><li>• Place heaviest items in the lowest drawers.</li></ul>
	<p><i>This is a permanent label. Do not remove!</i></p>




A x75  6x35mm	B x75  6x35mm	C x24  6x30mm	D x6  5x40mm	E x39  4x30mm	F x108  3.5x12mm	G x4 
H x2  4x12mm	I x2  4x12mm	J x2  4x12mm	K x12  4x18mm	L x12  4x18mm	M x2  4x12mm	N x12  4x12mm
O x12  3x14mm	P x2  4x35mm	CL x9 	CR x9 	DR x9 	DL x9 	

# STEP 1

Install the screw A on the part 7,8  
Insert the dowel C into part 3,  
and then put the eccentric B into the corresponding hold and  
use a flat-blade screwdriver to turn it clockwise to tighten,  
the installation is as shown below.




flat-blade screwdriver




# STEP 2

Install the screw A on the part 5,6  
Insert the dowel C into part 2,  
and then put the eccentric B into the corresponding hold and  
use a flat-blade screwdriver to turn it clockwise to tighten,  
the installation is as shown below.





flat-blade screwdriver



# STEP 3







Use the screw F to install the guide rail CL on the side panel 2, and install the guide tail CR on the side panel 3. The installation position is as shown in the figure below.

F	x18	G	x4	CL	x3	CR	x3
							
3.5x12mm							



# STEP 4 <sub>x2</sub>

Use the screw F to install the guide rail CL on the side panel 5, and install the guide tail CR on the side panel 5. The installation position is as shown in the figure below.




F	x36	CL	x6	CR	x6
					
3.5x12mm					


# STEP 5







Assemble parts 10 and part 9 by screw M, the installation position is as shown below.



Install the screw A on the part 11,15 and then put the eccentric B into the corresponding hold and use a flat-blade screwdriver to turn it clockwise to tighten, the installation position is as shown below.






flat-blade screwdriver




# STEP 6

Insert the dowel C into part 4 first,  
then assemble parts 11,15 and part 4 by screw D.  
Assemble part 13 to part 4 by screw D.  
The installation position is as shown below.






# STEP 7

Put the eccentric B into the corresponding hold (part 13;15;11);  
Insert the dowel C into part 2  
and use a flat-blade screwdriver to turn it clockwise to tighten,  
the installation position is as shown below.




flat-blade screwdriver




# STEP 8

Insert part 14 along the slot, the position is as shown below.






# STEP 9

Put the eccentric B into the corresponding hold (part 13;15;11);  
Insert the dowel C into part 3,  
and use a flat-blade screwdriver to turn it clockwise to tighten,  
the installation position is as shown below.



flat-blade screwdriver





B	x4	C	x2
			6x30mm



# STEP 10


Insert the dowel C into part 2/3;  
Insert part 12 along the slot, the position is as shown below.





C	x8
	
6x30mm	


# STEP 11

Install the screw A on the part 1,  
fasten the L-shaped iron piece I with screw H;  
the installation position is as shown below.



A	x8
	
6x35mm	




H	x2
	
4x12mm	

I	x2
	

# STEP 12

Put the eccentric B into the corresponding hole and use a flat-blade screwdriver to turn it clockwise to tighten, assemble part 1, the installation position is as shown below.


flat-blade screwdriver




# STEP 13

## x3


Assemble parts 17,18,22 and part 21 by screw E, the installation position is as shown below.




Insert the bottom plate 20 according to the slot




Install the screw A on the drawer panels 23 first, and then use the screw K to lock the handle L on the drawer panels 23.




Put the eccentric B into the corresponding hole and use a flat-blade screwdriver to turn it clockwise to tighten, assemble drawer front.



Use the screw F to install the guide rail DR/DL on the drawer side panel. the installation position is as shown in the figure below.



flat-blade screwdriver




A x15 6x35mm	B x15	E x15 4x30mm
F x18 3.5x12mm	K x6 4x18mm	L x6
		DR x3
		DL x3


# STEP 14

# x3


Assemble parts 17,18 and part 16 by screw E, the installation position is as shown below.




Insert the bottom plate 19 according to the slot of side plate.




Install the screw A on the drawer panels 25 first, and then use the screw K to lock the handle L on the drawer panels 25.




Put the eccentric B into the corresponding hole and use a flat-blade screwdriver to turn it clockwise to tighten, assemble drawer front.











Use the screw F to install the guide rail DR/DL on the drawer side panel. the installation position is as shown in the figure below.



flat-blade screwdriver




A x12  6x35mm	B x12 	E x12  4x30mm
F x18  3.5x12mm	K x3  4x18mm	L x3 
DR x3 	DL x3 	


# STEP 15

## x3


Assemble parts 17,18 and part 16 by screw E,the installation position is as shown below.




Insert the bottom plate 19 according to the slot of side plate.




Install the screw A on the drawer panels 24 first, and then use the screw K to lock the handle L on the drawer panels 24.




Put the eccentric B into the corresponding hole and use a flat-blade screwdriver to turn it clockwise to tighten, assemble drawer front.





flat-blade screwdriver





Use the screw F to install the guide rail DR/DL on the drawer side panel. The installation position is as shown in the figure below.





F	x18
	3.5x12mm


K	x3
	4x18mm


A	x12
	6x35mm

B	x12
	

E	x12
	4x30mm


L	x3
	

DR	x3
	

DL	x3
	


# STEP 16

Use the screws in component O&N to fasten the back plate buckle.  
The installation position is as shown in the figure below.



# STEP 17

First drill holes on the wall where it is placed, and then use the long screw and expansion screw J to fix the cabinet with screw P. The installation location is as shown in the figure below.



# STEP 18

