



# Assembly Instructions




# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product.






















- VIII. Drill may be needed for securing product to wall.

# Parts List



# Hardware List


A		Ø8x30mm	Wooden dowel	24 pcs
B		Ø6x35mm	Cam bolt	17 pcs
C		Ø15x11mm	Cam lock	17 pcs
D		Ø30mm	Sticker	17 pcs
E		Ø6x50mm	Screw	5 pcs
F		Ø4x32mm	Screw	4 pcs
G		Ø8x60mm	Bolt	4 pcs
H		Ø38mm	Plastic cover	4 pcs
J		Ø8	Washer	4 pcs
K		Ø8X13mm	Nut	4 pcs
L		M13mm	Wrench	1 pc
M		4mm	Hex Key	1 pc
N		Ø4x44mm	Screw	4 pcs
P			Velcro strap	2 pcs
Q		Ø4x25mm	Screw	2 pcs
R			Nut	2 pcs
S		Ø4x12mm	Screw	2 pcs
T			Glue tube	1 pc



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1




Insert wooden dowel (A) into parts (6,7,8) as per diagram.

## Step 2




Insert wooden dowel (A) into parts (2,9) as per diagram.

# Step 3




Using screw (F) attach part (9) to part (2) with Philips head screwdriver as per diagram.

# Step 4




Using screw (E) secure part (2) to part (8) with hex key (M) as per diagram.

# Step 5




Using screw (E) secure part (2) to part (7) with hex key (M) as per diagram.

# Step 6




Secure cam bolt (B) into part (1) with Philips head screwdriver; Attach part (10) to part (3) as per diagram.

# Step 7





Using screw (N) attach part (6) to part (1) with Philips head screwdriver as per diagram.

# Step 8




Insert wooden dowel (A) into parts (4,5). Secure cam bolt (B) to parts (4,5) with Philips head screwdriver. Secure bolt (G) to parts (4,5) as per diagram.

# Step 9





Using cam lock (C) secure parts (2,8) to part (5) with Philips head screwdriver as per diagram.

# Step 10





Using washer (J), nut (K) attach part (3) to part (5) with wrench (L) as per diagram.

# Step 11




Using cam lock (C) secure parts (2,8) to part (4), then using washer (J), nut (K) attach part (3) to part (4) with wrench (L) as per diagram.

# Step 12




Using cam lock (C) secure part (1) to parts (4,5,7,8) with Philips head screwdriver as per diagram.

# Step 13




Place sticker (D) and plastic cover (H) to cover the holes as per diagram.

# Step 14



Put part (11) into unit as per diagram.


# Step 15



Using screw (S) attach Velcro strap (P) to part (1) with Philips head screwdriver as per diagram.


# Step 16

WARNING




Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

Wall




Using screw (Q) attach Velcro strap (P) into Nut (R) to wall with Philips head screwdriver as per diagram.

# Step 17



Position the assembled unit at the desired location, if necessary adjust the floor leveler at the bottom of the support leg to level the unit.

# Step 18



Final Assembly