

T013

User Instruction

Wi-Fi Smart LED Bulb



V1.4

Trouble Shooting

a) APP can not find the device.

- Update APP to newest version.
- Make sure the phone bluetooth is on.
- Allow the permissions of APP. APP needs them to connect.
- Check the light is on.
- Kill APP, turn off bluetooth and turn on bluetooth again, then start APP to add device again.
- Ensure phone within 4ft from product when connecting.
- Your phone may be incompatible with the APP, try another phone.

b) Failed to connect to Wi-Fi.

- Check Wi-Fi supports 2.4GHz. Not 5GHz.
- Reset device by power on and off 3 or 4 times until light breaths.
- Shorten distance between device and router to improve signal.
- Add device and connect it to Wi-Fi again.

c) Device not shown on Alexa APP.

- Remove device from DayBetter APP and add the device again.
- Unlink Alexa, and Link Alexa again.

d) The bulb is so hot.

- The shell is hot when working. It is normal. Please turn off bulb first and wait a minute before touching the bulb.

e) I do not like DayBetter APP.

- You can use Alexa to control the light after linking to Alexa. However we suggest keep DayBetter for full experience.