

Before you get started...

We're confident you will be happy with your new Aspire bed frame.

However it is worth making sure before you unpackage and start to put it together.

Please check the following:

CORRECT COLOUR

Please make sure you are happy with the colour. There is no need to fully unpack, please just check the first component.

PACKAGING

If you're satisfied, then it's time to open. Start by laying out all components on the cardboard. This will prevent the fabric getting stained or scuffed.

COMPONENTS

Finally, double check your components page and ensure you have all parts listed.

RETURNS

If you are not completely satisfied with the product, don't worry. We just need everything back in the original packaging.

INFORMATION


























- Due to the size of this product we recommend that it is assembled in the room intended for use.
- When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.
- Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent it from scratching.
- Check the pack and make sure you have all the parts listed.
- Ensure that this product is fully assembled and secured as illustrated before use.
- Check all screws or bolts are tightened and inspect regularly.
- This product should only be used on firm, level ground.
- Please dismantle for transportation
- Only use the storage compartment when the frame is fully raised in the up position.
- Make sure the legs remain in contact with the ground.
- Keep small parts out of reach of children.
- Use caution when operating, this bed uses a pressured mechanism.
- Keep hands and fingers clear of the mechanism when opening and closing the bed for use.







WARNINGS

- **DO NOT** use power tools to construct this product.
- **DO NOT** tighten screws until fully assembled.
- **DO NOT** over tighten screws or bolts.
- **DO NOT** use this product if parts are missing, damaged or worn.
- **DO NOT** stand on the product.
- **DO NOT** remain on the bed whilst the lifting mechanism is in use.
- **DO NOT** expose this product to dripping or splashing, rain or areas with heavy moisture.
- **DO NOT** place any objects filled with liquids, such as vases, on the product.
- **DO NOT** insert foreign objects into the product or attempt to repair this unit by yourself.
- **DO NOT** place the product in direct sunlight, open flames such as candles or heat, such as radiators. Keep away from temperatures over 35°C.



CARE INSTRUCTIONS

- Hair products such as hairsprays, oils and gels may affect the finish. Avoid prolonged contact with such products.
- Regular cleaning is essential to avoid build up of these products on the surface.
- Avoid exposure to direct or prolonged periods of sunlight and position away from direct heat sources such as radiators.
- Care should be taken to avoid spilling anything on the upholstery. If a spillage occurs act promptly and soak up any liquids by blotting with a clean absorbent cloth. Never rub to remove stains. Never use a wet cloth.
- If a spillage does occur, blot any liquids immediately with a clean, dry absorbent cloth and allow to dry naturally.
- For more stubborn stains a professional upholstery cleaner should be consulted.
- Clean periodically in situ using a professional cleaning company.
- Do not drag the frame across the floor.
- All assembly fixings should always be tightened properly and periodically check all fixings and tighten if necessary.

<p>1. Centre Rail</p> 	<p>2. Side Rail</p> 	<p>3. Head/Foot Rail</p> 	<p>4. Mechanism Fabric Handle</p> 	<p>5. Slat</p> 
<p>6. Outer Slat Mount</p> 	<p>7. Centre Slat Mount</p> 	<p>8. Centre Support</p> 	<p>9. Nut</p> 	<p>10. M8x40 Phillips Bolt</p> 
<p>11. Mattress Hold</p> 	<p>12. Centre Bracket</p> 	<p>13. Grey Corner Bracket</p> 	<p>A. Headboard</p> 	<p>B. Footboard</p> 
<p>C. Side Board</p> 	<p>E. M8 x 20mm Allen Bolt</p> 	<p>F. Allen Key</p> 	<p>G. Small Corner Bracket</p> 	<p>H. Friction Pad</p> 
<p>I. Velcro Bottom Sheet</p> 	<p>J. Rail Protectors</p> 	<p>K. Wooden Cross Beam</p> 	<p>L. Screw Driver</p> 	<p>N. 5x50mm Self Tapping Screw</p> 



Tools



Component	3'	4'	4'6	5'	6'
1	0	1	1	1	1
2	2	2	2	2	2
3	2	2	2	2	2
4	1	1	1	1	1
5	12	24	24	26	26
6	24	24	24	26	26
7	0	12	12	13	13
8	0	2	2	2	2
9	26	26	26	26	26
10	24	24	24	24	24
11	1	1	1	1	1
12	0	2	2	2	2
13	4	4	4	4	4
A	1	1	1	1	1
B	1	1	1	1	1
C	2	2	2	2	2
E	42	42	42	42	42
F	1	1	1	1	1
G	4	4	4	4	4
H	1	1	1	1	1
I	1	1	1	1	1
J	6	6	6	6	6
K	1	1	1	1	1
L	1	1	1	1	1
N	8	8	8	8	8
O	4	4	4	4	4
P	2	2	2	2	2
Q	2	2	2	2	2
R	1	1	1	1	1
S	4	4	4	4	4
T	5	5	5	5	5
U	18	18	18	18	18
V	2	2	2	2	2

Additional components may be included however this is to ensure there are spares if required.


IMPORTANT PISTON INFORMATION

The pistons used in the construction of this product are extremely strong and cannot be operated by hand when not fitted to the ottoman hinges. All pistons are tested in the factory for correct pressure and operation before use.


Initially it might appear that the pistons are very stiff when opening and closing the ottoman frame, **THIS IS NORMAL.**

After operating the ottoman a few times, the movement of the pistons and the opening and closing of the ottoman will become easier.


1) Position all 4 Grey Corner Brackets (13), Side Rails (2), and Head/ Foot Rails (3). Ensure holes in the Head/Foot Rails for mattress holder face upwards. Ensure slat holes on Side Rails face upwards.




2) Ensure the 2 larger through holes in the Side Rails (2) are at the same end of the completed sub-frame.




(3) Tighten the Nuts (9) and M8x40mm Phillips Bolts (10) using the Screw Driver (L) and Spanner (R) provided. Ensure the nuts are on the inner side of the slat frame. **If Frame is 3ft skip to 7.**




4) Attach Centre Brackets (12) to both ends of the Centre Rail (1) using Nuts (9) and M8x40mm Phillips Bolts (10) with the Screwdriver and Spanner provided.




5) Attach the Centre Brackets (12) to the Head/Foot Rails (3) with Nuts (9) and M8x40mm Phillips Bolts (10) with the Screwdriver and Spanner provided.




6) Connect 2 x Slats (5) with 2 x Outer Slat Mount (6) and 1 x Central Slat Mount (7). Repeat this step with all the slats.




7) Press the connected slats and mounts into the Slat Frame. **If 3ft skip to 10.**




8) Insert M8x40mm Phillips Bolts (10) into 2 larger through-holes on the Centre Rail




9) Turn the Slat Frame on its side and screw the Centre Supports (8) into the Centre Rail (1). These only need to be hand tight for now.




10) Screw the 4 Feet (O) into place on the Headboard (A) and Footboard (B) using 5x50mm Self Tapping Screws (N) and Screwdriver (L)




11) Lay down both Side Boards (C) and attach Small Corner Brackets (G) and Silver Support Brackets (T) using M8x20mm Allen Bolts (E). Only finger tighten for now




12) Fit Rail Protectors (J) to the both Side Boards (C), positioned as shown below. Line up to labels attached.



13) Attach the Rail Protectors (J) using the 3 x 20mm Self Tapping Screws (U) and Screwdriver (L).




14) Attach the Small Corner Brackets (G), Silver Support Brackets (T) and Sideboards (C) to the Headboard (A) using the M8 x 20mm Allen Bolts (E). Only finger tighten.




Note: Ensure 4 remaining holes in each Side Board are closest to the Headboard


15. Attach a Silver Support Bracket (T) on a 90° angle as a centre support on the Headboard (A) using the M8 x 20mm Allen Bolts (E). Attach stick on Friction Pad (H)




16) Attach the Side Boards (C), Silver Support Brackets (T) and Small Corner Brackets (G) to the Footboard (B) using M8 x 20mm Allen Bolts (E). Only finger tighten.




17) Once all 4 corners are correctly positioned, tighten all M8 x 20mm Allen Bolts (E) using provided Allen Key (F) on the Headboard (A), Footboard (B) and Side Boards (C).




18) Line up the Cross Beam Brackets (V) with the marked lines on the Wooden Cross Beam (K).




19) Attach the Cross Beam Brackets (V) to the Wooden Cross Beam (K) with six 3x20mm Self Tapping Screws (U) using the Screwdriver (L) provided.




20) Next Attach the Ottoman Arms (Q) to the Side Boards (C).




21) Finger tighten M8 x 20mm Allen Bolts (E) into points B, C & D




22) Position the Wooden Cross Beam (K) at point A with the Cross Beam Bracket (V) between the Ottoman Arm (Q) and the Sideboard (C).




23) Screw the Cross Beam into place using M8 x 20mm Allen Bolts (E) and tighten using Allen Key (F). Tighten remaining 3 Allen Bolts using Allen Key. Repeat on opposite Sideboard.




24) Position the Slat Frame on top of the Ottoman Arms. Ensure 2 larger through holes are towards the Headboard. 2 people required for the remaining steps.




25) Screw the Slat Frame to the Ottoman Arms (Q) Using M8 x 50mm Allen Bolts (S) and Nuts (9). Only finger tighten these for now. 2 Nuts and Allen Bolts on each side.




26) Correctly position the Slat Frame so it can move up and down without obstruction.




27) Tighten the Allen Bolts (S) and Nuts (9) using the Allen Key (F) and Spanner (R) provided.




28) Connect both Pistons (P) using the attached locking nuts. Tighten using Spanner (R) *



29) Tighten up the Centre Supports (8) using the Screw Driver (L) provided.




30) Position the Mattress Hold (11) at the headboard end of the Slat Frame.




Pistons will be stiff to begin with. They will ease with time. Only use with Mattress in place.

31) Attach the Mechanism Fabric Handle (4) to the footboard end of the slat Frame. Loop through itself around the Foot Rail.



32) Turn the frame on its side and attach the Velcro Bottom Sheet (I). Loosen feet slightly to correctly position, then retighten. Ensure the slat frame is held closed.



***When in use only lift and push the Slat Frame Mechanism from the centre of the Slat Frame ***

Only operate ottoman mechanism with mattress in place

If pistons wear out, do not operate. Please contact us for further information