

LED Ghost Yard Decoration

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

PARTS LIST

- A. 1 EA. GHOST SIGN WITH POWER ADAPTER
- B. 1 EA. STAKE

NO TOOLS REQUIRED

ASSEMBLY

Carefully remove the contents from the carton and keep the carton for future storage. Be sure to untangle any wires that may be tangled with other items. (Please DO NOT forcibly remove any contents.)

Step 1: For outdoor use, attach the stake to the ghost sign and tighten the wing nut to secure it in place. For indoor use the stake is not needed.

Step 2: Push the stake into the ground to secure the sign. If the soil is very hard, attach the stake to the ground first using a hammer, if needed, and then attach the sign to the stake.

Step 3: Plug the power adapter to the power outlet.

THIS PRODUCT IS SUITABLE FOR INDOOR AND OUTDOOR USE

IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ AND FOLLOW ALL SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be practiced including the following:

- **WARNING:** Risk of Electric Shock. When products are used in outdoor applications, connect the product only to a covered Ground Fault Circuit Interrupter (GFCI) protected receptacle that is weatherproof with the power unit connected to the receptacle. If you do not have one, contact a qualified electrician for proper installation. Ensure that the power unit and cord do not interfere with completely closing the receptacle cover.
- Read and follow all instructions that are on the product or provided with the product.
- Not to use with receptacles that are weatherproof only when the receptacle is covered (attachment plug cap not inserted and receptacle cover closed).

- Do not operate this product if the power cord or plug is damaged. Always inspect electrical cords for signs of damage or wear. If there are any observable defects, immediately dispose of them and replace it with one that is in working order.
- Do not use an extension cord.
- Do not use in a bathroom or within 10 feet of a pool.
- This is an electrical product - not a toy! To avoid risk of fire, burns, personal injury and electric shock, it should not be played with or placed where small children can reach it.
- Reference the National Electrical Code, ANSI/NFPA 70, specifically for the installation of wiring and clearances from power and lighting conductors.
- Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction.
- This seasonal use product is not intended for permanent installation or use.
- This product is not intended for commercial purposes.
- Do not secure the wiring of this product with staples or nails or place on sharp hooks or nails.
- Do not alter the construction of the wiring in anyway.
- Unplug the product when leaving the house, retiring for the night or if left unattended.
- Do not use this product for anything other than its intended use.
- Do not close doors or windows on the product or extension cords as this may damage the wire insulation.

SAVE THESE INSTRUCTIONS FOR FUTURE USE

FCC STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.