













F09B603 & F09B607 & F09B611**LOVESEAT**

| | | | |
|----|---|-------------------------------------|------|
| A1 |  | Left Arm Rest | 1PC |
| A2 |  | Right Arm Rest | 1PC |
| B |  | Seat Back | 1PC |
| C |  | Seat Base | 1PC |
| D |  | M6 x 18 Socket Head Cap Screw | 6PCS |
| E |  | M6 x 40 Socket Head Cap Screw | 2PCS |
| F |  | Washer | 8PCS |
| G |  | Allen Key | 1PC |



| | | | |
|---|--|--------------|------|
| H |  | Back Cushion | 2PCS |
| J |  | Seat Cushion | 1PC |

- ① Attach right arm rest (A2) to seat base (C) using M6 x 18 socket head cap screw (D) and washer (F) as shown. Do this in two places.




Loose attach all connections
at the beginning, adjust
alignments then fully tighten
all joints


F09B603 & F09B607 & F09B611

LOVESEAT

- ② Attach left arm rest (A1) to seat base (C) using M6 x 18 socket head cap screw (D) and washer (F) as shown. Do this in two places.









- ③ Attach seat back (B) to left and right arm rest (A1&A2) using M6 x 40 socket head cap screw (E) and washer (F) as shown. Do this in four places. Connect seat back (B) with seat base (C) using M6 x 18 socket head cap screw (D) and washer (F).



F09B603 & F09B607 & F09B611

COFFEE TABLE




| PART LIST | FIGURE | QUANTITY | DESCRIPTION |
|-----------|---|----------|---------------|
| A |  | 1 PC | TABLE TOP |
| B |  | 4 PCS | LEG |
| C |  | 1 PC | LEG CONNECTOR |
| D |  | 12 PCS | BOLT (M6*28) |
| E |  | 12 PCS | FLAT WASHER |
| F |  | 1 PC | ALLEN WRENCH |

COFFEE TABLE

STEP 1


A. PLACE TABLE TOP (A) UPSIDE DOWN ON A FLAT, PROTECTED SURFACE.

B. ATTACH LEGS (B) TO TABLE TOP (A) WITH FLAT WASHER (E) AND BOLT (D) USING ALLEN WRENCH (F). DO NOT TIGHTEN COMPLETELY.



STEP 2

A. ATTACH LEG CONNECTOR (C) TO LEG (B) WITH FLAT WASHER (E) AND BOLT (D) USING ALLEN WRENCH (F). DO NOT TIGHTEN COMPLETELY.



STEP 3

A. ROTATE TABLE TO UPRIGHT POSITION SO THAT IT STANDS STABLE ON THE FLOOR.

B. TIGHTEN ALL BOLTS SECURELY USING ALLEN WRENCH (F).

TIGHTEN LEG CONNECTOR (C) FIRST, THEN TIGHTEN LEG (B) TO TABLE TOP (A).

C. KEEP ALLEN WRENCH (F) TO TIGHTEN ALL BOLTS PERIODICALLY AS NEEDED.

