







INSTALLATION INSTRUCTIONS

10'x10' LEAN TO GAZEBO



REQUIRED TOOLS

Tools			
	Gloves	Table	Ladder
			
	Power drill	Screw driver	Tape Measure

ASSEMBLY TIPS

Handle each part of the gazebo with care, as many components have sharp edges.

DO NOT attempt to assemble the gazebo before verifying that all parts are present as listed. Partially assembled structures can be severely damaged by light winds.

DO NOT attempt to assemble the gazebo on windy days, as this can make construction difficult and unsafe. Monitor the weather closely. During construction and until the gazebo is fully assembled, **keep children and pets away from the worksite to avoid distractions and potential accidents.** Avoid placing weight concentrated on the roof of the gazebo.

ASSEMBLY

The best location is a flat area.

Ensure there is adequate space around the gazebo to access the roof with a ladder.

TEAMWORK:


Two or more people are required to assemble the structure.

Maintenance

- Steel components for this gazebo are treated with rust inhibiting paint . However, due to the nature of steel, surface oxidation (rusting) will occur if these protective coatings are scratched. This is not a defect and thus not covered by the warranty.
- To minimize this condition, it is recommended to use care when assembling and handling the product to prevent scratching the paint. Should any scratching or damage occur, it is recommended to cover the scratch immediately with rust inhibiting resistant paint (not included).
- Do not use bleach, acid, or other abrasive cleaners on the roof or frame parts.
- Keep instruction manual for future reference.
- Keep the original packaging to store the gazebo.
- Periodically check and ensure that all bolts are well-tighten during use.





Installation size diagram

10x10






































Installation size diagram


10x10



Parts List



A X2  Top Back Leg	B X2  Top Front Leg	C X4  Bottom Leg	D X2  Side Beam(left)
D1 X2  Side Beam(right)	E X5  Board Arm	E1 X5  Board Arm	F X4  Board Protection
G X6  Board Protection	G1 X2  Board Protection	H X5  Arm Down Connection	I X15  Arm Hold Tube
I2 X5  Arm Hold Tube	K X14  Board	L X4  Leg Connection	M X10  Wall Connection&Base
N1 X2  Beam Connection	O X1  Right Beam Hold	P X1  Left Beam Hold	Q X10  Arm&Beam Connection
S X5  Arm Up Connection	U X4  Beam Plug	V X10  Arm Plug	Z2 X15  Middle Beam Connection
Z3 X10  Side Beam Connection	Z X1  Allen Wrench	W1 X143  Bolt M6*15	W2 X8  Bolt M6*70
W4 X10  Bolt M6*35	X X61  Bolt ST4.2*10	X1 X72  Bolt ST4.2*13	Y X16  Bolt M6*15
X2 X61  Bolt Washer	Z5 X20  Expansion Bolt	Z5 X20  Tent stake	

STEP 1




X2






2. Fix the A&C connection point with W1 bolts.



X2


4. Fix the B&C connection point with W1 bolts.




 A	x2	 L	x4
 B	x2		
 C	x4	 W1	x32

STEP 2



2. Use W2 to fix M in the specific hole of C.



1. Use W1 to fix M in the specific hole of A.




3. Repeat the last step. Use W2 to fix M in the specific hole of C.




STEP 3

X2


1. Connect D and D1 with N1.








2. Fix the D&D1 connection point with W1 bolts.



3. Use U to plug D&D1.




X2



	D x2		W1 x16
	D1 x2		
	N1 x2		U x4

STEP 4

1. Use Y to fix A/B and D/D1.




X4




STEP 6

X5









1. Use W1 to fix Q in the specific hole of E&E1.

2. Connect E and E1 with S, and fix them with W1 bolts.




X2




	E x5		Q x10
	E1 x5		
	S x5		W1 x40

STEP 7

1. Connect D/D1 and E/E1 with Q, and fix them with W1 bolts.



X10










W1 x20

STEP 8

1. Connect E and I with Z3, fix them with W1 and X1 bolts.



2. Connect E and I/I2 with Z2, fix them with W1 and X1 bolts.




	I x3		Z3x2
	I2 x1		X1 x8
	Z2x3		W1 x5




STEP 9

! These three holes do not need to be aligned with the holes on E/E1



1. Use V to plug H.




	H x5
	V x10
	W4 x10

STEP 10


! Note: The I2 side hole faces outward

1. Connect I and I/I2 with Z2, fix them with W1 and X1 bolts


2. Connect E/E1 and I with Z3, fix them with W1 and X1 bolts.









X12



X8





	I x12		X1 x32
	I2 x4		
	Z2 x12		Z3 x8
			W1 x20


STEP 11

1. Put K on the I/I2 and E1, fix them with X and X2.

Note: K need to be stacked.





2. Fix K and E1 with X2&X.



X12

X4




STEP 12

2. Put K on the I/12 and E1, fix them with X and X2.

Note: K need to be stacked.


1. Fix K and E1 with X2&X.



3. Fix K and K with X&X2.

4. Fix K and K with X&X2.



5. Fix K and K with X&X2.



STEP 13


1. Use X1 to fix F and E/E2.

2. Stack F, and use X1 to connect them with E.






STEP 14

1. Use X1 to fix G and I.






2. Use X1 to fix G1 and I2.





STEP 15



1. Use X1 to fix G1/G and I.



STEP 16



1. Secure the product to both the wall and the floor using Z5 .



or

