



3 DOOR SLIDER WARDROBE GREY GLOSS ASSEMBLY INSTRUCTIONS




IMPORTANT FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.






































PARTS LIST

Please Note:

The below parts have all been stamped with the part number to help identify them during assembly.



Part Number	Part Description	Quantity	Carton
1	Base Panel	1	1/4
2	Left Side	1	2/4
3	Right Division Panel	1	3/4
4	Top Panel	1	1/4
5	Left Division Panel	1	3/4
6	Right Side	1	2/4
7	Front Baseboard	1	1/4
8	Back Baseboard	1	1/4
9	Crossbeam	2	1/4
10	Frame	1	1/4
11	Fixed Shelf	1	1/4
12	Door	2	4/4
13	Back Panel	6	2/4
14	Small Divider Panel	2	1/4
15	Large Shelf Panel	1	3/4
16	Movable Shelf	2	3/4
17	Mirrored Door	1	4/4

FITTINGS LIST

A x 8  Cam Bolt 32xØ6mm 1/+	B x 12  Can Nut Ø15 mm 2/+	C x 34  Screw Ø4 x 14 mm 2/+	D x 8  Shelf Support 7x6 1/+	E x 34  Dowel Ø6 x 30 mm 2/+
F x 24  Screw Ø4 x 50 mm 2/+	G x 6  Dowel Ø6 x 70 mm 1/+	H x 68  Nail 10x10 Ringed -1,5x23mm 2/+	I x 14  Back Panel Bracket 14x14 mm 2/+	J x 13  18x18 Corner 2/+
K x 4  Washer Ø16x7 mm 1/+	L x 12  Plastic Foot L 19x17x8mm Ø2mm 2/+	M x 4  Hanging Rail Support	N x 2  Screw Ø3,5 x 30 mm 1/+	O x 32  Screw Ø3,5 x 14 mm 2/+
P x 32  Screw Ø3 x 16 mm 2/+	Q x 2  Cam Bolt (Double) (2x)	R x 10  Screw Ø3,5 x 35 mm 2/+	S x 2  Strap 200x20x1mm	T x 32  Triangle Support Angle 2/+
U x 46  Hole Plugs 19mm 2/+	V x 2  Glue 10g	W x 18  Silicone Drop Ø6x2mm 2/+	X x 2  Dowel Ø6 x 40 mm 1/+	Y x 1  MDF Spacer 80x27x3mm
Z x 1  Top Rail 2398x60x23mm cart. 1/4	A1 x 1  Lower Rail 2398x42x5mm cart. 1/4	B1 x 3  Handle Profile 1760x38x16mm cart. 2/4	F1 SLIDING SYSTEM KIT x 3  Lower Roller Latch x6  Sliding System Lock x4  Screw Ø3,5 x 16 mm x40 (2/+)  Upper Roller Latch x6	
C1 x 3  Back Panel Strip 1787x19x6mm cart. 2/4	D1 x 2  Hanging Rail 780x28x16mm cart. 1/4	E1 x 2  Back Panel Strip 297x19x6mm cart. 2/4		


TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT, ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE



CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)



STEP 1

PARTS REQUIRED

7 - FRONT BASEBOARD x1

8- BACK BASEBOARD x1

9- CROSSBEAM x2

HARDWARE REQUIRED




C  04

H  08

J  04

L  08

TOOLS REQUIRED



STEP 2

PARTS REQUIRED

7 - FRONT BASEBOARD x1

8- BACK BASEBOARD x1

9- CROSSBEAM x2




HARDWARE REQUIRED

E  16

G  04

V  01

TOOLS REQUIRED



STEP 3

PARTS REQUIRED

1- BASE PANEL x1

10- FRAME x1

HARDWARE REQUIRED



C  02

E  04

J  02

V  01

TOOLS REQUIRED



STEP 4

PARTS REQUIRED

1- BASE PANEL x1


HARDWARE REQUIRED

A  04

A1  01

O  05

TOOLS REQUIRED



STEP 5

PARTS REQUIRED

11- FIXED SHELF x1

14 - SMALL DIVIDER PANEL x2


HARDWARE REQUIRED

E  06


G  02

V  01


TOOLS REQUIRED



Detail 25



Detail 1



STEP 6

PARTS REQUIRED

2- LEFT SIDE x1

HARDWARE REQUIRED




C  02

H  02

L  02


M  01

TOOLS REQUIRED



Please note:
Pre-marked
Holes

Detail 6







Detail 2

STEP 7




PARTS REQUIRED

6- RIGHT SIDE x1

HARDWARE REQUIRED

C		02
H		02
L		02
M		01

TOOLS REQUIRED







STEP 8




PARTS REQUIRED

3 - RIGHT DIVISION PANEL x1

HARDWARE REQUIRED

C		02
M		01
V		01
X		01

TOOLS REQUIRED



STEP 9




PARTS REQUIRED

3- RIGHT DIVISION PANEL x1

HARDWARE REQUIRED

D  04

TOOLS REQUIRED



Detail 7

STEP 10

PARTS REQUIRED

5- LEFT DIVISION PANEL x1

HARDWARE REQUIRED



C  02

M  01


V  01

X  01

TOOLS REQUIRED



Detail 25



**Please note:
Pre-marked
Holes**

STEP 11




PARTS REQUIRED

5- LEFT DIVISION PANEL x1

HARDWARE REQUIRED

D  04

TOOLS REQUIRED



STEP 12

PARTS REQUIRED

4- TOP PANEL x1

HARDWARE REQUIRED




C  05

E  04

J  05

V  01

TOOLS REQUIRED



Please note:
Pre-marked
Hole


Detail 3

STEP 13

PARTS REQUIRED

4- TOP PANEL x1


HARDWARE REQUIRED

A  02

O  12

Z  01

TOOLS REQUIRED



STEP 14

PARTS REQUIRED

15- LARGE SHELF PANEL x1



HARDWARE REQUIRED

A  02

E  04

V  01

TOOLS REQUIRED



STEP 15

PARTS REQUIRED

7- FRONT BASEBOARD x1

8- BACK BASEBOARD x1


9- CROSSBEAM x2

HARDWARE REQUIRED

C  04

V  01


TOOLS REQUIRED



STEP 16

PARTS REQUIRED


2- LEFT SIDE x1





HARDWARE REQUIRED

F  02

U  02

V  01


TOOLS REQUIRED



STEP 17


PARTS REQUIRED

1- BASE PANEL x1




HARDWARE REQUIRED

F  03

U  03

V  01

TOOLS REQUIRED




Attach base to Dowels of the Crossbeam

STEP 18

PARTS REQUIRED

6- RIGHT SIDE x1





HARDWARE REQUIRED

F  05

U  05


V  01

TOOLS REQUIRED




STEP 19





PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED




Detail 10

STEP 20

PARTS REQUIRED

3- LEFT DIVISION PANEL x1




5- RIGHT DIVISION PANEL x1




HARDWARE REQUIRED




TOOLS REQUIRED



Detail 27




Detail 11



STEP 21

PARTS REQUIRED

11- FIXED SHELF x 1






HARDWARE REQUIRED

F  04


U  04

V  01

TOOLS REQUIRED



Detail 27




Detail 9

STEP 22

PARTS REQUIRED

15- LARGE SHELF PANEL x1



HARDWARE REQUIRED




B  02

F  04


U  06

V  01


TOOLS REQUIRED




Detail 9



Detail 11



Cam bolt head needs to be in centre




Detail 27

STEP 23

PARTS REQUIRED







14- SMALL DIVIDER PANEL x2



HARDWARE REQUIRED

B		04
Q		02
U		04
V		01


TOOLS REQUIRED



STEP 24

PARTS REQUIRED



4- TOP PANEL x1




HARDWARE REQUIRED

B		02
F		06
U		08
V		01


TOOLS REQUIRED



Detail 9



Detail 11




Detail 27

STEP 25

PARTS REQUIRED





13 - BACK PANEL x2




HARDWARE REQUIRED

H 06


TOOLS REQUIRED



* For your future reference
Order Number should be here



Detail 15




Detail 15

STEP 26

PARTS REQUIRED

13 - BACK PANEL x2








HARDWARE REQUIRED


H 06

C1 02


TOOLS REQUIRED



Detail 15



Detail 16




Detail 16

STEP 27

PARTS REQUIRED

13 - BACK PANEL x2



HARDWARE REQUIRED





H  20

I  14


C1  01

E1  02


TOOLS REQUIRED




Detail 14




Detail 15



Detail 16




Detail 24



STEP 28

PARTS REQUIRED





HARDWARE REQUIRED

H  24


P  32

T  32






TOOLS REQUIRED



Detail 17



Detail 15



STEP 29

PARTS REQUIRED

16 - MOVABLE SHELF x2




HARDWARE REQUIRED







Y  01

D1  02

F1  04

F1  04

TOOLS REQUIRED



USE TEMPLATE (Y) TO ASSEMBLE THE SLIDING SYSTEM BRAKE

MAKE THIS ASSEMBLY ON BOTH SIDES OF THE WARDROBE

STEP 30

PARTS REQUIRED






10- FRAME x1



HARDWARE REQUIRED

C  02

TOOLS REQUIRED




Detail 23

Align Corners

Detail 23

STEP 31



PARTS REQUIRED



HARDWARE REQUIRED


C		09
J		02

TOOLS REQUIRED



Detail 13

Detail 13



STEP 32



PARTS REQUIRED

12- DOOR	x2
17- MIRRORED DOOR	x1


HARDWARE REQUIRED

B1		03
O		15

TOOLS REQUIRED



Detail 19



Detail 19

STEP 33


PARTS REQUIRED

HARDWARE REQUIRED


TOOLS REQUIRED

F1


SLIDING SYSTEM KIT




Lower Pulley x6




1° UNSCREW



2° PUSH THE WHEEL UP UNTIL IT TOUCHES THE SCREW



3° SLIDE TO LOCK



STEP 34

PARTS REQUIRED


12- DOOR x2

17- MIRRORED DOOR x1

HARDWARE REQUIRED

F1

SLIDING SYSTEM KIT



Lower Pulley X6





Upper Pulley X6




Screw Ø3.5 x 16 mm X36


TOOLS REQUIRED





Detail 21




29mm




29mm



Detail 20






60mm



60mm

ATTENTION



1°

Fit the Door

2°

Unlock the Pulley

STEP 35


PARTS REQUIRED

12- DOOR x1



HARDWARE REQUIRED

TOOLS REQUIRED



STEP 36


PARTS REQUIRED

12-DOOR x1




HARDWARE REQUIRED

TOOLS REQUIRED




ATTENTION

1



1° Fit the Door




2° Unlock the Pulley

STEP 37



PARTS REQUIRED

17 - MIRRORED DOOR x1



HARDWARE REQUIRED





TOOLS REQUIRED



ATTENTION

DOORS ADJUSTMENT

Illustrative Picture




BEFORE REGULATION
UNLOCK THE PULLEY



BEFORE REGULATION
UNLOCK THE PULLEY

STEP 38

PARTS REQUIRED





HARDWARE REQUIRED



TOOLS REQUIRED



TIP
If desired, after assembly use an alcohol cleaner to erase the number printed on the parts.






WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.



HARDWARE LIST

- S** Strap (Anti-Tip Kit) (2x)
- N** Wood Screw (Anti-Tip Kit) 3.5 x 30mm (2x)
- K** Washer (Anti-Tip Kit) (4x)