


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT


Tools Required For Assembly:

Box Wrench




(Included)

Allen Wrench



(Included)

Wrench



(Included)



2 PERSONS RECOMMENDED

ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.

BASIC ASSEMBLY TECHNIQUES



When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.



Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Parts List




#1 x 1pc
Handrail




#2 x 2pcs
Long Railing




#3 x 1pc
Short Railing




#4 x 2pcs
Side Frame



#5 x 1pc
Top Panel



#6 x 1pc
Bottom Panel



#7 x 1pc
Wine Rack




#I x 1pc
Wrench


Hardware List




#A x 12pcs
Nut



#B x 8pcs
Bolt 1/4" X 1 1/4"



#C x 8pcs
Cap Screw 1/4" X 1 1/2"



#D x 2pcs
Cap Screw 1/4" X 5/8"



#E x 22pcs
Flat Washer



#F x 4pcs
Caster




#G x 1pc
Box Wrench



#H x 1pc
Allen Wrench




#C x 4pcs
 #D x 2pcs
 #E x 6pcs





1. Prepare 4 bolt assemblies by inserting a flat washer (#E) onto the bolts (#C). Align the ends of the long railings (#2) to the holes along the top panel (#5). Then insert the bolts and secure using the Allen wrench (#H).

2. Prepare 2 bolt assemblies by inserting a flat washer (#E) onto the bolts (#D). Align the ends of the wine rack (#7) to the holes along the bottom panel (#5). Then insert the bolts and secure using the Allen wrench (#H).



#A x 8pcs
 #B x 8pcs
 #E x 8pcs

1. Place the side frames (#4) face down onto a protected surface. Then insert the top panel (#5) face down into the bottom ridges and the bottom panel (#6) into the top ridges.



2. Insert a bolt (#B) into each hole from beneath.


3. Then apply a flat washer (#E) and a nut (#A) onto the ends. Secure using the wrench.




#E x 4pcs
#F x 4pcs

1. Apply a flat washer (#E) onto the threaded ends of the casters (#F).

2. Then insert the casters into the corner holes along the bottom panel (#6).



#C x 4pcs
#E x 4pcs



1. Prepare 4 bolt assemblies by inserting a flat washer (#E) onto the bolts (#C).

2. Align the ends of the handrail (#1) and short railing (#3) to the top sides along the top panel (#5).

3. Then insert the bolts from below and secure using the Allen wrench (#H).